

Häggglunds CBp

Radial piston hydraulic motor



The data specified only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. Catalog specifications do not constitute assured characteristics. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

© This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth AG. It may not be reproduced or given to third parties without its consent.

The cover shows an example configuration. The product delivered may differ from the image on the cover.

The original instruction manual were prepared in English

Contents

1	About this documentation	5
1.1	Validity of the documentation	5
1.2	Required and additional documentations	5
1.3	Presentation of information	5
1.3.1	Safety messages	6
1.3.2	Symbols	6
2	Safety instructions	7
2.1	About this chapter	7
2.2	Intended use	7
2.3	Improper use	7
2.4	Personnel qualification	8
2.5	General safety instructions	8
2.6	Product and technology-related safety messages	9
2.7	Personal protective equipment (PPE)	10
3	General notes regarding property damages and product damages	11
4	Scope of delivery	13
5	About this product	13
5.1	Performance description	13
5.2	Product description	13
5.3	Product identification	14
6	Transport and storage	15
6.1	Product transport	15
6.1.1	Lifting methods	15
6.1.2	Lifting motors and accessories	16
6.2	Product storage	19
6.2.1	Standing the motor on a flat surface	19
6.2.2	Storing for extended periods or in uncontrolled environment	20
6.2.3	Storing during maintenance	21
7	Installation	21
7.1	Unpacking	21
7.2	Installation conditions	22
7.2.1	Spline shaft end	22
7.2.2	Plain shaft end	22
7.3	Required tools	23
7.3.1	Assembly tool for coupling adapter CBp 280 to CBp 840	23
7.3.2	Assembly tool for CBp motor	24
7.4	Product installation	25
7.4.1	Fitting the torque arm on the motor	26
7.4.2	Single ended torque arm installation	28
7.4.3	Double ended torque arm installation	33
7.4.4	Mounting of coupling adapter	38
7.4.5	Mounting of spline motor	44
7.4.6	Draining and venting of the motor	48
7.4.7	Flushing	50
7.4.8	Hydraulic connections	51
7.4.9	Direction of rotation of motor shaft	53

8	Commissioning	54
8.1	Commissioning	54
8.1.1	Oil filling	54
8.1.2	Start of the hydraulic supply	55
8.2	Re-commissioning after standstill	55
9	Operation	56
10	Maintenance and repair	56
10.1	Cleaning and care	56
10.2	Inspections	57
10.3	Maintenance plan	59
10.4	Maintenance	60
10.4.1	Filter maintenance	60
10.4.2	Oil maintenance	60
10.5	Repair	61
10.6	Spare parts	61
11	Removal and replacement	61
11.1	Required tools	61
11.2	Preparing for removal	61
11.3	Removing motor	62
11.4	Preparing the components for storage or further use	64
12	Disposal	65
12.1	Environmental protection	65
13	Extension and conversion	65
14	Troubleshooting	66
15	Technical data	67
15.1	Technical data, Häggelunds CBp	67
15.1.1	Hydraulic fluids	67

1 About this documentation

1.1 Validity of the documentation

This documentation applies to the radial piston hydraulic motor Häggglunds CBp and is intended for machine/system manufacturers, users and service engineers.

This documentation contains important information on the safe and appropriate assembly, transport, commissioning, operation, maintenance, disassembly and simple troubleshooting of the product.

- ▶ Prior to working with the Häggglunds CBp, read the entire documentation carefully, in particular the “Safety instructions” chapter.

1.2 Required and additional documentations






- ▶ Before commissioning the product, make sure to have received and fully understood the documentations identified by the book symbol  and observe the instructions included in these documentations.

Table 1: Required and additional documentations

Title	Document number	Document type
 Radial Piston Hydraulic motor, Häggglunds CBp	RE 15301	Data sheet
 Order confirmation	Contains the order-related technical data for your Häggglunds CBp	Order confirmation
 Torque arms, Häggglunds TC A, DTCA, DTCB, DTCBM	RE 15355	Data sheet
 Hydraulic fluid quick reference Häggglunds products	RE 15414	Data sheet

1.3 Presentation of information

Consistent safety instructions, symbols, terms and abbreviations are used in the present documentation to facilitate orientation for the reader and to ensure safe product handling. The explanations in the following sections will provide for easy understanding.

1.3.1 Safety messages




Consistent safety instructions, symbols, terms and abbreviations are used in the present documentation to facilitate orientation for the reader and to ensure safe product handling. The explanations in the following sections will provide for easy understanding.

Safety messages are structured as shown below:

 SIGNAL WORD
Type and source of risk Consequences if disregarded <ul style="list-style-type: none"> ▶ Precautionary measures ▶ <listing>

- **Warning sign:** Draws attention to the risk
- **Signal word:** Identifies the hazard level
- **Type and source of risk:** Identifies the type and source of the hazard
- **Consequences:** Describes what occurs when the safety messages are not complied with
- **Precautions:** Indicates how the hazard can be avoided



Table 2: Risk categories to ANSI Z535.6-2006

Warning sign, signal word	Meaning
 DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	Indicates potential property damage: the product or the environment may be damaged.

1.3.2 Symbols

The following symbols identify notices that are not safety-relevant, but enhance the comprehensibility of the documentation.

Table 3: Meaning of the symbols

Symbol	Meaning
	When this information is not observed, optimum use or operation of the product cannot be ensured.
▶	Single, independent step.
1.	Numbered instructions:
2.	The number indicates that the different steps are to be performed successively.
3.	
	Center of gravity Markings on packaging to indicate where the center of gravity are.

2 Safety instructions

2.1 About this chapter

This product has been manufactured in strict compliance with the generally accepted rules of technology. However, this does not exclude the risk of damage to persons or property if this chapter and the safety instructions included in the present documentation are not observed.

- ▶ Read the entire documentation carefully before starting to use the product.
- ▶ Keep this documentation in a location where it is accessible to all users at any time.
- ▶ When passing over the product to third parties, make sure to include the necessary documentation.

2.2 Intended use

The Hägglunds CBp is a radial piston hydraulic motor.

In an application the CBp motor is classified as component. The CBp motor may only be commissioned after it has been installed in the machine/system for which it is intended and the safety of the entire system has been established in accordance with the machine directive.

The product is intended for professional and not for private use.

Intended use includes having read and understood the entire documentation, in particular the “Safety instructions” chapter.

The product is intended for the following use:

- Radial piston motor in open or closed circuit. The radial piston motor is only approved to be used in motor mode or pump mode.

Observe the technical data, application and operating conditions and performance limits as specified in the product-specific data sheet and in the order confirmation.

2.3 Improper use

Any use other than that described as intended use shall be considered as improper and is therefore impermissible.

Bosch Rexroth shall accept no liability whatsoever for damage resulting from improper use. The user shall bear all risks arising from improper use.

Similarly, the following foreseeable faulty usages are also considered to be improper.

Improper use of the product includes:

- Using outside the operating parameters approved in the product-specific data sheet or in the order confirmation (unless customer-specific approval has been granted).
- Use of fluids outside of the standards as specified in *15.1.1: Hydraulic fluids* and in [Data sheet RE 15414](#) Hydraulic fluid quick reference.
- Modification of factory settings by non-authorized persons.
- Use of add-on parts (e.g. mountable filter, control unit, valves) that are not specified by Bosch Rexroth must be approved by contact at Bosch Rexroth.
- Extension or conversion is not permissible and has to be approved by contact at Bosch Rexroth.

- Using the Radial piston motor under water without necessary additional measures.
- Using the Radial piston motor when the exterior pressure is greater than the interior pressure (case pressure).
- Using the Radial piston motor in explosive environments unless the component or machine/system has been certified as compliant with the ATEX directive 2014/34/EU.
- Using the Radial piston motor in an aggressive environment without necessary additional measures.

2.4 Personnel qualification

The work steps described in the present documentation require basic skills in mechanical, electrical and hydraulic knowledge, as well as knowledge of the associated technical terms. In order to ensure safety at work, these jobs must be exclusively carried out by qualified technical personnel or by trained staff under the direction and supervision of qualified personnel.

For transporting and handling of the product, additional knowledge is necessary with regard to working with a lifting device and the corresponding attachment equipment. In order to ensure safe use, these activities may therefore only be carried out by appropriate qualified personnel or a trained person under the direction and supervision of qualified personnel.

Qualified personnel are in a position to recognize possible hazards and institute appropriate safety measures thanks to their professional training, knowledge and experience, as well as their understanding of the relevant conditions pertaining to the work to be done. Qualified personnel must observe the subject-specific rule and have the necessary hydraulic knowledge.

Hydraulic knowledge means, for instance:

- reading and fully understanding hydraulic diagram,
- fully understanding in particular the interrelationships regarding safety devices and having knowledge on the function and assembly of hydraulic components.



Bosch Rexroth offers training support for special fields. For more information about training, please contact your Bosch Rexroth representative.

2.5 General safety instructions

- Observe the regulations for accident prevention and environmental protection.
- Comply with the local safety provisions and regulations of the country in which the product is used.
- Make sure to use Rexroth products in perfect working order.
- Strictly observe all instructions on the product.
- Persons, who assemble, operate, disassemble or maintain Rexroth products must not consume any alcohol, drugs or pharmaceuticals that may affect their ability to respond.
- Use exclusively accessories and spare parts explicitly approved by the manufacturer (genuine Bosch Rexroth spare parts) to avoid accidents due to improper accessories and spare parts.
- Strictly observe the technical data and ambient conditions specified in the product documentation.
- Inadequate products installed or used for safety-relevant applications may produce unintended operating behavior and result in product or property

damage. For this reason, use a product in safety-relevant applications only on condition that such use is specified and allowed in the corresponding product documentation.

- Prior to commissioning the product, make sure that the end product (e. g. a machine or line), into which Rexroth products are integrated, perfectly complies with the country-specific provisions, safety regulations and standards applicable to its use.

2.6 Product and technology-related safety messages

The safety instructions below is valid from chapter 6: *Transport and storage* to chapter 15: *Technical data*.

DANGER

Danger from excessively high pressure

Danger to life or risk of injury, damage to equipment.

Operating the motor above the permissible maximum pressure can cause components to burst and hydraulic fluid to escape under high pressure.

- ▶ Operate the motor only within permissible maximum pressure.

Danger from suspended loads

Danger to life or risk of injury, damage to equipment.

Improper transportation may cause the Häggglunds motors to fall down leading to injuries e.g. crushed or broken bones or damage to the product.

- ▶ Make certain that the forklift truck or lifting device has adequate lifting capacity.
- ▶ Never stand under or put you hands under suspended loads.
- ▶ Ensure your position is stable during transportation.
- ▶ Use Personal Protective Equipment, PPE (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ Use suitable lifting device for transport and storage, installation and for removal and repair. Make sure the motor is well mounted or anchored when the lifting device is disconnected.
- ▶ Observe the prescribed position of the lifting strap.
- ▶ Observe the local Federal laws and regulations on work and health protection and transportation.

Pressurized machine/system

Danger to life or risk of injury, serious injuries when working on energized machines/systems. Damage to equipment.

- ▶ Protect the complete system against being energized.
- ▶ Make sure that the machine/system is depressurized. Please follow the machine/ system manufacturer's instructions.
- ▶ Do not disconnect any line connections, ports and components when the machine/system is pressurized.
- ▶ Switch off all power-transmitting components and connections (electric, pneumatic, hydraulic, mechanical) in accordance with the manufacturer's instruction and secure them against being switched back on.

WARNING

Escaping oil mist

Risk of explosion, fire, health hazard, environmental pollution.

- ▶ Depressurize the machine/system and repair the leak.
- ▶ Keep open flames and ignition sources away from the Häggglunds motors.
- ▶ If Häggglunds motors are to be situated in the vicinity of ignition sources or powerful thermal radiators, a shield must be erected to ensure that any escaped hydraulic fluid can not ignite, and to protect hose lines from premature aging.

CAUTION

High noise development in operation

Danger of hearing damage and hearing loss.

- ▶ The noise emission of Häggglunds motors depends on speed, operating pressure and installation conditions.
- ▶ Always wear hearing protection when in the vicinity of the operating Häggglunds motor.

Hot surfaces on the Häggglunds motor

Risk of burns.

- ▶ Allow the Häggglunds motors to cool down sufficiently before touching it.
- ▶ Wear heat-resistant protective clothing, e.g. gloves.

Improper routing of cables and lines

Tripping hazard and damage to equipment.

- ▶ Lay cables and lines so that they can not be damaged and nobody can trip over them.

Contact with hydraulic fluid

Hazard to health e.g. eye injuries, skin damage, toxication during inhalation.

- ▶ Avoid contact with hydraulic fluids.
- ▶ When working with hydraulic fluids, strictly observe the safety instructions provided by the lubricant manufacturer.
- ▶ Use your personal protective equipment (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ If hydraulic fluid inadvertently comes into contact with your eyes or bloodstream or is swallowed, consult a doctor immediately.

Escaping hydraulic fluid due to machine/system leakage

Risk of burns and risk of injury due to escaping oil jet.

- ▶ Depressurize and de-energize the machine/system and repair the leak.
- ▶ Never attempt to block or seal the leak or oil jet with a cloth.

2.7 Personal protective equipment (PPE)

PPE is the responsibility of the user of the Häggglunds motors. Observe the safety regulations and provisions of your country. All components of the PPE must be intact.

3 General notes regarding property damages and product damages

NOTICE

Danger from improper handling

Product can be damaged.

- ▶ Do not expose the product to an impermissible mechanical load.
- ▶ Never use the product as a handle or step.
- ▶ Do not place/lay any objects on the product.
- ▶ Do not strike the Hägglunds motor or any part of it or its accessories.
- ▶ Do not set/place the Hägglunds motor on the drive shaft or fittings.
- ▶ Do not strike fittings (e.g. sensors or valves).
- ▶ Do not strike sealing surfaces (e.g. service line ports).
- ▶ Leave the protective covers on the Hägglunds motor until shortly before the lines are connected.
- ▶ Make sure that the electronics are not electro-statically charged (e.g. for painting operations).

Damage to equipment due to improper lubrication

Product can be damaged or destroyed.

- ▶ Never operate the Hägglunds motor with insufficient hydraulic fluid.
- ▶ When commissioning a machine/system, make sure that the case interior and the main lines of the Hägglunds motor are filled with hydraulic fluid and remain filled during operation.
- ▶ With above-reservoir installation, the case interior may drain via the drain line after longer standstill periods (air enters via the shaft seal).

Mixing of hydraulic fluids

Product can be damaged.

- ▶ Before installation, remove all fluids from the Hägglunds motor to prevent mixing with the hydraulic fluid used in the machine/system.
- ▶ Any mixing of hydraulic fluids of different manufacturers or different types of the same manufacturer is not permissible in general.

Damage from electro-welding

Product can be damaged.

- ▶ Do not perform electro-welding on the Hägglunds motor.
- ▶ Do not perform any electro-welding on the driven machine without disconnecting the pivoted attachment from ground.
- ▶ Do not perform any electro-welding at all on the driven machine with a flange mounted motor without providing some special grounding to avoid any current going through the hydraulic motor.
- ▶ Remove any sensitive electronic equipment before performing any electro-welding on the machine.

NOTICE

Contamination of the hydraulic fluid

The cleanliness of the hydraulic fluid has a considerable impact on the cleanliness and service life of the hydraulic system. Contamination of the hydraulic fluid could cause premature wear and malfunctions.

- ▶ Make sure that the working environment at the installation site is fully free of dust and foreign substances in order to prevent contaminants, such as welding beads or metal cuttings, from getting into the hydraulic lines and causing product wear or malfunctions. The Häggglunds motor must be installed in a clean condition.
- ▶ Use only clean connections, hydraulic lines and attachments (e.g. measuring equipment).
- ▶ No contaminants may enter the connections when they are plugged.
- ▶ Before commissioning, make sure that all hydraulic connections are tight and that all of the connection seals and plugs are installed correctly to ensure that they are leakproof and fluids and contaminants are prevented from penetrating the product.
- ▶ Use a suitable filter system to filter hydraulic fluid during filling to minimize solid impurities and water in the hydraulic system.

Improper cleaning

Product can be damaged.

- ▶ Plug all openings with the appropriate protective equipment in order to prevent detergents from entering the hydraulic system.
- ▶ Never use solvents or aggressive detergents. Use only water and, if necessary, a mild detergent to clean the Häggglunds motor.
- ▶ Do not point the power washer at sensitive components, e.g. shaft seal, electrical connections and components.
- ▶ Use lint-free cloths for cleaning.

Environmental pollution due to incorrect disposal

Careless disposal of the Häggglunds motor and its fittings, the hydraulic fluid and the packaging material could lead to pollution of the environment.

- ▶ Dispose of the Häggglunds motor, hydraulic fluid and packaging in accordance with the national regulations in your country.
- ▶ Dispose of the hydraulic fluid in accordance with the applicable safety data sheet for the hydraulic fluid.

Escaping or spilling hydraulic fluid

Environmental pollution and contamination of the ground water.

- ▶ Always place a drip tray under the Häggglunds motor when filling and draining the hydraulic fluid.
- ▶ Use an oil binding agent if hydraulic fluid is spilled.
- ▶ Observe the information in the safety data sheet for the hydraulic fluid and the specifications provided by the system manufacturer.

The warranty applies only to the delivered configuration.

The entitlement to warranty cover will be rendered void if the product is incorrectly installed, commissioned or operated, or if it is used or handled improperly.

4 Scope of delivery

Included in the delivery contents is Hägglunds CBp as per order confirmation.

5 About this product

5.1 Performance description

The Hägglunds CBp is a radial piston hydraulic motor that converts hydraulic flow into mechanical rotation. Refer to product-specific data sheet and the order confirmation for technical data, operating conditions and operating limits of the specific CBp motor.

5.2 Product description

The Hägglunds CBp is a radial piston hydraulic motor with a rotating cylinder block shaft and a stationary housing. The cylinder block is mounted in fixed roller bearings in the housing. An even number of pistons are radially located in bores inside the cylinder block, and two distributors directs the incoming and outgoing oil to and from the working pistons. Each piston is working against a cam roller. When the hydraulic pressure is acting on the pistons, the cam rollers are pushed against the slope on the cam ring that is rigidly connected to the housing, thereby producing a torque. The cam rollers transfer the reaction force to the piston which are guided in the rotating cylinder block. Rotation therefore occurs, and the torque available is proportional to the pressure in the system.

Oil main lines are connected to ports in the connection block and drain lines to ports in the motor housing. The motor is connected to the shaft of the driven machine through the cylinder block. The torque is transmitted by splines.

1. Cam ring
2. Cam roller
3. Piston
4. Cylinder block with splines
5. Flange
6. Cylindrical roller bearing
For CBp 140 Combined axial and radial bearing
7. Connection housing
8. Distributor
9. Wear ring




Fig. 1: The CBp radial piston motor

5.3 Product identification




Fig. 2: Plate on motor

6 Transport and storage

6.1 Product transport

6.1.1 Lifting methods

! **DANGER**

Danger while transporting or lifting Hägglunds motors due to heavy weight
 Danger to life, risk of injury or serious injuries and risk of damage to equipment.

- ▶ Make sure that lifting device is correctly installed.
- ▶ Do not stand under suspended load.
- ▶ Always make sure where the centre of gravity is before any lifting.

Danger if using wrong lifting equipment
 Danger to life, risk of injury or serious injuries and risk of damage to equipment.

- ▶ Make sure the correct lifting equipment is used.




Fig. 3: Center of gravity

Table 4: Center of gravity

Motor type	Mounting type	Measure A	
		mm	in
CBp 140	F	269.21	10.60
	C	5.99	0.24
CBp 280	F	405.96	15.98
CBp 400	F	465.77	18.34
	C	20.49	0.80
CBp 560	F	458.35	18.05
	C	23.9	0.94
CBp 840	C	75.13	2.96

6.1.2 Lifting motors and accessories



Fig. 4: Lifting eyes are included in delivery for CBp 280 to CBp 840

Table 5: Tightening torque for lifting eyes

Motor type	Screw dimension	Number of screws	Tightening torque	
			Nm	lbf-ft
CBp 280 to CBp 840	M20	4	380	280



The end cover and the screws must be removed before mounting the lifting eyes.




Fig. 5: Example, lifting of motor with shaft in vertical position




Fig. 6: Example, lifting of motor with shaft in horizontal position




Fig. 7: Example, lifting CBp tandem motors

! WARNING

Shrink disc coupling slipping off shaft adapter and falling down

Danger to life, risk of injury or serious injuries and risk of damage to equipment.

- ▶ Remove the shrink disc coupling before lifting the shaft adapter in a vertical position.




Fig. 8: Example, lifting of single ended torque arm




Fig. 9: Example, lifting coupling adapter




Fig. 10: Example, lifting of motor mounted to single/double ended torque arm

6.2 Product storage

The motor is delivered with internal protection in the form of an oil film with vapor state corrosion inhibitors, and external protection in form of a VCI plastic bag. This provides sufficient protection for indoor storage in normal temperatures for about 12 months.

6.2.1 Standing the motor on a flat surface

! DANGER

Unsecured motor can fall

Danger to life or risk of injury, damage to equipment.

- ▶ When in storage or during oil filling, the motor must always be secured from falling.

NOTICE

Incorrect placement of the motor

Risk of damage to equipment.

- ▶ When in storage with shaft vertical, the motor must always be placed with the motor shaft facing down.
- ▶ It is also advisable to provide supports at the mounting surface of the motor, see Fig. 11.

When the motor is placed on a flat surface such as a floor, it must stand either on its outer diameter or on the suitably protected end face of the hollow shaft. It is also advisable to provide supports shown in Fig. 11.




Fig. 11: Example, CBp motor standing on a flat surface

6.2.2 Storing for extended periods or in uncontrolled environment

<h2 style="margin: 0;">NOTICE</h2>
<p>Insufficient cleanliness Risk of damage to equipment. ► Take extreme care to ensure that no contamination enters the motor.</p>

If the motor is stored for more than 3 months in uncontrolled environment or more than 12 months in controlled environment, it must be totally filled with oil according to below:

1. Place the motor as shown in Fig. 11, B) Standing with shaft vertical.
2. Fill the motor full with filtered oil containing a mixture of 2% Shell VSI 8235, or similar compatible corrosion inhibitor in the selected fluid in the following order: D1, A1 and C1.
NOTE! See Table 6 for oil volume.
3. Fit the plug to D1.
4. Seal connections A1 and C1 with the cover plates fitted to the connection surface at delivery. Check that the O-rings or rubber seals are in position in the cover plates.
5. Position the motor as shown in Fig. 11, A) Standing with shaft horizontal or alt. B) Standing with shaft vertical.
6. The motor must be turned a few revolutions once a year to prevent internal corrosion in the motor.




Fig. 12: Filling the motor with oil

Table 6: Motor case oil volume

Motor size	Motor case oil volume including channels	
	Litre	US gallon
CBp 140	5.2	1.37
CBp 280	29.0	7.6
CBp 400	35.0	9.2
CBp 560	35.0	9.2
CBp 840	41.0	10.8

6.2.3 Storing during maintenance

If the motor has been in operation and the oil in the hydraulic system fulfills the requirements in [data sheet RE 15414](#), regarding water content, the drained motor can be stored for one month without additional rust protection.

The oil connections of the motor must be properly plugged/covered during the whole storage period to avoid any contamination or humidity/water to enter the motor.

If the storage time is longer than one month, follow the instructions in 6.2.2, or if the motor is kept on the shaft, the power unit must be started and the motor rotated once a month.

7 Installation

7.1 Unpacking

CAUTION

Danger from parts falling out

If the packaging is not opened correctly, parts may fall out and damage the parts or even cause injuries.

- ▶ Place the packaging on a flat and solid surface.
- ▶ Only open the packaging from the top.
- ▶ Remove the packaging from the Häggglunds motor.
- ▶ Check the Häggglunds motor for transport damage and completeness, see chapter 4: *Scope of delivery*.
- ▶ Dispose of the packaging according to the environmental regulations of your country.

7.2 Installation conditions

7.2.1 Spline shaft end

The splines shall be lubricated with hydraulic oil, see 7.4.5, or filled with transmission oil from any connected gearbox or similar according to *Fig. 42*.

To avoid wear in the splines, the installation must be within the recommendations and specified tolerances according to data sheet [RE 15301](#).

7.2.2 Plain shaft end

Recommended design of driven shaft end on normally loaded shaft

In drives with only one direction of rotation and/or load where the stresses in the shaft are moderate, the shaft can be plain. For further information see data sheet [RE 15301](#).

Recommended design of driven shaft end on heavily loaded shaft

Where the driven shaft is heavily loaded and is subject to high stresses, for example for changes in the direction of rotation and/or load, it is recommended that the plain driven shaft should have a stress relieving groove. For further information see data sheet [RE 15301](#).

Thread for assembly tool

To make it easier to mount the motor on the driven shaft end or to remove the motor from the shaft it is recommended that a hole should be drilled and tapped in the centre of the shaft for a mounting tool. For further information see data sheet [RE 15301](#).

7.3 Required tools

7.3.1 Assembly tool for coupling adapter CBp 280 to CBp 840

An assembly tool can be used for easier and faster mounting of the coupling adapter to the driven shaft. The assembly tool is passed through the coupling adapter and screwed into the pre made thread in the driven shaft. The coupling adapter is pulled onto the shaft by turning the nut on the assembly tool.

Material ID Assembly tool for coupling adapter:

Material ID R939064002




Fig. 13: Mounting coupling adapter with assembly tool for CBp 280 to CBp 840

Included in coupling adapter

- 1. Lifting eye
- 2. Adapter shaft
- 3. Shrink disc

Included in assembly tool:

- 4. Dismantling tool
- 5. Nut
- 6. Washer
- 7. Screw
- 8. Carriage beam
- 9. Adapter M20 to M16

7.3.2 Assembly tool for CBp motor

For easier and faster mounting of the motor on the coupling adapter or driven shaft, a special assembly tool can be used. The assembly tool is passed through the motor and screwed into a pre made thread in the coupling adapter or driven shaft. The motor is pulled onto the shaft by turning the nut on the assembly tool.

Material ID Assembly tool for CBp motor:

Material ID R939003803




Fig. 14: Mounting CBp motor with assembly tool

7.4 Product installation

Before the installation, drain all fluids from the motor.

DANGER

Danger from suspended loads

Danger to life or risk of injury, damage to equipment! Improper transportation may cause the Häggglunds motors to fall down leading to injuries e.g. crushing or broken bones or damage to the product.

- ▶ Make certain that the forklift truck or lifting device has adequate lifting capacity.
- ▶ Never stand under or put your hands under suspended loads.
- ▶ Ensure your position is stable during transportation.
- ▶ Use PPE (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ Use suitable lifting device for transport and storage, installation and for removal and repair. Make sure the motor is well mounted or anchored when the lifting device is disconnected.
- ▶ Observe the prescribed position of the lifting strap.
- ▶ Observe the local federal laws and regulations on work and health protection and transportation.

CAUTION

Risk for pressurized hydraulic fluid in the motor due to temperature variations

Risk of health hazard, environmental pollution.

- ▶ Be careful when opening plugs.
- ▶ Use PPE (e.g. safety glasses, safety gloves).

Contact with hydraulic fluid

Hazard to health/health impairment e.g. eye injuries, skin damage, toxication during inhalation!

- ▶ Avoid contact with hydraulic fluids.
- ▶ When working with hydraulic fluids, strictly observe the safety instructions provided by the lubricant manufacturer.
- ▶ Use PPE (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ If hydraulic fluid should, inadvertently comes into contact with your eyes or bloodstream or is swallowed, consult the medical care immediately.

NOTICE

Escaping or spilling hydraulic fluid

Environmental pollution and contamination of the ground water!

- ▶ Always place a drip tray under the Häggglunds motor when filling and draining the hydraulic fluid.
- ▶ Use an oil binding agent if hydraulic fluid is spilled.
- ▶ Observe the information in the safety data sheet for the hydraulic fluid and the specifications provided by the system manufacturer.

7.4.1 Fitting the torque arm on the motor

NOTICE

Unauthorized modification of component

Risk of damage to equipment.

- ▶ Do not weld, drill, grind or carry out any similar work on the torque arm without Bosch Rexroth approval.

General information for TC A, DTCA and DTCB

The torque arm shall be fitted to the motor before the motor is mounted on the driven shaft. See also data sheet [RE 15355](#).

1. Clean the mating surfaces on the torque arm and motor.
2. Oil the screws (1).
3. Make sure that the foundation can withstand the forces from the torque arm (see *Fig. 21*, *Fig. 30*, *Table 9* and *Table 12*).
4. The motor must be turned until the drain outlets are positioned according to 7.4.6.
5. Mount the torque arm on the motor with the screws and washers.
6. Tighten the screws (1) to the torque stated in *Table 7*.




Fig. 15: Example, mounting single ended torque arm TC A 0400 for CBp 400 F




Fig. 16: Example, mounting double ended torque arm DTCB_1120 for CBp 840

Table 7: Screw dimensions

Torque arm	Motor type	Screw dimension	Number of screws	Tightening torque	
				Nm	lb-ft
TC A 0210 DTCA_0140	CBp 140	M20x70-10.9	21	540	400
TC A 0400, DTCB_0400	CBp 280, CBp 400 F	M20x180/300 10.9	34	540	400
TC A 0840 DTCB_1120	CBp 400 C, CBp 560 F/C, CBp 840	M24x80 10.9	41	900	660



Use calibrated torque wrench and oiled screws.

7.4.2 Single ended torque arm installation

The single ended torque arm is fitted to the motor before the motor is mounted on the driven shaft. See 7.4.1 , Fig. 15.




Fig. 17: Single ended torque arm mounting for spline shaft




Fig. 18: Single ended torque arm mounting for plain shaft




Fig. 19: Single ended torque arm TC A

Table 8: Dimensions torque arm TCA


Torque arm	Motor type	B		C		Weight ¹⁾	
		mm	in	mm	in	kg	lb
TC A 0210	CBp 140	800	31.50	430	17.20	91	200
TC A 0400	CBp 280, CBp 400 F	1250	49.21	545	21.46	162	357
TC A 0840	CBp 400 C, CBp 560, CBp 840	1 500	59.06	545	21.46	223	492

¹⁾ Single ended torque arm with articulated connection.

Mounting of articulated connection for TC A**! DANGER****Articulated connection rotates with the motor**

Risk to life and risk of injury or serious injuries and risk of damage to equipment.

- ▶ Make sure the foundation and the customer machine can withstand the forces from the torque arm. See *Fig. 21*, *Fig. 30*, *Table 9* and *Table 12*.
- ▶ Do not stand in the danger zone.

**! WARNING****Heating of material (welding)**

Risk of fire, health hazard, damage to equipment, environmental pollution.

- ▶ Only perform welding work when the machine/system is depressurized.
- ▶ The product is painted with thermosetting plastic paint containing an isocyanate component. When a thermosetting plastic paint is heated to over 150-175°C, gases are emitted that can cause serious health risk. If hot work (e.g. welding) is done on the product, protective breathing equipment must be used.
- ▶ **Never** use motor as grounding point.

Articulated connection in general

- ▶ $x \leq \pm 2 \text{ mm}$ (0,079 inch) misalignment in installation.
 $x \leq \pm 15 \text{ mm}$ (0,59 inch) movement when in use.
- ▶ The articulated connection and the spherical plain bearing (1) must be dismantled during welding. See Fig. 22.
- ▶ Steel: EN 10025-3 – S355N (1.0545), shall be protected against corrosion after welding (2).




Fig. 20: Installation of articulated connection for TC A




Fig. 21: External forces Fr, Fb for TC A

Table 9: External forces single ended torque arm valid for a pressure difference of 420 bar [6000 psi] static

Torque arm	Motor	Force Fb		Force Fr ¹⁾	
		N	lb	N	lb
TC A 0210	CBP 140 140 F/C	73 500	16 523	68 977	15 506.65
TC A 0400	CBP 400 400 F	134 400	30 214.32	122 883	27 625.20
	CBP 280 280 F	94 080	21 150.03	77 462	17 414.15
TC A 0840	CBP 400 400 C	112 000	25 178.62	92 439	20 781.13
	CBP 560 560 F/ C	156 800	35 250.04	136 071	30 589.98
	CBP 840 840 C	235 200	52 875.06	211 724	47 597.45

1) Fr=Fb-weight of motor and torque arm.

For the other torque dircetion Fr= Fb+weight of motor

Standard and electrical isolated articulated connection

1. The bearing (5)/(6) shall be mounted by using a mounting sleeve or tube applied on the bearing outer ring.
2. The bearing shall be mounted with the slot in the outer ring perpendicular towards the load direction. See Fig. 22 (also valid for Fig. 23).
3. Lock the bearings with the circlips (4)/(5).
4. Assemble the rest of the components according to Fig. 22 and Fig. 23.




Fig. 22: Standard articulated connection for TC A




Fig. 23: Electrical isolated articulated connection TC A 0400 and TC A 0840

TC A 0210			TC A 0400 and TCA 0840		
Pos	Description	Pcs	Pos	Description	Pcs
1	Linkage part	1	1	Linkage part	1
2	Fastening support	1	2	Fastening support	1
3	Bolt	2	3	Bolt	2
4	Circlip	4	4	Supporting disc	12
5	Spherical plain bearing	2	5	Circlip	4
6	Split pin	2	6	Spherical plain bearing	2
			7	Split pin	2
			8	Washer (electrical isolated)	4
			9	Bushing (electrical isolated)	4
			10	Washer (electrical isolated)	4

Heavy duty articulated connection TC A

1. The bearing (6) shall be mounted by using a mounting sleeve or tube applied on the bearing outer ring.
2. The bearing (6) shall be mounted with the slot in the outer ring perpendicular towards the load direction. See Fig. 24.
3. Lock the bearings (6) with the circlips (5).
4. Grease the sleeves (7) and shaft (3) with grease available, preferably graphite grease. Do not grease the threads.
5. Insert the shaft (3) and then the supporting sleeves/disc rings (4) and position the shaft (3) in the bores. Make sure the shaft is centered, see Fig. 24. Install the sleeves (7), and for TC A 0400/0840 washers (10), then wedge lock washers (8) and nuts /screws (9). Tighten the nuts/screws acc. to Fig. 24
6. After initial torque, check the torque after 10 hours, 40 hours and at regular service intervals to ensure proper seating of the sleeves.




Fig. 24: Heavy duty articulated connection for TC A

Pos	Description TC A 0210	Pcs	Pos	TC A 0400 and TC A 0840	Pcs
1	Linkage part	1	1	Linkage part	1
2	Fastening support	1	2	Fastening support	1
3	Shaft	2	3	Shaft	2
4	Supporting sleeve	4	4	Supporting disc	12
5	Circlip	4	5	Circlip	4
6	Spherical plain bearing	2	6	Spherical plain bearing	2
7	Conical sleeve	4	7	Sleeve	4
8	Set of wedge lock washers	4	8	Set of wedge lock washers	4
9	Nut	4	9	Screw 350 Nm, 258 lb-ft	4
			10	Washer	4

7.4.3 Double ended torque arm installation

The double ended torque arm is fitted to the motor before the motor is mounted on to the driven shaft, see 7.4.1 Fig. 16




Fig. 25: Double ended torque arm mounting for spline shaft




Fig. 26: Double ended torque arm mounting for plain shaft




Fig. 27: Double ended torque arm DTCA_ and DTCB_

Table 10: Dimensions torque arm DTCA_ and DTCB_

Torque arm	B		C		Weight ¹⁾	
	mm	in	mm	in	kg	lb
DTCA_ 0140	1165	45.87	780	30.71	155	341
DTCB_ 0400	2120	83.46	900	35.43	500	1102
DTCB_ 1120	3000	118.11	900	35.43	500	1102

1) Double ended torque arm with articulated connection and hydraulic cylinder

Mounting of hydraulic cylinder and articulated connection for DTCA_ and DTCB_




Fig. 28: Installation of articulated connection and hydraulic cylinder for DTCA_ and DTCB_

- ▶ $x \leq \pm 2$ mm (0,079 inch) misalignment in installation.
 $x \leq \pm 15$ mm (0,59 inch) movement when in use.
- ▶ Hole pattern and dimensions for ground attachment see Fig. 29 and Table 11.




Fig. 29: Hole pattern for articulated connection and hydraulic cylinder for DTCA_ and DTCB_

Table 11: Hole pattern and dimensions for articulated connection and hydraulic cylinder for DTCA_ and DTCB_

Torque arm	A		B		C		D		E	
	mm	in	mm	in	mm	in	mm	in	mm	in
DTCA_ 0140	129	5.08	85	3.35	152	5.98	196	7.72	25	0.98
DTCB_ 0400 and DTCB_ 0840	138	5.43	95	3.74	152	5.98	196	7.72	25	0.98




Fig. 30: External forces Fr, Fa, Fb for DTCA_ and DTCB_

Table 12: External forces double ended torque arm valid for a pressure difference of 420 bar [6000 psi] static

Torque arm	Motor	Force Fa, Fb on foundation		Force Fr on driven shaft ¹⁾	
		N	lb	N	lb
DTCA_0140 03	CBP 140 140 F/C	46 727	10 504.65	3 531	793.80
DTCB_0400 05	CBP 280 240 F, CBP 400 240 F	46 386	10 427.99	4 794	1 077.73
DTCB_0400 06	CBP 400 320 F	61 836	13 901.29	7 145	1 606.26
DTCB_0400 07	CBP 400 360 F	76 341	17 162.14	-7 341	-1 650.32
DTCB_1120 06	CBP 560 480 F/C	61 836	13 901.29	17 008	3 823.55
DTCB_1120 09	CBP 560 560 F/C	77 327	17 383.80	6 546	1 471.60
DTCB_1120 08	CBP 840 600 C	91 450	20 558.78	-8 202	-1 843.88
DTCB_1120 10	CBP 840 760 C	103 823	23 340.34	8 090	1 818.70
DTCB_1120 11	CBP 840 840 C	163 226	36 694.66	67 033	15 069.62
DTCB_1120 05	CBP 400 360 C	46 727	10 504.65	22 224	4 996.15

1) The force Fr is calculated included the weight of splines motor and torque arm.

1. Mount the articulated connection on the left side of the torque arm (viewed from the connection side of the motor, see Fig. 31), use the pins (2) and lock them in place with circlips (3).
2. Mount the hydraulic cylinder with the piston rod facing upwards on the right side of the torque arm (viewed from the connection side of the motor), use the pins (2) and lock them in place with circlips (3).
3. Attachment brackets (6) for torque arm should be fastened with screws (7).
4. Check and adjust the distance C for the cylinder according to Table 10 (Note! depending on application this distance can be different). Shim between the torque arm attachment brackets and the foundation or if possible, adjust the mounting plate of the foundation to reach the required distance.




Fig. 31: Example articulated connection and hydraulic cylinder for DTCB_0400

Pos	Description	Pcs
1	Articulated connection	1
2	Pins	4
3	Circlips	4
4	Hydraulic cylinder	1
5	Air bleeding G 1/4" (opposite side of connections)	2
6	Attachment brackets	4
7	Screw M24-8.8 Tightening torque 665 Nm (490 lb·ft)	8*

*Not included in delivery

Hydraulic connection between motor and hydraulic cylinder

This is valid with the hydraulic cylinder on the right hand-side of the the motor.
See Fig. 32.

1. Mount the hoses to connection T1 (CBp 140) / T4A (CBp 280 to CBp 840) to the hydraulic cylinder connection (A) and the hose from connection T2(CBp 140) / T4C (CBp 280 to CBp 840) to the cylinder connection (B). See Fig. 45 and Fig. 46.




Fig. 32: Example hydraulic connections DTCB_ 0400

Table 13: Hydraulic connections DTCA_ and DTCB_

Connection	Description	Dimensions	Remarks
T1 (CBp 140)	Pressure connection	G ¼"	To be connected to A on cylinder
T4A (CBp 280 to CBp 840)	Pressure connection	G ½"	To be connected to A on cylinder
T2 (CBp 140)	Pressure connection	G ¼"	To be connected to B on cylinder
T4C (CBp 280 to CBp 840)	Pressure connection	G ½"	To be connected to B on cylinder
A	Pressure connection	G ½"	
B	Pressure connection	G ½"	
C	Air ventilation	G ½"	Air filter

NOTICE

Overload of driven shaft

Damage of equipment.

- Make sure to follow the installation instructions regarding hydraulic connections.



The cylinders should be vented from air during commisioning by using the air bleeding screws on the cylinder, see Fig. 31.

7.4.4 Mounting of coupling adapter

NOTICE

Slipping shaft

Damage of adapter shaft or customer shaft.

- ▶ Grease must under no circumstances be transferred to the surfaces between the driven shaft and the hollow shaft (see *Fig. 34*).
- ▶ Clean hands free from grease before start of mounting.

Incorrect tightening of shrink disc

Damage to the hollow shaft.

- ▶ Never tighten the coupling screws before the adapter has been mounted on the driven shaft.

Mounting of shrink disc to adapter shaft

- 1.** The shrink disc arrives from the factory lubricated with grease on the conical surfaces and the screws (see *Fig. 34*). This lubricants shall remain on these surfaces.
- 2.** Clean the outside of the hollow shaft.
- 3.** Remove the spacers between the two clamping rings of the shrink disc.
- 4.** Mount the shrink disc on the hollow shaft. Use an approved sling between the clamping rings (see *Fig. 33* and *Fig. 34*). The coupling must be pushed completely to the stop of the hollow shaft. If necessary separate the clamping ring for easier mounting.
- 5.** Absolutely no grease on the surfaces between driven shaft and hollow shaft. Clean the driven shaft and the inside of the hollow shaft.




Fig. 33: Mounting of shrink disc on adapter shaft




Fig. 34: Shrink disc



*) The conical surface between the coupling ring and the clamping rings as well as the screws shall be coated with Molykote G-Rapid plus paste, (see Fig. 34). This is done from the factory at delivery.

During service it may be necessary to relubricate those surfaces with Molykote G-Rapid plus paste again but only on the specified surfaces.

Mounting the coupling adapter to the driven shaft (CBp 280 to CBp 840)

1. Mount 3 lifting eyes on the coupling adapter for lifting, see Fig. 9 in chapter 6.1.2.
2. Align the coupling adapter with the driven shaft.
3. Pass the assembly tool through the centre of the coupling adapter and screw it into the driven shaft by using the squared key in the end of the tool, see Fig. 35.
4. Pull the coupling adapter on the shaft by turning the nut on the assembly tool to specified clamping length (length B, see Fig. 36 and Fig. 37 and Table 14).
5. Tighten the shrink disc, (see : Tightening of shrink disc page 42).
6. Remove the assembly tool.
7. Remove the lifting device and the lifting eyes from the coupling adapter.




Fig. 35: Mounting the coupling adapter on the driven shaft with the assembly tool.

Assembly tool

- 1 Nut
- 2 Carriage beam




Fig. 36: Driven shaft without stress relieving groove




Fig. 37: Driven shaft with stress relieving groove

Table 14: Clamping length

Motor	Length B	
	mm	in
CBP 280	106	4,17
CBP 400	117	4,61
CBP 560	153	6,02
CBP 840	153	6,02

Tightening of shrink disc

1. Keep tension in the lifting straps to avoid a skewed setting of the coupling adapter during the tightening of the screws. Wobbling caused from a skewed setting will add a load to the main bearing of the motor.
2. In order to avoid misalignment of the two clamping rings during the tightening of the screws, the gap between the rings must be measured in several places during the process, see *Fig. 38*. The difference between the measured gaps must never vary more than 1 mm (0,04") during any stage of the tightening process.
3. Pre-set the coupling screws in opposite pairs (12-6-9-3 o'clock) to max 1/3 of the torque specified for the screws, see *Table 15*. It is very important that the misalignment is kept within the tolerance as described above.
4. Mark the screw head at 12 o'clock with a pen or paint so that you can follow the turning sequence of the screws.
5. Set the torque wrench to max 1/3 of the specified maximum torque for the coupling screws, tighten all bolts in sequence, shown in *Fig. 39*, for 2 or 3 passes. Increase the torque to max 2/3' of maximum torque and tighten the bolts another 2 or 3 of passes.
6. Set the torque wrench for the specified maximum torque of the coupling screws as shown on the sign of the coupling or *Table 15*.
7. Start tightening the screws in sequence shown in *Fig. 39*.
8. Keep on doing this until you have reached the stated torque. Several passes are required before the screws are tightened to specified torque. Keep checking the alignment of the coupling. (15-20 passes may be necessary).
9. When the specified torque is reached it is important that all screws are tightened with specified torque and that no further movement can be observed.




Fig. 38: Gap between the clamping rings




Fig. 39: Tightening order

Table 15: Screws and tightening torque, for standard shrink discs

Motor type	Shrink disc size	Number of screws	Screw dim.	Strength	Tightening		Type of head
					Nm	lb-ft	
CBP 280	∅ 405	12	M20 x 80				
CBP 400	∅ 440	15	M20 x 90	10.9	490	362	Hexagon
CBp 560/CBp 840	∅ 520	20	M20 x 100				

NOTICE

Slipping shaft

Damage of motor or customer shaft.

- ▶ There is a metallic sign on every shrink disc with a tightening torque stamped on it. This torque is always to be used.
- ▶ Tightening torque value is critical. Use calibrated torque wrenches.
- ▶ Uncoated screws shall be greased with Molykote G-Rapid plus paste.

7.4.5 Mounting of spline motor

NOTICE

Spline not lubricated

Damage to motor and driven shaft.

- ▶ The splines shall be filled up with hydraulic oil.

Mounting of spline motor with torque arm to the driven shaft

The motor can be mounted to the driven shaft with or without a mounting tool, but the use of a mounting tool is recommended since it makes the work easier.

This instruction is related to the pictures *Fig. 40, Fig. 41*.

Mount torque arm to the motor as described in chapter 7.4.1.

- 1.** Lubricate the o-ring (5) and make sure it is undamaged. The O-ring is delivered with the motor.
- 2.** Check shaft/splines for burrs, to minimize the risk to damage the o-ring. Lubricate shaft/splines with hydraulic fluid.
- 3.** Remove the end cover (1) together with screws and washers.
- 4.** Remove the plug G1" (2).
- 5.** Mark spline tooth location on the outside of the cylinder block to assist alignment during installation.
- 6.** Align the motor with the driven shaft.
- 7.** Install the assembly tool by passing the tie rod through the centre of the motor, and screw it into the driven shaft by using a wrench at the key grip at the end of the assembly tool. Assemble the washer and then the nut tight to the bearing retainer (3).
- 8.** Rotate the cylinder block/motor to line up the splines with the drive shaft.
- 9.** Pull the motor onto the shaft by turning the nut on the assembly tool.
- 10.** Remove the assembly tool.
- 11.** For CBp 280 to CBp 840 remove the bearing retainer. Mount the spacer included in the mounting kit (4) to the driven shaft. Torque 450 Nm (332 lbf·ft). - Remount the bearing retainer. Torque 136 Nm (100 lbf·ft).
- 12.** Fill up with hydraulic oil to the G1" thread (clearance between the shaft and the bearing retainer). Oil volume, see *Table 16*.
- 13.** Fix the motor to the driven shaft with the M20 screw and an O-ring, included in the mounting kit (4). Torque 385 Nm (284 lbf·ft).
- 14.** Remount the end cover (1). Torque 80 Nm (59 lbf·ft).

Table 16: Oil Volume for lubrication of spline connection, torque arm mounting

Frame size	Horizontal mounted		Vertical mounted	
	Litre	US gallon	Litre	US gallon
CBp 140	1.6	0.42	3.2	0.85
CBp 280	7.0	1.85	14.0	3.70
CBp 400	8.0	2.11	16.0	4.23
CBp 560	8.0	2.11	16.0	4.23
CBp 840	10.0	2.64	20.0	5.28




Fig. 40: Mounting spline motor with assembly tool




Fig. 41: Fix the spline motor with the mounting kit, horizontal mounting

Vertical mounting of motor


DANGER
Vertical mounted motor: Motor/flange falls down

Risk to life and risk of injury or serious injuries and risk of damage to equipment!

- ▶ Make sure that the flange is correctly mounted to the foundation and can withstand the weight and forces from the motor.
- ▶ Make sure the motor is correctly mounted to the flange.
- ▶ Do not stand in the danger zone!
- ▶ The spline area must always be lubricated with hydraulic oil to prevent wear of spline interface.

Wear of spline increase relative movement between driven shaft and motor, which can cause the mounting kit, holding the motor axially, to break.

- ▶ Torque arm mounted motor with spline and mounting kit can be used only for horizontal mounting and/or motor driven shaft pointing downwards unless extra safety arrangements is installed to secure the motor from falling.



Flange mounting of motor

See: *Mounting of spline motor with torque arm to the driven shaft page 44* step 2 to step11.

NOTE!

Mounting kit shall normally not be used for flange mounted motors.

1. Mount the motor to the flange. For screw dimensions and tightening torque, see *Table 7*.
2. Fill up hydraulic oil to the G1" thread. See *Fig. 42*. Oil volume see *Table 17*.
3. Mount the G1" plug (2). Torque 125 Nm (92 lb•ft).
4. Mount the end cover (1). Torque 80 Nm (59 lb•ft).




Fig. 42: Flange mounted motor, shaft horizontal

Table 17: Oil Volume for lubrication of spline connection, flange mounting

Frame size	Horizontal mounted		Vertical mounted	
	Litre	US gallon	Litre	US gallon
CBp 140	4.0	1.06	8.0	2.64
CBp 280	7.0	1.85	14.0	3.70
CBp 400	8.0	2.11	16.0	4.23
CBp 560	8.0	2.11	16.0	4.23
CBp 840	10.0	2.64	20.0	5.28

7.4.6 Draining and venting of the motor

Horizontal mounting

When the motor is installed with the shaft in the horizontal plane, the highest of the drain ports D1 to D4 must always be used see Fig. 43.

Drain line must be connected to the tank with a minimum of restrictions, to ensure that the maximum case pressure is not exceeded.




Fig. 43: Horizontal mounting

Vertical mounting

When the motor is mounted vertically, the highest of drain ports D1 to D4 must be used. Flushing (lubrication) of radial seal from charge pressure (low pressure) is necessary. For CBp 140 install orifice \varnothing 1 mm R939004236.

With bidirectional drives, use the connection with lowest average pressure. (Connecting to high pressure will increase the motor drain flow).

A) Motor shaft pointing upwards (See Fig. 44 or Fig. 45, alt. A) Shaft side upwards).

- The drain line must be connected to one of the drain ports D3 or D4
- The flushing line must be connected to one of the flushing ports:
 - F5 or F6 on CBp 140
 - F1 on CBp 280 to CBp 840

B) Motor shaft pointing downwards (See Fig. 44 or Fig. 45 alt. B) Shaft side downwards).

- The drain line must be connected to one of the drain ports D1 or D2
- The flushing line must be connected to one of the flushing ports:
 - F3 or F4 on CBp 140
 - F2 on CBp 280 to CBp 840




Fig. 44: Vertical mounting CBp 140




Fig. 45: Vertical mounting CBp 280 to CBp 840

7.4.7 Flushing

To avoid high temperature in the motor case the heat must be removed, because high temperature gives lower viscosity and that gives reduction in basic rated life / service life. The motor case must be flushed when the output power exceeds the max. values.

CAUTION

High temperature in motor case

Reduction in basic rated life/service life.

► Max. power without flushing:

CBp 140 and CBp 280	120 kW (160 hp)
CBp 400 to CBp 840	170 kW (227 hp)

For calculation of required flushing, see [data sheet RE 15301](#) or contact your Bosch Rexroth representative. The flushing oil shall be drained in the normal drainline, see chapter 7.4.6.

Connect the input flushing line at the lowest drain port, D1 to D4 at opposite side compared to the drain outlet in order to obtain a cross flushing flow through the motor, see Fig. 43, Fig. 44 and Fig. 45.

7.4.8 Hydraulic connections

When using (thick wall) piping and in applications with frequent reversal of rotation direction, it is recommended to fit flexible hoses between the motor and piping to avoid damage due to vibration and to simplify installation of the motor. The length of the hoses should be kept as short as possible.




Fig. 46: Hydraulic connections CBp 140

Table 18: Hydraulic connections CBp 140

Connection	Description	Dimensions	Remarks
A1, C3	Main connection	1 1/4" *	If A1, C3 is used as the inlet, the motor shaft rotates counterclockwise, viewed from the motor shaft side
C1, A3	Main connection	1 1/4" *	If C1, A3 is used as the inlet, the motor shaft rotates clockwise, viewed from the motor shaft side
A2, A4	Alternative main connection	1 1/4" *	
C2, C4	Alternative main connection	1 1/4" *	
D1	Drain connection	G 3/4"	
D2, D3, D4	Alternative drain connection	G 3/4"	Temperature sensor normally mounted in D2
T	Test connection	G1/4"	Used to measure pressure and/or temperature at the main connections. Minimes M16
D2	Temperature sensor Pt 100	EN 175301-803	
F3, F4, F5, F6	Alternative flushing connections	G1/4"	For flushing of motor housing and radial lip seal

*SAE flange J 518 , code 62, 420 bar (6000 psi).

All connections are normally plugged at delivery.




Fig. 47: Hydraulic connections CBp 280 to CBp 840

Table 19: Hydraulic connections CBp 280 to CBp 840

Connection	Description	Dimensions	Remarks
A1, C3	Main connection	2" *	If A1, C3 is used as the inlet, the motor shaft rotates counterclockwise, viewed from the motor shaft side
C1, A3	Main connection	2" *	If C1, A3 is used as the inlet, the motor shaft rotates clockwise, viewed from the motor shaft side
A2, C4	Alternative main connection	2" *	
C2, A4	Alternative main connection	2" *	
D1	Drain connection	G 1 1/4"	
D2, D3, D4	Alternative drain connection	G 1 1/4"	
T1, T2,	Test connection	G1/4"	Used to measure pressure and/or temperature at the main connections. Minimes M16
T3	Test connection	G1/4"	
F1, F2	Flushing connection	G1/4"	For flushing of radial lip seal
T4	Pressure connection	G1/2"	
T5, T6	Pressure connection	G1/4"	
T7	Temperature sensor Pt 100	EN 175301-803	

*SAE flange J 518 , code 62, 420 bar (6000 psi).
 All connections are normally plugged at delivery.

7.4.9 Direction of rotation of motor shaft

! WARNING

Rotating parts

Risk of injury or serious injuries.

- ▶ Do not touch rotating parts or be in the zone of rotating parts.




Fig. 48: Rotating part, spline motor




Fig. 49: Direction of rotation

With the inlet flow connected to port A1 or C3, the motor shaft rotates in the direction shown by the arrow, anti-clockwise viewed from shaft side of the motor. With the inlet flow connected to C1 or A3 port, the motor shaft rotates clockwise viewed from shaft side of the motor.

8 Commissioning

NOTICE

Dirt particles

A not run-in motor in combination with dirt particles in the oil can badly affect the sliding surfaces in the motor. This is valid during the first 100 hours.

- ▶ The Häggelunds radial piston hydraulic motor must be installed and commissioned in a clean condition.

8.1 Commissioning

Check the following points before commissioning the motor, i.e. before starting the first time:

- Make sure that all fluids have been drained from the motor to prevent accidental mixing with the hydraulic fluid used in the system.
- Check that the motor is installed according to chapter 7.
- Check that all hydraulic couplings and plugs are properly tightened to prevent leakage.
- Select the hydraulic fluid in accordance with the recommendations, See chapter 15.1.1 and Data sheet [RE 15414 Hydraulic fluid quick reference](#).
- Check that the motor is protected from overloads, see chapter *Motor data* in data sheet [RE 15301](#).

8.1.1 Oil filling

1. Fill the motor case with hydraulic fluid via a filter into one of the drain ports D1 to D4 (depending on how the motor is mounted), for oil volumes see *Table 6*.
2. Check the drain line to ensure that excessive pressure does not build up in the motor case; see 7.4.6

8.1.2 Start of the hydraulic supply

1. During initial starting and the period immediately after it, any hydraulic installation must be regularly and carefully checked at frequent intervals.
2. The working pressure and charge pressure must be checked to ensure that they correspond to the contracted values. Check that the charge pressure conforms to the charge pressure curve, see chapter, *Recommended charge pressure* in data sheet [RE 15301](#).
3. The pressure in the drain line measured at the motor must not exceed maximum case pressure according to data in RE 15301. This pressure limit is important for the life of the motor seals.
4. If leakage occurs, correct the fault and carry out new measurements.
5. Check all lines, connections, screws, etc. and correct if necessary.
6. Check other possible leakage points and replace faulty parts.
7. During the start up period, dirt particles in the system are removed by the filters. The filter cartridges have to be changed after the first 100 working hours and after that according to the maintenance chart, *Table 20*. See also Chapter 10.3 (second point) about filter clogged indicators.



It is important that the pressure is limited to 250 bar (3626 psi) when starting up the motor. This is valid for the first 100 hours.

8.2 Re-commissioning after standstill

For re-commissioning, proceed as described in chapter 8.1.

WARNING
Material or product damage

Risk of injury or serious injuries.

- ▶ Before re-commissioning, make sure that the Häggglunds product hasn't been damaged in any way.

In case of accident or malfunction where it is not possible to determine the status of the Häggglunds product, please contact your Bosch Rexroth representative.

9 Operation

The product is a component which requires no settings or changes during operation. For this reason, this chapter of the manual does not contain any information on adjustment options. Use the product only within the performance range provided in the technical data. The machine/system manufacturer is responsible for the proper project-planning of the hydraulic system and its controls.

10 Maintenance and repair

10.1 Cleaning and care

NOTICE

Damage to surface

Aggressive solvents and detergents may damage the seals on the hydraulic motor and cause them to age faster.

- ▶ Never use solvents or aggressive detergents.
- ▶ If in doubt, check the compatibility of the detergent with the seal type (Nitrile or Viton) specified in the hydraulic motor.

Damage to the hydraulic system and the seals

Using a high-pressure cleaner could damage the speed sensor and the seals of the hydraulic motor.

- ▶ Do not point the high-pressure cleaner at sensitive components, e. g. shaft seals, seals in general, electrical connections, speed sensors and valves.

For cleaning and care of the hydraulic motor, observe the following:

- ▶ Plug all openings with suitable protective caps/devices.
- ▶ Check whether all plugs and plug seals are securely seated to ensure that no moisture can penetrate into the hydraulic motor during cleaning.
- ▶ Use only water and, if necessary, a mild detergent to clean the hydraulic motor.
- ▶ Remove coarse dirt from the outside of the motor and keep sensitive and important components, such as sensors and valve blocks clean.

10.2 Inspections

DANGER

Pressurized machine/system

Danger to life or risk of injury, serious injuries when working on energized machines/systems. Damage to equipment.

- ▶ Check and be aware of the pressure you may have on the connection before you connect your equipment.
- ▶ Do not disconnect any line connections, ports and components when the machine/system is pressurized.
- ▶ Be careful when connecting the mini-mess hose because the oil stream can be dangerous and should never point against any person or other sensitive object.

CAUTION

Contact with hydraulic fluid

Hazard to health e.g. eye injuries, skin damage, toxication during inhalation.

- ▶ Avoid contact with hydraulic fluids.
- ▶ When working with hydraulic fluids, strictly observe the safety instructions provided by the lubricant manufacturer.
- ▶ Use your personal protective equipment (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ If hydraulic fluid inadvertently comes into contact with your eyes or bloodstream or is swallowed, consult a doctor immediately.

10.2.1 Oil inspection

Purpose of taking oil sample

The purpose of oil sampling is to check the condition of the hydraulic fluid. With scheduled oil analysis, wear products can be identified and corrective action can be taken before failure occurs. Oil analysis can indicate when an oil change is required, point out shortcomings in maintenance and keep repair cost to a minimum. Using oil analysis can create a “window of opportunity”, allowing the user to schedule overhauls, maintenance or repairs, thus saving money on equipment repairs and unplanned downtime.

The most used method is to take samples in a clean sample bottle and send it to a fluid laboratory for an analysis. The laboratory should deliver a report following a specific international standard.

The analysis should at a minimum cover viscosity, oxidation, water content and particle counting (possibly including element analysis of particles). Another method is to install an inline particle counter direct in your hydraulic system which provides the contamination level according to international standards. The disadvantage with this method is that you only get the contamination level in the oil.

General

The intention is to verify the condition of the oil during operation. The motor should be running at normal operation while the sample is taken.

The cleanliness is extremely important during sampling.

Always use designated oil sample bottles, these can be ordered from any fluid analysis laboratory.

Never try to clean your own bottle if you want a reliable result.

The sample should be taken by using a mini-mess hose connected to a mini-mess coupling.

Always clean the connections carefully before you connect the mini-mess hose to the coupling.

Be careful when connecting the mini-mess hose because the oil stream can be dangerous and should never point against any person or other sensitive object. Check and be aware of the pressure you may have on the connection before you connect.

How to do bottle samples

The sample shall be taken at the mini-mess coupling on the low pressure side of the motor in the main loop. Never take the sample out of the tank.

Clean the coupling and the hose carefully.

Connect the mini-mess hose to the coupling, be careful and aware of the direction of the oil stream.

Let minimum 2 liters (0.53 gallon US) of oil flush into a bucket before you fill the bottle.

Remove the cap of the bottle as late as possible and don't let any contamination be in touch with the cap, bottle or the mini-mess hose when the sample is taken.

To get a reliable result the system must run without moving any valves and the mini-mess hose should not touch the bottle.

Only $\frac{3}{4}$ of the bottle shall be filled because the laboratory has to shake the sample to get a mixed fluid when they analyse it. Minimum 200 ml are needed for a good analysis.

When the bottle is filled close the cap as soon as possible to prevent contamination from the air that might enter the bottle and give you a wrong result.

Inline measure

The sample shall be taken at the mini-mess coupling on the low pressure side of the motor in the main loop system. Clean the coupling and the hose carefully.

Connect the hoses according to the particle counters manual.

To get a true value the contamination readings have to be stable about 10 min before you stop to measure.

10.3 Maintenance plan

When a hydraulic system has been in service for some time, it must undergo periodic maintenance and servicing at intervals which depend on the equipment and the type of duty. This periodic maintenance must include the following operations:

- ▶ Check the hydraulic system for leakage. Tighten screws and fittings, replace faulty seals and keep the drive clean.
- ▶ Inspect tank, pumps, motors and filters (e.g. air-, oil-, magnetic filters etc.), clean or change if necessary. Replace all filter cartridges for which a filter clogged indication has been given.
- ▶ Check the pressures and temperatures in the hydraulic system and carry out routine operations. Adjust valves etc. if necessary.
- ▶ Check the hydraulic fluid; see chapter 10.4.2.
- ▶ Make sure that no dirt or other contaminations enter the system during inspection. Check that the outside of the hydraulic motor in an installation is kept free of dirt, thus leakage and faults will be detected earlier.
- ▶ We recommend that a running log be kept and that planned inspections are carried out at set intervals.
- ▶ Maintenance checks and operations, see *Table 20*.
- ▶ Check torque arm and pivoted attachment.

Table 20: Maintenance chart

In operation	Oil filters	Oil	Torque arm
After the first 100 hours	R	-	I
After 3 months or 500 hours	R	-	-
Once every 2 weeks	-	-	-
Once every 6 months	R	I	I
Once every 12 months	-	-	-

R = Replacement, **I** = Inspection

10.4 Maintenance

10.4.1 Filter maintenance

Filters in the hydraulic system must be changed after the first 100 working hours and the second change is to be carried out after 3 months or 500 working hours whichever is earlier. They must then be changed at regular intervals of 6 months or 4000 working hours.

10.4.2 Oil maintenance

See chapter 15.1.1 and Data sheet [RE 15414 Hydraulic fluid quick reference](#).

NOTE!

All hydraulic fluids are affected differently. Obtain the advice of your oil supplier or by nearest Bosch Rexroth representative.

Analysis

It is recommended that the oil should be analysed every 6 months. The analysis should at a minimum cover viscosity, oxidation, water content and particle counting (possibly including element analysis of particles).

Most oil suppliers are equipped to analyse the state of the oil and to recommend appropriate action. The oil must be replaced immediately if the analysis shows that it is outside the specifications.

Viscosity

Many hydraulic oils display viscosity loss with increasing use, and this means poorer lubrication. The viscosity of the oil in service must never fall below the minimum allowed viscosity for the actual fluid or the recommended viscosity for the motor, see chapter *Hydraulic fluids* in data sheet [RE 15301](#).

Oxidation

Hydraulic oil oxidizes with time of use and temperature. This is indicated by changes in colour and smell, increased acidity or the formation of sludge in the tank. The rate of oxidation increases rapidly at surface temperatures above 60 °C (140 °F), and the oil should then be checked more often.

The oxidation process increases the acidity of the fluid; the acidity is stated in terms of the neutralization number (TAN). Typical oxidation is slow initially and increases rapidly later. A sharp increase (by a factor of 2 and 3) in the TAN between inspections is a signal that the oil has oxidized too much and should be replaced immediately.

Water content

Contamination of the oil by water can be detected by sampling from the bottom of the tank. Most hydraulic oils repel the water, which then collects at the bottom of the tank. This water must be drained off at regular intervals. Certain types of transmission oils and engine oils emulsify the water; this can be detected by coatings on filter cartridges or a change in the colour of the oil. Obtain the advice of your oil supplier in such cases.

Degree of contamination

Heavy contamination of the oil causes increased wear of the components in hydraulic systems. The cause of the contamination must be immediately investigated and remedied.

10.5 Repair

Bosch Rexroth offers a comprehensive range of services for repairs of Häggglunds products.

Repairs on the Häggglunds products may only be performed by service centers certified by Bosch Rexroth.

- ▶ Use exclusively original spare parts from Bosch Rexroth to repair the Häggglunds products, otherwise the functional reliability of the products can not be assured and you lose your entitlement under warranty.

In the event of questions regarding repairs, contact your responsible Bosch Rexroth Service partner or the service department of the manufacturer's plant for the Häggglunds products, see chapter 10.6

10.6 Spare parts

CAUTION

Use of unsuitable spare parts

Spare parts that do not meet the technical requirements specified by Bosch Rexroth may cause personal injury or property damage!

- ▶ Use exclusively original spare parts from Bosch Rexroth to repair the Häggglunds product, otherwise the functional reliability of the Häggglunds product can not be assured and you lose your entitlement under warranty....

Address all questions regarding spare parts to your responsible Bosch Rexroth Service partner or the service department of the manufacturer's plant for the Häggglunds products. Details of the manufacturer's plant can be found on the product identification plate of the Häggglunds product.

11 Removal and replacement

11.1 Required tools

In addition to standard tools the following are also needed, for example:

- ▶ Lifting tool/device
- ▶ Assembly tool
- ▶ Lifting eyes
- ▶ Waste oil collector

11.2 Preparing for removal

1. Decommission the entire system as described in the instruction manual for the machine or system. Relieve pressure in the hydraulic system according to the instructions of the machine or system manufacturer. Make sure that the relevant system components are not under pressure or voltage.
2. Protect the complete system against being energized.
3. Remove the hoses, cables and pipelines from the motor.

11.3 Removing motor

DANGER

Danger from suspended loads

Danger to life or risk of injury, damage to equipment! Improper transportation may cause the Häggglunds motors to fall down leading to injuries e.g. crushing or broken bones or damage to the product.

- ▶ Make certain that the forklift truck or lifting device has adequate lifting capacity.
- ▶ Never stand under or put your hands under suspended loads.
- ▶ Ensure your position is stable during transportation.
- ▶ Use PPE (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ Use suitable lifting device for transport and storage, installation and for removal and repair. Make sure the motor is well mounted or anchored when the lifting device is disconnected.
- ▶ Observe the prescribed position of the lifting strap.
- ▶ Observe the local federal laws and regulations on work and health protection and transportation.

CAUTION

Contact with hydraulic fluid

Hazard to health/health impairment e.g. eye injuries, skin damage, toxication during inhalation!

- ▶ Avoid contact with hydraulic fluids.
- ▶ When working with hydraulic fluids, strictly observe the safety instructions provided by the lubricant manufacturer.
- ▶ Use PPE (e.g. safety glasses, safety gloves, suitable working clothes, safety shoes).
- ▶ If hydraulic fluid should, inadvertently comes into contact with your eyes or bloodstream or is swallowed, consult the medical care immediately.

NOTICE

Escaping or spilling hydraulic fluid

Environmental pollution and contamination of the ground water!

- ▶ Always place a drip tray under the Häggglunds motor when filling and draining the hydraulic fluid.
- ▶ Use an oil binding agent if hydraulic fluid is spilled.
- ▶ Observe the information in the safety data sheet for the hydraulic fluid and the specifications provided by the system manufacturer.

Removing the CBp motor

1. Secure the motor to a lifting device, see chapter 6.1.
2. Place the waste oil collector below the motor.
3. Remove the end cover (1) together with screws and washers.
4. Dismount the mounting kit (4) or the plug G1" (2).
5. Remove the bearing retainer (3). The oil will drain out.
6. Dismount the spacer (torque armed mounted CBp 280 to CBp 840).
7. Install the assembly tool with the nut according to Fig. 50. Screw it into the driven shaft by using a wrench at the key grip at the end of the assembly tool.
8. Remount the bearing retainer (3).
9. If the motor is flange mounted, unscrew the motor from the flange. If the motor is torque arm mounted, dismount the articulated connection.
10. Pull the motor off the shaft by turning the nut on the assembly tool.




Fig. 50: Removing the CBp motor

Removing the coupling adapter for CBp 280 to CBp 840

1. Mount the lifting eyes and secure the coupling adapter to a lifting device, see chapter 6.1 Fig. 9.
2. Mount the carriage beam to the customer shaft through the center hole of the coupling adapter.
3. Tighten the nut on the carriage beam against the coupling-adapter by hand.
4. Fasten the dismantling tool against the end of the coupling adapter by using the two screws supplied with the coupling adapter.
5. Loosen the screws on the shrink disc gradually, appr. a quarter turn each. Keep doing this until all screws are loosened.
6. Remove the coupling adapter from the customer shaft by turning the nut on the mounting tool counterclockwise.




Fig. 51: Assembly tool for removing the coupling adapter

Included in coupling adapter

1. Lifting eye

Assembly tool coupling adapter

2. Dismounting tool
3. Nut
4. Washer
5. Screw
6. Carriage beam
7. Adapter M20 to M16

11.4 Preparing the components for storage or further use

Proceed as described in chapter 6.2.

12 Disposal

12.1 Environmental protection

Careless disposal of the CBp motor, the hydraulic fluid and the packaging material could lead to pollution of the environment.

Observe the following points when disposing of the CBp motor:

- 1.** Completely drain the motor from fluid.
- 2.** Dispose of the motor and packaging material in accordance with the national regulations in your country.
- 3.** Dispose of the hydraulic fluid according to the national regulations of your country. Also observe the applicable safety data sheet for the hydraulic fluid.
- 4.** Remove the motor into its individual parts and properly recycle these parts and separate according to, for instance:
 - Cast iron
 - Steel
 - Aluminum
 - Non-ferrous metal
 - Electronic waste
 - Plastic
 - Seals

Dispose material in accordance with the national regulations in your country.

13 Extension and conversion

Do not modify Häggglunds products. Please contact your Bosch Rexroth representative for extension or conversion.

14 Troubleshooting

Please, contact your nearest Bosch Rexroth representative.

Table 21: Troubleshooting hydraulic motor

Fault	Probable cause	Action
The motor does not run.	Mechanical stop in the drive.	Check system pressure. If the pressure has risen to the relief valve setting, remove the load from the drive.
	The motor does not deliver enough torque because the pressure difference across the motor is not enough for the load.	Investigate the pressure level in the system and correct the setting of the pressure limiting valve if necessary.
	Insufficient or no oil being supplied to motor.	Check the hydraulic system. Check the external leakage of the motor (D connection).
Motor rotates in wrong direction.	Oil supply connections to motor incorrectly connected.	Connect the oil supply correctly.
Motor runs rough.	Pressure or flow fluctuations in the hydraulic system.	Find the cause in the system or in the driven unit.
Noise in the motor.	The motor is being operated with too low charge pressure.	Adjust the charge pressure to the correct level. See chapter Recommended charge pressure in data sheet RE 15301 .
	Internal faults in the motor.	Investigate the drain oil, if necessary. Put a magnetic plug in the oil flow and check the material that sticks to the magnet. Steel particles indicate damage. Note that fine material from the castings may be deposited and does not mean internal damage in the motor.
External oil leakage on the motor.	The radial lip seals or other seals is worn or damaged.	Replace the damaged seals.

15 Technical data

15.1 Technical data, Hägglunds CBp

For complete technical data see [RE 15301](#).

DANGER

Hanging load falls down

Danger to life, risk of injury or damage to equipment, in hanging load applications.

- ▶ Charge pressure at motors connection must be according to recommended pressure under all conditions, see data sheet [RE 15301](#) , chapter Recommended charge pressure.
- ▶ Changes to the factory settings must only be made by Bosch Rexroth specialist personnel.

15.1.1 Hydraulic fluids

The hydraulic CA motor is primarily designed for operation with hydraulic fluids according to ISO 11158 HM.

Before the start of project planning, see Data sheet [RE 15414 Hydraulic fluid quick reference](#) for detailed information on hydraulic fluids and specific additional demands.

Filtration of the hydraulic fluid

A contamination level of at most 18/16/13 according to ISO 4406 is required. The less contaminated the fluid, the longer the service life of the hydraulic motor.

Details regarding the selection of hydraulic fluid

The hydraulic fluid should be selected such that the operating viscosity in the temperature range, as measured in the motor housing, is within optimum operation range according to chapter *Hydraulic fluids* in data sheet [RE 15301](#).

Bosch Rexroth AB

SE-895 80 Mellansel

Sweden

Tel. +46 (0) 660 870 00

Fax +46 (0) 660 871 60

www.boschrexroth.com/hagglundscontacts