

# Rexroth EcoDrive Cs Drives

R911320343  
Edition 01

## Instruction Manual



**Title** Rexroth EcoDrive Cs  
Drives

**Type of Documentation** Instruction Manual

**Document Typecode** DOK-ECODR3-DKC\*CS\*UL\*\*-IB01-EN-P

**Purpose of Documentation** This documentation provides information on the installation and operation of the described products, by persons trained and qualified to work with electrical installations.

**Record of Revisions**

Description	Release Date	Notes
Instruction Manual	03.2007	1 <sup>st</sup> edition

**Copyright** © 2007 Bosch Rexroth AG  
Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

**Validity** The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

**Published by** Bosch Rexroth AG  
Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main  
Telephone +49 (0)93 52/40-0 • Tx 68 94 21 • Fax +49 (0)93 52/40-48 85  
<http://www.boschrexroth.com/>  
Dept. BRC/EDY4 (NN)

**Note** This document has been printed on chlorine-free bleached paper.

# Contents

<b>1</b>	<b>Important Notes</b>	<b>1-1</b>
1.1	Safety Instructions .....	1-1
	General Information .....	1-1
	Contact with Electrical Parts .....	1-2
	Handling and Assembly .....	1-2
	Dangerous Movements .....	1-2
	Magnetic and Electromagnetic Fields .....	1-4
	Hot Parts .....	1-4
1.2	Appropriate Use .....	1-4
<b>2</b>	<b>Identification</b>	<b>2-1</b>
2.1	Type Codes .....	2-1
	Drive Controllers with Analog/Parallel Interface .....	2-1
	Drive Controllers with SERCOS interface .....	2-2
	Drive Controllers without Master Communication (Basic Devices) .....	2-3
	Master Communication .....	2-3
	Motor MSM020B .....	2-4
	Motor MSM030 .....	2-5
	Motor MSM040B .....	2-6
2.2	Type Plates .....	2-7
	Drive Controller .....	2-7
	Motor .....	2-7
2.3	Drive Controller – Motor Combinations .....	2-8
2.4	Scope of Supply .....	2-8
<b>3</b>	<b>Ratings and Dimensions</b>	<b>3-1</b>
<b>4</b>	<b>Reference Documentations</b>	<b>4-1</b>
4.1	Overview .....	4-1
<b>5</b>	<b>Instructions for Use</b>	<b>5-1</b>
5.1	Overcurrent Protection .....	5-1
5.2	Connections .....	5-2
	Wiring Diagram .....	5-2
	Connection Diagram .....	5-3
	X1, Mains and Control Voltage .....	5-3
	X2, Additional Choke and Braking Resistor .....	5-4
	X3, Motor .....	5-6

Equipment Grounding Conductor Connection..... 5-8

Connection of Control Interfaces and Terminals ..... 5-8

X5\_3: Holding Brake..... 5-9

Connecting the Motor ..... 5-11

4.3 Startup, Operation, and Maintenance..... 5-11

    Startup ..... 5-11

    Operation ..... 5-12

    Maintenance ..... 5-12

4.4 Installation..... 5-16

    General Information on How to Install the Drive Controller..... 5-16

    Sizing of Enclosure and Control Cabinet..... 5-18

**6 Index**

# 1 Important Notes

## 1.1 Safety Instructions

### General Information

- Do not attempt to install or commission this device without first reading all documentations provided with the product. Read and understand these safety instructions and all user documentation prior to working with the device. If you do not have the user documentation for the device, contact your responsible Bosch Rexroth sales representative. Ask for these documents to be sent immediately to the person or persons responsible for the safe operation of the device.
- If these documentations contain some information you do not understand, it is absolutely necessary that you ask Bosch Rexroth for explanation before you start working on or with the devices.
- Only persons who are trained and qualified for the use and operation of the device may work on this device or within its proximity. The persons are qualified if they have sufficient knowledge of the assembly, installation and operation of the equipment as well as an understanding of all warnings and precautionary measures noted in this documentation.
- Only trained, instructed and qualified persons are allowed to switch electrical circuits and devices on and off in accordance with technical safety regulations, to ground them and to mark them according to the requirements of safe work practices. These persons must have adequate safety equipment and be trained in first aid.
- Technical data, connections and operational conditions are specified in the reference documentations for the product and must be followed at all times.
- If the products take the form of hardware, then they must remain in their original state, in other words, no structural changes are permitted. It is not permitted to decompile software products or alter source codes.
- Do not mount damaged or faulty products or use them in operation.
- Only use spare parts and accessories approved by Bosch Rexroth.
- Follow all safety regulations and requirements for the specific application as practiced in the country of use.
- If the device is resold, rented and/or passed on to others in any other form, these safety instructions must be delivered with the device in the official language of the user's country.
- Proper and correct transport, storage, assembly and installation as well as care in operation and maintenance are prerequisites for optimal and safe operation of this device. Observe the data contained in the corresponding product documentations.



**WARNING**

**Improper use of these devices, failure to follow the safety instructions in this document or tampering with the product, including disabling of safety devices, may result in material damage, bodily harm, electric shock or even death!**

⇒ Observe the following safety instructions!

## Contact with Electrical Parts



### High electrical voltage! Danger to life, electric shock and severe bodily injury!

- Follow general construction and safety regulations when working on power installations.
- Before switching on the device, the equipment grounding conductor must have been non-detachably connected to all electrical equipment and motors in accordance with the connection diagram.

The equipment grounding conductor of the electrical equipment and the units must be non-detachably and permanently connected to the power supply unit at all times. The leakage current is greater than 3.5 mA.

Over the total length, use copper wire of a cross section of a minimum of 10 mm<sup>2</sup> for this equipment grounding connection!

- Before working with electrical parts with voltage potentials higher than 50 V, the device must be disconnected from the mains voltage or power supply unit. Provide a safeguard to prevent reconnection.
- Wait **30 minutes** after switching off power to allow capacitors to discharge before beginning to work. Measure the electric voltage on the capacitors before beginning to work to make sure that the equipment is safe to touch.
- Never touch the electrical connection points of a component while power is turned on.
- Install the covers and guards provided with the equipment properly before switching the device on. Before switching the equipment on, cover and safeguard live parts safely to prevent contact with those parts.
- A residual-current-operated circuit-breaker or r.c.d. cannot be used for electric drives! Indirect contact must be prevented by other means, for example, by an overcurrent protective device according to the relevant standards.

## Handling and Assembly



### Risk of injury by improper handling! Bodily injury by bruising, shearing, cutting, hitting!

- Observe the general construction and safety regulations on handling and assembly.
- Use suitable devices for assembly and transport.
- Avoid jamming and bruising by appropriate measures.
- Always use suitable tools. Use special tools if specified.
- Use lifting equipment and tools in the correct manner.
- If necessary, use suitable protective equipment (for example safety goggles, safety shoes, safety gloves).
- Do not stand under hanging loads.
- Immediately clean up any spilled liquids because of the danger of skidding.

## Dangerous Movements

Dangerous movements can be caused by faulty control of connected motors. Some common examples are:

- improper or wrong wiring of cable connections
- incorrect operation of the equipment components
- wrong input of parameters before commissioning
- malfunction of sensors, encoders and monitoring devices
- defective components
- software or firmware errors

Dangerous movements can occur immediately after equipment is switched on or even after an unspecified time of trouble-free operation.

The monitoring in the drive components will normally be sufficient to avoid faulty operation in the connected drives. Regarding personal safety, especially the danger of bodily harm and material damage, this alone cannot be relied upon to ensure complete safety. Until the integrated monitoring functions become effective, it must be assumed in any case that faulty drive movements will occur. The extent of faulty drive movements depends upon the type of control and the state of operation.



**DANGER**

**Dangerous movements! Danger to life, risk of injury, severe bodily harm or material damage!**

- For the above reasons, ensure personal safety by means of qualified and tested higher-level monitoring devices or measures integrated in the installation.

They have to be provided for by the user according to the specific conditions within the installation and a hazard and fault analysis. The safety regulations applicable for the installation have to be taken into consideration. Unintended machine motion or other malfunction is possible if safety devices are disabled, bypassed or not activated.

**To avoid accidents, bodily harm and/or material damage:**

- Keep free and clear of the machine's range of motion and moving parts. Possible measures to prevent people from accidentally entering the machine's range of motion:
  - use safety fences
  - use safety guards
  - use protective coverings
  - install light curtains or light barriers
- Fences and coverings must be strong enough to resist maximum possible momentum.
- Mount the emergency stop switch in the immediate reach of the operator. Verify that the emergency stop works before startup. Don't operate the device if the emergency stop is not working.
- Isolate the drive power connection by means of an emergency stop circuit or use a safety related starting lockout to prevent unintentional start.
- Make sure that the drives are brought to a safe standstill before accessing or entering the danger zone.
- Additionally secure vertical axes against falling or dropping after switching off the motor power by, for example:
  - mechanically securing the vertical axes,
  - adding an external braking/ arrester/ clamping mechanism or
  - ensuring sufficient equilibration of the vertical axes.
- The standard equipment motor brake or an external brake controlled directly by the drive controller are **not sufficient to guarantee personal safety!**
- Disconnect electrical power to the equipment using a master switch and secure the switch against reconnection for:
  - maintenance and repair work
  - cleaning of equipment
  - long periods of discontinued equipment use
- Prevent the operation of high-frequency, remote control and radio equipment near electronics circuits and supply leads. If the use of such devices cannot be avoided, verify the system and the installation for possible malfunctions in all possible positions of normal use before initial startup. If necessary, perform a special electromagnetic compatibility (EMC) test on the installation.

## Magnetic and Electromagnetic Fields



### WARNING

#### Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electrical equipment!

- Persons with heart pacemakers and metal implants are not permitted to enter following areas:
  - Areas in which electrical equipment and parts are mounted, being operated or commissioned.
  - Areas in which parts of motors with permanent magnets are being stored, repaired or mounted.
- If it is necessary for somebody with a pacemaker to enter such an area, a doctor must be consulted prior to doing so. The interference immunity of present or future implanted heart pacemakers differs greatly, so that no general rules can be given.
- Those with metal implants or metal pieces, as well as with hearing aids must consult a doctor before they enter the areas described above. Otherwise health hazards may occur.

## Hot Parts



### CAUTION

#### Hot surfaces at motor housings, on drive controllers or chokes! Danger of burns!

- Do not touch surfaces of device housings and chokes in the proximity of heat sources! Danger of burns!
- Do not touch housing surfaces of motors! Danger of burns!
- According to operating conditions, temperatures can be higher than **60 °C (140 °F)** during or after operation.
- Before accessing motors after having switched them off, let them cool down for a sufficiently long time. Cooling down can require **up to 140 minutes!** Roughly estimated, the time required for cooling down is five times the thermal time constant specified in the Technical Data.
- Wear safety gloves or do not work at hot surfaces.
- For certain applications, the manufacturer of the end product, machine or installation, according to the respective safety regulations, has to take measures to avoid injuries caused by burns in the end application. These measures can be, for example: warnings, guards (shielding or barrier), technical documentation.

## 1.2 Appropriate Use

This product may only be used for the applications mentioned in the reference documentations (see chapter "Reference Documentations") and under the described application, ambient and operating conditions.











# Motor MSM040B

Abbrev. Column	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0							
Example:	M	S	M	0	4	0	B	-	0	3	0	-	N	N	-	C	0	-	C	G	1																										

- 1. Product**
  - 1.1 MSM. .... = MSM
  
- 2. Size**
  - 2.1 040. .... = 040
  
- 3. Length**
  - 3.1 Length ..... = B
  
- 4. Windings**
  - 4.1 MSM040B ..... = 0300
  
- 5. Cooling mode**
  - 5.1 natural convection, without blower ..... = NN
  
- 6. Encoder**
  - 6.1 Incremental encoder ..... = C0
  - 6.2 Multiturn absolute encoder ..... = M0
  
- 7. Electrical connection**
  - 7.1 cable tail ..... = C
  
- 8. Shaft**
  - 8.1 key per DIN 6885-1 ..... = C
  - 8.2 plain shaft ..... = G
  
- 9. Holding brake**
  - 9.1 without holding brake ..... = 0
  - 9.2 electrical release 2.45 Nm ..... = 1
  
- 10. Standard reference**

<u>Standard</u>	<u>Title</u>	<u>Edition</u>
DIN 6885-1	Drive Type with Fastenings without Taper Action; Parallel Keys, Keyways, Deep Pattern	1968-08

Fig. 2-7: Type code for motor MSM040B

## 2.2 Type Plates

### Drive Controller




Fig. 2-8: Type plate 1

### Motor




Fig. 2-9: Motor type plate

## 2.3 Drive Controller – Motor Combinations

**Note:** The individual drive controllers may only be operated with the respective motors.

Drive controller	Motor	Properties (motor)
DKCxx.x-004	MSM020B-0300-NN-C0-CG0	100 W: incremental, plain shaft, without brake
	MSM020B-0300-NN-C0-CG1	100 W: incremental, plain shaft, with brake
	MSM020B-0300-NN-C0-CC0	100 W: incremental, key, without brake
	MSM020B-0300-NN-C0-CC1	100 W: incremental, key, with brake
	MSM020B-0300-NN-M0-CG0	100 W: absolute, plain shaft, without brake
	MSM020B-0300-NN-M0-CG1	100 W: absolute, plain shaft, with brake
	MSM020B-0300-NN-M0-CC0	100 W: absolute, key, without brake
	MSM020B-0300-NN-M0-CC1	100 W: absolute, key, with brake
DKCxx.x-008	MSM030B-0300-NN-C0-CG0	200 W: incremental, plain shaft, without brake
	MSM030B-0300-NN-C0-CG1	200 W: incremental, plain shaft, with brake
	MSM030B-0300-NN-C0-CC0	200 W: incremental, key, without brake
	MSM030B-0300-NN-C0-CC1	200 W: incremental, key, with brake
	MSM030B-0300-NN-M0-CG0	200 W: absolute, plain shaft, without brake
	MSM030B-0300-NN-M0-CG1	200 W: absolute, plain shaft, with brake
	MSM030B-0300-NN-M0-CC0	200 W: absolute, key, without brake
	MSM030B-0300-NN-M0-CC1	200 W: absolute, key, with brake
DKCxx.x-012	MSM030C-0300-NN-C0-CG0	400 W: incremental, plain shaft, without brake
	MSM030C-0300-NN-C0-CG1	400 W: incremental, plain shaft, with brake
	MSM030C-0300-NN-C0-CC0	400 W: incremental, key, without brake
	MSM030C-0300-NN-C0-CC1	400 W: incremental, key, with brake
	MSM030C-0300-NN-M0-CG0	400 W: absolute, plain shaft, without brake
	MSM030C-0300-NN-M0-CG1	400 W: absolute, plain shaft, with brake
	MSM030C-0300-NN-M0-CC0	400 W: absolute, key, without brake
	MSM030C-0300-NN-M0-CC1	400 W: absolute, key, with brake
DKCxx.x-018	MSM040B-0300-NN-C0-CG0	750 W: incremental, plain shaft, without brake
	MSM040B-0300-NN-C0-CG1	750 W: incremental, plain shaft, with brake
	MSM040B-0300-NN-C0-CC0	750 W: incremental, key, without brake
	MSM040B-0300-NN-C0-CC1	750 W: incremental, key, with brake
	MSM040B-0300-NN-M0-CG0	750 W: absolute, plain shaft, without brake
	MSM040B-0300-NN-M0-CG1	750 W: absolute, plain shaft, with brake
	MSM040B-0300-NN-M0-CC0	750 W: absolute, key, without brake
	MSM040B-0300-NN-M0-CC1	750 W: absolute, key, with brake

Fig. 2-10: Drive controller – motor combinations

## 2.4 Scope of Supply

Connection accessories for connections X1, X2 and X3 (SUP-E02-DKC\*CS-CONPWR)


### 3 Ratings and Dimensions

Description	Symbol	Unit	DKC**.3-004	DKC**.3-008	DKC**.3-012	DKC**.3-018
listing according UL-standard (UL)			UL 508 C			
listing according CSA-standard (UL)			Canadian National Standard(s) C22.2 No. 14-05			
UL files (UL)			E 227957			
pollution degree (UL)			Use in a pollution degree 2 environment. The device is to be installed in an enclosure that provides pollution degree 2.			
maximum ambient temperature with nominal data (UL)	T <sub>amax</sub>	°C	40 °C			
maximum ambient temperature with reduced nominal data (UL)	T <sub>amax_red</sub>	°C	55 °C			
Weight	m	kg	1,8			2,1
Device height (UL) <sup>1)</sup>	H	mm	182			
Device depth (UL) <sup>2)</sup>	T	mm	170			
Device width (UL) <sup>3)</sup>	B	mm	55			70
minimum distance on the top of the device <sup>4)</sup>	d <sub>top</sub>	mm	50			
minimum distance on the bottom of the device <sup>5)</sup>	d <sub>bot</sub>	mm	50			
rated control voltage input (UL) <sup>6)</sup>	U <sub>N3</sub>	V	24 ac			
rated power consumption control voltage input without holding brake, without control section at U <sub>N3</sub> = DC 24 V (UL) <sup>7)</sup>	P <sub>N3</sub>	W	n / a	n / a	n / a	n / a
short circuit current rating, SCCR, symmetrical amperes (UL) <sup>8)</sup>	I <sub>SCCR</sub>	A rms	5000			
rated input voltage, power (UL) <sup>9)</sup>		V	200 – 230 ac			200 – 240 ac
tolerance rated input voltage (UL)		%	n / a	n / a	n / a	n / a
input number of phases (UL)			3 (1)	3 (1)	3(1)	3
input frequency (UL)	f <sub>LN</sub>	Hz	50 / 60 Hz			
tolerance input frequency (UL)		Hz	n / a	n / a	n / a	n / a
maximum input current (UL) <sup>10)</sup>	I <sub>L_cont</sub>	A	1,1	1,3	2,2	3,1
branch circuit protection fuse (UL) <sup>11)</sup>			2	2	3	4
field wiring material (UL) <sup>12)</sup>			Use 60/75 °C copper wire only, use class 1 wire only or equivalent			
required wire size according UL 508 A (internal wiring); at I <sub>L_cont</sub> (UL) <sup>13)</sup>	A <sub>LN</sub>		AWG 14			
maximum output voltage (UL)	U <sub>out</sub>	V	84	92	106	116
output number of phases (UL)			3			
maximum output current (UL)	I <sub>out_max</sub>	A	1	1,6	2,5	4,3
maximum output frequency (UL) <sup>14)</sup>	f <sub>out</sub>	Hz	333,3			300

Description	Symbol	Unit	DKC**.3-004	DKC**.3-008	DKC**.3-012	DKC**.3-018
power dissipation at continuous current $I_{out\_cont}$ and continuous DC bus power $P_{DC\_cont}$ respectively (UL) <sup>15)</sup>	$P_{Diss\_cont}$	W	100	200	400	750
Overspeed protection <sup>16)</sup>			n / a			

- 1) 2) 3) housing dimension; see related dimension sheet also
  - 4) 5) see fig. "Air inlet and outlet of drive controller"
  - 6) observe supply voltage for motor holding brakes
  - 7) find value for control section in project planning manual
  - 8) Suitable for use on a circuit capable of delivering not more than this SCCR value, 230 V AC or less. The drive series shall be used with listed AC input line fuses or listed circuit breakers specified in this documentation.
  - 9) Mains input L1, L2, L3
  - 10) at  $P_{DC\_cont}$
  - 11) class J branch circuit fuse
  - 12) find value for tightening torque in project planning manual, electrical terminals
  - 13) copper wire; PVC-insulation (conductor temperature 90 °C); Table 13.5.1;  $T_a \leq 40$  °C
  - 14) depending on switching frequency which was set in parameter P-0-0001
  - 15) plus dissipation of braking resistor
  - 16) These devices do not provide overspeed protection or equivalent
- Abb. 3-1: UL ratings and dimensions

**Distances**



A: air intake  
 B: air outlet  
 C: mounting surface in control cabinet  
 $d_{top}$ : distance top  
 $d_{bot}$ : distance bottom  
 Fig. 3-2: Air intake and air outlet at drive controller

## 4 Reference Documentations

### 4.1 Overview

Title	Type	Document Typecode
Rexroth EcoDrive Cs Drive Controllers MGP 01VRS	Functional Description	DOK-ECODR3-MGP-01VRS**-FKxx-EN-P
	Parameter Description	DOK-ECODR3-MGP-01VRS**-PAxx-EN-P
	Troubleshooting Guide	DOK-ECODR3-MGP-01VRS**-WA01-EN-P

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: "PR01" is the first edition of a Project Planning Manual)

Fig. 4-1: Documentations - Overview

## 5 Instructions for Use

### 5.1 Overcurrent Protection

Branch circuit protection has to be provided externally according to the maximum values (voltage and current or voltage and percent of FLA of the fuses [FLA: Full Load Ampacity]).

## 5.2 Connections

### Wiring Diagram




Fig. 5-2: Wiring diagram

### Connection Diagram




Fig. 5-3: Total connection diagram

### X1, Mains and Control Voltage



**Lethal electric shock caused by live parts with more than 50 V!**

- ⇒ Before starting to work on the drive controller switch off the voltage supply via the main switch or the circuit breaker.
- ⇒ Always mount or dismount both connectors (motor connection and mains connection) at the drive controller.
- ⇒ Observe the notes in the "Important Notes" chapter.

### Technical Data of the Terminal Connector

Graphic Representation




Fig. 5-4: Terminal connector X1

Design

Type	Number of poles	Type of design
spring tension	5	socket on connector

Fig. 5-5: Design

Connection Cross Section

Max. connectable cross section [mm <sup>2</sup> ]	Cross section in AWG gauge No.
2.5	12

Fig. 5-6: Connection cross section

## X2, Additional Choke and Braking Resistor

### Technical Data of the Terminal Connector

Graphic Representation




Fig. 5-7: Terminal connector X2

Design	Type	Number of poles	Type of design
	spring tension	5	socket on connector

Fig. 5-8: Design

Connection Cross Section	Cross section single-core [mm <sup>2</sup> ]	Cross section in AWG gauge No.
	0,75 - 2	18 - 14

Fig. 5-9: Connection cross section

### DL1, DL2: Additional Choke

By connecting an additional choke it is possible to increase the allowed continuous DC bus power.

**Note:** If there isn't any choke used these connections must be jumpered. A wire bridge is supplied together with the device.

**Note:** Rexroth doesn't deliver additional chokes for Rexroth EcoDrive Cs drives.

### Choke Connection




Fig. 5-10: Connection for choke

### RB1, RB2, RB3: Braking Resistor

**Note:** The internal braking resistor causes a derating of the continuous DC bus power.

By connecting an external braking resistor the derating of the continuous DC bus power can be prevented.

**Note:** When an external braking resistor is used, the drive has to be informed of this fact by means of the **DriveTop** commissioning software (call in DriveTop by menu item "Drive Functions -> Drive controller")

**Accessory** An external braking resistor is available as an accessory.

## Braking Resistor Connection




Fig. 5-11: Connection for braking resistor

**Note:** If you do not use any external braking resistor, the RB2 and RB3 connections must be jumpered.




Fig. 5-12: Jumper on RB2 and RB3

## X3, Motor



**Lethal electric shock caused by live parts with more than 50 V!**

- ⇒ Before starting to work on the drive controller switch off the voltage supply via the main switch or the fuse.
- ⇒ Always mount or dismount both connectors (motor connection and mains connection) at the drive controller.
- ⇒ Observe the notes in the "Important Notes" chapter.

### Technical Data of the Terminal Connector

Graphic Representation




Fig. 5-13: Terminal connector X3

Design

Type	Number of poles	Type of design
spring tension	4	socket on connector

Fig. 5-14: Design

Connection Cross Section

Max. connectable cross section [mm <sup>2</sup> ]	Max. cross section in AWG gauge No.:
0,75 - 2	18 - 14

Fig. 5-15: Connection cross section

Motor Cables

For connecting drive controller and motor please use the appropriate Rexroth motor power cables.

**Cable length:**

The maximum cable length is **40 m** with:

- ready-made Rexroth cable
- ambient temperature of ≤ 40 °C according to EN 60204
- maximum switching frequency of 8 kHz



**WARNING**

**No warranty!**

If cables manufactured by a company other than Bosch Rexroth resp. cables longer than 40 m are used, the Bosch Rexroth warranty for the entire drive system becomes invalid.

Use ready-made Rexroth cables!

## Equipment Grounding Conductor Connection



**Lethal electric shock caused by live parts with more than 50 V!**

Connect the equipment grounding conductor connection of the drive controller to the equipment grounding system of the control cabinet.

Check the continuity of the equipment grounding conductors from the mains connection to the connected motors.

### Technical Data of the Terminal Connector

Graphic Representation




Fig. 5-16: Equipment grounding conductor connection

Design

Type	Number	Type of design
terminal block	2	threaded terminal end for M4 ring cable lugs

Fig. 5-17: Design

Connection Cross Section

Cross section single-core [mm <sup>2</sup> ]	Max. cross section in AWG gauge No.
2.0	14

Fig. 5-18: Connection cross section

Contrary to the safety instruction in chapter 1.1 a copper conductor cross section of 2 mm<sup>2</sup> would be sufficient.

**Cable Length** Maximum 1 m

## Connection of Control Interfaces and Terminals



See project planning manual for more details.

## X5\_3: Holding Brake



### Dangerous movements! Danger to personnel from falling or dropping axes!

- ⇒ The optionally delivered motor holding brake or an external brake controlled by the drive controller are not sufficient to guarantee the safety of personnel!
- ⇒ Personnel safety must be achieved using higher-ranking, fail-safe procedures:  
 Dangerous areas should be blocked off with fences or grids.  
 Additionally secure vertical axes against falling or sinking after switching off the motor power by, for example:
  - mechanically blocking the vertical axis,
  - adding an external braking/catching/clamping mechanism or
  - providing sufficient counterbalance for the axis.

Switching performance: see Functional Description of firmware.

### Technical Data of the Terminal Connector

#### Graphic Representation




Fig. 5-19: Terminal connector X5\_3

#### Design

Type	Number of poles	Type of design
spring tension	4	socket on connector

Fig. 5-20: Design

#### Connection Cross Section

Max. cross section single-core [mm <sup>2</sup> ]	Cross section in AWG gauge No.
0,25 - 0.5	23 - 20

Fig. 5-21: Connection cross section

**BR+, BR-  
Connection**

4	holding brake-
3	holding brake+
2	+24V_ext_brake
1	0V_ext_brake

Fig. 5-22: Holding brake and voltage connection

**Load Capacity of the BR+, BR- connection:**

max. switching voltage	DC 36 V
max. switching current	DC 1 A
max. continuous current	DC 1 A
voltage drop electronic contact	100 mV
guaranteed number of switching operations	unlimited (wear-resistant electronic contact)
short-circuit and overload protection	present

**Voltage connection for brake**

**Note:** The motor holding brake is not supplied by the drive controller. Observe the data of the motor holding brake.

**Note:** It is impossible to loop through the voltages to other drive controllers. Other drive controllers have to be connected to the voltage source in star-shaped form.

**CAUTION****Risk of damage!**

⇒ The maximum allowed current load of the terminal connectors for the voltage supply of the brake and the control voltage supply must also be observed in the case of a short circuit.

max. voltage at X5_3.1 referring to X5_3.2:	36 V
current consumption at X5_3.3 and required supply voltage:	see Project Planning Manual

**Line for Voltage Connection of  
Brake**

line cross section	min. 1 mm <sup>2</sup>
voltage stability of a single strand against ground:	≥ 750 V
line routing:	parallel where possible (twist)
max. inductance between 24 V source and X5_3:	100 μH (corresponds to approx. 2 x 75 m)

**Controlling the Motor Holding  
Brake**

The drive controller assumes the control of the holding brake.

## Connecting the Motor

After having mounted the motor mechanically as specified, proceed to connecting the motor.



**DANGER**

**Danger to life by electric voltage! Handling within the range of live parts is extremely dangerous. Therefore:**

- ⇒ Any work required on the electric system may only be carried out by skilled electricians. It is absolutely necessary to use electric tools.
- ⇒ Before starting work, the system must be de-energized and the power switch be secured against unintentional or unauthorized re-energization.
- ⇒ Before starting work, the appropriate measuring equipment must be used to check whether parts of the system are still applied to residual voltage (e.g. caused by capacitors, etc.). If yes, wait until these parts have discharged.



**WARNING**

**Injuries to persons or property are possible! Interrupting or connecting live lines may cause unpredictable dangerous situations or lead to physical damage. Therefore:**

- ⇒ Connect and disconnect plug connectors only when they are dry and de-energized.
- ⇒ During operation of the system, all plug connectors must be securely tightened.



**WARNING**

**Risk of short-circuit caused by liquid coolant or lubricant! Short-circuits of live lines may cause unpredictable dangerous situations or lead to physical damage. Therefore:**

- ⇒ Provide open mating sides of power plug connectors with safety caps when installing or replacing drive components, if you cannot exclude that they might be moistened with liquid coolant or lubricant.

The connection diagrams by Rexroth are exclusively intended for the preparation of system circuit diagrams!

- ⇒ Connect the motor as specified in the machine manufacturer's system circuit diagram!

## 5.3 Startup, Operation, and Maintenance

### Startup

The MSM motors may be put into operation only if they have been carefully and properly mounted and if the electric connection has been properly established.

- Before startup** Before putting the MSM motors into operation, the following must be checked and/or ensured:
- It must be possible to turn the rotor manually with the holding brake opened; there may be no running noise (e.g. rubbing). If necessary, the holding brake must be opened by applying a DC voltage of  $24\text{ V} \pm 10\%$ .
  - The motor must be mounted and aligned correctly. The motor flange must be coupled to the machine structure or the gear absolutely even.
  - It must be ensured that all electric connections (motor and drive controller) have been established as specified and that the cable screw unions have been tightened.
  - It must be ensured that the protective conductor and/or the protective grounding have been executed properly.
  - If the optional holding brake is used, its operational reliability must be ensured.
  - Shock protection measures against live and moving parts must be provided for.
- Startup** MSM motors may be put into operation only with Rexroth EcoDrive Cs drive controllers by Rexroth. After the connection has been properly established and the above requirements are complied with, the MSM motor can be put into operation via the drive controller.

---

**Note:** Startup of the drives is described in the Functional Description of the particular firmware MGPxxVRS. Request the corresponding product documentation from your local sales office.

---

## Operation

Ensure that the ambient conditions are kept during operation.

## Maintenance

### Cleaning

Excessive dirt, dust or shavings may affect the function of the motors adversely, may in extreme cases even cause a failure of the motors. For that reason, you should clean

- Cooling ribs**
- the cooling ribs of the motors at regular intervals, in order to obtain a sufficiently large heat radiation surface. If the cooling ribs are dirty in part, sufficient heat dissipation via the environmental air is not possible any longer.

An insufficient heat radiation may have undesired consequences. The bearing service life is reduced by operation at impermissibly high temperatures (the bearing grease is decomposing). Switchoff caused by overtemperature despite operation on the basis of selected data, because the appropriate cooling is missing.

### Bearings

The nominal service life of the bearings is 30.000 h, if the permissible radial and axial forces are not exceeded. Even if the bearings are loaded with higher forces to a minor degree only, their service life is affected negatively.

### Connection Cable

Check connection lines for damage at regular intervals and replace them, if necessary.

Check any optionally present energy management chains (drag chains) for defects.



**Electrocution by live parts of more than 50 V!**

⇒ Do not repair any connection lines provisionally. If the slightest defects are detected in the cable sheath, the system must be put out of operation immediately. Then the cable must be replaced.

Check the protective conductor connection for proper state and tight seat at regular intervals and replace it, if necessary.

**Holding brake**

The check can be done by means of a function (brake check) integrated in the firmware (see Functional Description).

**Battery**

**Absolute encoders** Motors with absolute encoders need a battery to back-up the encoder signals. The battery is set into the drive controller (Exception: Rexroth Cartesian Motion Systems (CMS)).

**Warning message** The drive controller observes voltage of battery and gives just in time a warning "F248 Low battery voltage".

**Service life** The service life of the battery depends on the ratio of switch-ON-duration to switch-OFF-duration:

$$I = \frac{t_{ON}}{t_{OFF}}$$

t<sub>ON</sub>: duration, the drive controller is switched on  
 t<sub>OFF</sub>: duration, the drive controller is switched off  
 I: ON/OFF ratio

Fig. 5-23: ON/OFF ratio




Fig. 5-24: Service life of battery

Thus, the longer the drive controller is switched on, the longer is the service life of the battery.

**Refresh Prior to using the battery you always have to refresh the battery:**

1. Connect connector of battery to mating connector of resistor (see figure below)  
(Battery and resistor are parts of SUP-E03-DKC\*CS-BATTERY)





Fig. 5-25: Battery refreshing

2. Wait **2 minutes**
3. Disconnect battery

**Changing the battery**

Depending on the operating hours of the motor, the time available for changing the battery is limited:



- A: operating hours: 3000 => backup time 79 s
- B: operating hours: 1000 => backup time 554 s
- C: operating hours: 0 (condition as supplied) => backup time 792 s
- D: range of battery undervoltage (2.3 to 2.7 V)

Fig. 5-26: Backup time of supply voltage

During this time the supply voltage of the absolute value encoder is backed up so that the information regarding the absolute value encoder position is maintained.

---


**Note:** If you exceed the backup time when changing the battery the absolute value encoder position gets lost.

---

**Note:** If you use the drive controllers together with Rexroth Cartesian Motion Systems (CMS), regard the instructions of the CMS manual (RE 82 674) now.


---

1. Push battery cover downwards and remove cover:



2. Remove old battery
3. If not already done so, refresh new battery now (see instructions above)
4. Insert new battery

5. Connect connector attached to the battery to one of the two mating connectors on the drive controller



6. Attach battery cover. Push cover upwards until it snaps in
7. Dispose old battery according to the valid directions of your country

## 5.4 Installation

### General Information on How to Install the Drive Controller

Damage can be caused to the drive controller or circuit boards if electrostatic charging present in people and/or tools is discharged across them. Therefore, please note the following information:



**CAUTION**

**Electrostatic charges can cause damage to electronic components and interfere with their operational safety!**

⇒ Exposed conductive parts coming into contact with components and circuit boards must be discharged by means of grounding. Otherwise errors may occur when triggering motors and moving elements.

Such exposed conductive parts include:

- the copper bit when soldering
- the human body (ground connection caused by touching a conductive, grounded item)
- parts and tools (place them on a conductive support)

Endangered components may only be stored or dispatched in conductive packaging.

---

**Note:** Rexroth connection diagrams are only to be used for producing installation connection diagrams. The machine manufacturer's installation connection diagrams must be used for wiring the installation!

---

- Lay signal lines separately from the load resistance lines because of the occurrence of interference.
  - Transmit analog signals (e.g. command values, actual values) via shielded lines.
  - Do not connect mains, DC bus or power leads to low voltages or allow them to come into contact with these.
  - When carrying out a high voltage test or an applied-overvoltage withstand test on the machine's electrical equipment, disconnect all connections to the devices. This protects the electronic components (allowed in accordance with EN 60204-1). During their routine testing, Rexroth drive components are tested for high voltage and insulation in accordance with EN 50178.
- 



**CAUTION**

**Risk of damage to the drive controller by connecting and disconnecting live connections!**

⇒ Do not connect and disconnect live connections.

---

## Sizing of Enclosure and Control Cabinet

### Control Cabinet with Multiple-Line Structure

**Note:** Particular attention should be paid to the maximum allowed air intake temperature of components when they are arranged in multiple lines in the control cabinet. Where necessary, cooling air guides are to be provided with blowers specially used for this purpose.




Fig. 5-27: Example of arrangement for multiple-line structure with components

### Arrangement of Cooling Units



**CAUTION**

#### Possible damage to the drive controller

Operational safety of the machine endangered!  
Note the following instructions!

#### Avoiding Dripping or Sprayed Water

Due to the operating principle, condensation water is formed when cooling units are used. For this reason, please observe the following information:

- Always position cooling units in such a way that condensation water cannot drip onto electronic equipment in the control cabinet.
- Position the cooling unit in such a way that the blower of the cooling unit does not spray accumulated condensation water onto electronic equipment.




Fig. 5-28: Arranging the cooling unit on the control cabinet




Fig. 5-29: Arranging the cooling unit at the front of the control cabinet

**Avoiding Moisture Condensation**

Moisture condensation occurs when the temperature of the device is lower than the ambient temperature.

- Set cooling units with temperature adjustment to the maximum surrounding temperature and not lower!
- Set cooling units with follow-up temperature in such a way that the interior temperature of the control cabinet is no lower than the temperature of the surrounding air. Set the temperature limitation to the maximum surrounding temperature!

- Only use well-sealed control cabinets so that moisture condensation cannot arise as a result of warm and moist external air entering the cabinet.

In the event that control cabinets are operated with the doors open (commissioning, servicing etc.) it is essential to ensure that after the doors are closed the drive controllers cannot at any time be cooler than the air in the control cabinet, as otherwise moisture condensation can occur. For this reason sufficient circulation must be provided inside the control cabinet to avoid pockets of heat.

## 6 Index

### A

absolute encoder  
battery 5-13  
Appropriate Use 1-4

### B

battery  
changing 5-14  
for absolute encoder 5-13  
refresh 5-14  
service life 5-13  
Br+, Br- 5-9  
brake  
connection 5-9  
braking resistor  
connection 5-5

### C

cable  
motor 5-7  
Cartesian Motion Systems 5-15  
changing  
battery 5-14  
choke  
connection 5-5  
CMS 5-15  
combination  
drive controller - motor 2-8  
connection  
braking resistor 5-5  
choke 5-5  
equipment grounding conductor 5-8  
holding brake 5-9  
motor 5-6  
Connection Diagram 5-3  
control cabinet  
with multiple-line structure 5-18  
cooling ribs 5-12  
cooling units 5-18

### D

Dimensions 3-1  
DL1, DL2 5-5  
Documentations 4-1  
dripping or sprayed water 5-18  
drive controller  
combination with motors 2-8  
index 2-7  
serial number 2-7

### E

EcoDrive Cs  
type codes 2-1  
equipment grounding conductor  
connection 5-8

### F

F248 Low battery voltage 5-13

**H**

holding brake  
connection 5-9

**I**

Identification 2-1  
Important Notes 1-1  
index  
drive controller 2-7  
motor 2-7  
Instructions for Use 5-1

**L**

L1, L2, L3 5-3

**M**

mains and control voltage  
terminal connector 5-3  
moisture condensation 5-19  
motor  
index 2-7  
motor  
battery (absolute encoder) 5-13  
cable 5-7  
combination with drive controllers 2-8  
connection 5-6  
maintenance 5-12  
operation 5-12  
serial number 2-7  
startup 5-11  
type code MSM020B 2-4  
type code MSM030 2-5  
type code MSM040B 2-6  
MSM020B  
type code 2-4  
MSM030  
type code 2-5  
MSM040B  
type code 2-6

**O**

Overcurrent Protection 5-1

**R**

Ratings 3-1  
RB1, RB2, RB3 5-5  
Reference Documentations 4-1  
refresh  
battery 5-14

**S**

Safety Instructions 1-1  
serial number  
drive controller 2-7  
motor 2-7  
service life  
battery 5-13

**T**

Type code  
basic devices 2-3

drive controllers with SERCOS interface 2-1, 2-2  
drive controllers without master communication 2-3  
master communication 2-3  
motor MSM020B 2-4  
motor MSM030 2-5  
motor MSM040B 2-6  
Type codes 2-1  
Type plates 2-7

## U

U, V, W 5-7  
Use  
    appropriate 1-4

## W

Wiring Diagram 5-2

## X

X1 5-3  
X2 5-4  
X3 5-6  
X5\_3 5-9





Bosch Rexroth AG  
Electric Drives and Controls  
P.O. Box 13 57  
97803 Lohr, Germany  
Bgm.-Dr.-Nebel-Str. 2  
97816 Lohr, Germany  
Phone +49 (0)93 52-40-50 60  
Fax +49 (0)93 52-40-49 41  
service.svc@boschrexroth.de  
[www.boschrexroth.com](http://www.boschrexroth.com)