

Rexroth IndraControl S67

High Speed Digital Module
8 Outputs – 0.1 A (4×M12)

Application Description
R911342200

Edition 02



Title Rexroth IndraControl S67
Digital Module High Speed
8 Outputs – 0.1 A (4×M12)

Type of Documentation Application Description

Document Typecode DOK-CONTRL-S67DO8M12HS-AP02-EN-P

Internal File Reference RS-dd1d988ff27506e80a6846a50069f75a-2-en-US-4

Change Record

| Edition | Release Date | Notes |
|----------------|---------------------|---------------|
| Edition 01 | 2013-10 | First edition |
| Edition 02 | 2014-08 | Supplements |

Copyright © Bosch Rexroth AG 2014

This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth AG. It may not be reproduced or given to third parties without its consent.

Liability The specified data is intended for product description purposes only and shall not be deemed to be a guaranteed characteristic unless expressly stipulated in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Editorial Department Compact Control KS (KaWa/MePe)

Table of Contents

| | Page |
|---|-----------|
| 1 About this Documentation..... | 5 |
| 1.1 General Information..... | 5 |
| 1.2 Scope..... | 5 |
| 1.3 Validity of the Documentation..... | 6 |
| 1.4 Structuring the Documentation..... | 7 |
| 1.5 Terms and Abbreviations..... | 8 |
| 1.6 Customer Feedback..... | 8 |
| | |
| 2 Important Instructions on Use..... | 9 |
| 2.1 Intended Use..... | 9 |
| 2.1.1 Introduction..... | 9 |
| 2.1.2 Use and Application Cases..... | 9 |
| 2.2 Safety Devices..... | 10 |
| 2.3 Information about the Operation..... | 10 |
| 2.4 Unintended Use..... | 10 |
| | |
| 3 Using the Safety Instructions..... | 11 |
| 3.1 Structure of the Safety Instructions..... | 11 |
| 3.2 Explaining Signal Words and Safety Alert Symbol..... | 11 |
| 3.3 Symbols Used..... | 12 |
| | |
| 4 Device Description..... | 13 |
| 4.1 General Information..... | 13 |
| 4.2 Connections | 13 |
| 4.3 Labeling Options and Mounting..... | 14 |
| 4.4 Display Elements..... | 15 |
| 4.5 Labeling and Bar Code Type at the Back of the Device..... | 16 |
| 4.6 Type Plate..... | 16 |
| 4.7 Schematic Circuit Diagram | 17 |
| 4.8 Dimensions..... | 18 |
| 4.9 Technical Data..... | 18 |
| 4.9.1 Device Data..... | 18 |
| 4.9.2 Module Supply..... | 18 |
| 4.9.3 Communication..... | 19 |
| 4.9.4 Digital Outputs..... | 19 |
| 4.9.5 Specification for Actuator Selection..... | 19 |
| 4.9.6 Influence of Operating States to the Output..... | 20 |
| 4.9.7 Electrical Isolation..... | 20 |
| 4.9.8 Parameterizable Functions..... | 20 |
| 4.9.9 Diagnostic I/O..... | 20 |
| 4.9.10 Process Image..... | 20 |
| 4.9.11 Displays..... | 21 |
| 4.9.12 Standards and Approvals..... | 21 |

Table of Contents

| | Page |
|-----------|--|
| 5 | Mounting the Module..... 23 |
| 5.1 | General Information..... 23 |
| 5.2 | Mounting Notes..... 23 |
| 5.3 | Required Tools and Accessories for Mounting..... 23 |
| 5.4 | Direct Mounting to the System..... 24 |
| 5.5 | Mounting on Carrier Rail (only with Bosch Rexroth Accessories)..... 24 |
| 5.5.1 | Fastening Carrier Rail Adapter on the Module..... 24 |
| 5.5.2 | Fastening the Module with Mounting Rail Adapter to a Mounting Rail..... 25 |
| 5.6 | Mounting on Profile Rail (only with Bosch Rexroth Accessories)..... 26 |
| 5.6.1 | Fastening Profile Adapter on the Module..... 26 |
| 5.6.2 | Fastening the Module with Profile Adapter on Profile Rail..... 27 |
| 5.7 | Replacing the Labeling Fields..... 27 |
| 5.8 | Mounting the Spacer in Case of Compact Arrangement..... 28 |
| 6 | Connecting Data and Supply Cable..... 31 |
| 6.1 | Notes..... 31 |
| 6.2 | Required Accessories..... 32 |
| 6.3 | S-BUS Connection..... 32 |
| 6.4 | Supply Cable Connection..... 33 |
| 6.5 | Connecting the Actuator cable..... 35 |
| 7 | Commissioning..... 37 |
| 7.1 | General Information..... 37 |
| 8 | Process Images..... 39 |
| 8.1 | General Information..... 39 |
| 8.2 | Output Data..... 39 |
| 8.3 | Input Data..... 40 |
| 9 | Parameterization..... 41 |
| 9.1 | General Information..... 41 |
| 9.2 | Diagnostic Overview..... 41 |
| 9.3 | Input Parameters..... 42 |
| 9.4 | Global Settings for Field Supply..... 43 |
| 9.5 | Automatic Storage of System Parameters..... 43 |
| 9.6 | Firmware Update..... 43 |
| 10 | Diagnostics via LED Signals..... 45 |
| 10.1 | General Information..... 45 |
| 10.2 | Operating Messages of the Module..... 45 |
| 11 | Maintenance and Service..... 49 |
| 11.1 | General Information..... 49 |
| 11.2 | Replacing the Module..... 49 |

Table of Contents

| | Page |
|-----------|---|
| 11.2.1 | General Information..... 49 |
| 11.2.2 | Disconnecting the Wiring..... 49 |
| 11.2.3 | Removing the Field Bus Coupler from the System..... 49 |
| 11.2.4 | Removing the Field Bus Coupler from the Carrier Plate..... 49 |
| 11.2.5 | Removing the Field Bus Coupler from the Profile Adapter..... 50 |
| 11.2.6 | Connecting the Module..... 50 |
| 11.3 | Disposal..... 50 |
| 12 | Accessories..... 51 |
| 12.1 | General Information..... 51 |
| 12.2 | Assembled S-BUS Cables..... 51 |
| 12.3 | Ready-Made Supply Cables..... 51 |
| 12.4 | Carrier Rail Adapter, Profile Adapter and Spacer..... 52 |
| 12.5 | End Clamp..... 53 |
| 12.6 | Protective Caps..... 53 |
| 12.7 | Module Labeling Strips..... 53 |
| 13 | Appendix..... 55 |
| 13.1 | Diagnostic Information..... 55 |
| 14 | Service and support..... 57 |
| | Index..... 59 |

1 About this Documentation

1.1 General Information

Read this chapter thoroughly before using the application description.

1.2 Scope

The present documentation applies to the digital output module S67-DO8-HS-M12 of the IndraControl S67 series.

For other components of the IndraControl S67 series, the following documentations are available:

| Document | Title | Parts number |
|-----------------------------|---|--------------|
| Module-comprehensive | | |
| Application Description | Rexroth IndraControl S67 | R911329572 |
| Application Description | Rexroth IndraControl S67 DTM Input and Output Modules | R911340954 |
| Field Bus Couplers | | |
| Application Description | Rexroth IndraControl S67 Ethernet/IP Coupler 8 Digital Inputs (M8) | R911329564 |
| Application Description | Rexroth IndraControl S67 Profibus Coupler 8 Digital Inputs (M8) | R911329566 |
| Application Description | Rexroth IndraControl S67 Profinet Coupler 8 Digital Inputs (M8) | R911329568 |
| Application Description | Rexroth IndraControl S67 sercos Coupler 8 Digital Inputs (M8) | R911338401 |
| Modules | | |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Outputs – 0.5 A (8×M8) | R911329560 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Outputs – 2.0 A (8×M8) | R911329562 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Outputs – 0.5 A (4×M12) | R911329556 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Outputs – 2.0 A (4×M12) | R911329558 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Outputs – 0.5 A (8×M12) | R911342196 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Inputs (8×M8) | R911329552 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Inputs (4×M12) | R911329550 |
| Application Description | Rexroth IndraControl S67 Digital Module High Speed 8 Inputs (4×M12) | R911342198 |

About this Documentation

| Document | Title | Parts number |
|-------------------------|---|--------------|
| Application Description | Rexroth IndraControl S67 Digital Module 8 Inputs (8×M12) | R911342194 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Inputs/Outputs – 0.5 A (8×M8) | R911338695 |
| Application Description | Rexroth IndraControl S67 Digital Module 8 Inputs/Outputs – 0.5 A (8×M12) | R911338697 |
| Application Description | Rexroth IndraControl S67 Digital Module High Speed 4 Inputs/Outputs – 0.2 A (4×M12) | R911342202 |
| Application Description | Rexroth IndraControl S67 Analog Module – 4 Inputs Voltage/Current (4×M12) | R911329544 |
| Application Description | Rexroth IndraControl S67 Analog Module – 4 Inputs for the RTD (4×M12) | R911329542 |
| Application Description | Rexroth IndraControl S67 Analog Module – 4 Inputs TC Temperature Sensors (4×M12) | R911338699 |
| Application Description | Rexroth IndraControl S67 Analog Module – 4 Outputs Voltage/Current (4×M12) | R911329546 |
| Application Description | Rexroth IndraControl S67 Universal Interface Module - 4 Inputs/Outputs – 0.5 A (M12) | R911339361 |
| Application Description | Rexroth IndraControl S67 HTL Encoder, Counter Module 4 Digital Inputs/Outputs (4×M12) | R911342204 |
| Application Description | Rexroth IndraControl S67 TTL, SSI Encoder Module 4 Digital Inputs/Outputs (4×M12) | R911342206 |
| Application Description | Rexroth IndraControl S67 Power Divider (6×M12) | R911329570 |

Tab. 1-1: Overview on the IndraControl S67 manuals

1.3 Validity of the Documentation

Overview on target groups and product phases

In the following illustration, the framed activities, product phases and target groups refer to the present documentation.

Example: In the product phase "Mounting (assembly/installation)", the target group "Mechanic/electrician" can execute the activity "Unpack, Mount and Install" using this documentation.

About this Documentation




Fig. 1-1: Assigning this documentation to the target groups, product phases and target group activities

Purpose This documentation is intended for users commissioning a digital output module of type S67-DO8-HS-M12. This documentation contains general information on the output module. Mounting and cabling of the output module are also described. The basic commissioning steps and the configuration of the IndraControl S67 station are then explained.

1.4 Structuring the Documentation

The first part of the documentation contains important information on the intended use as well as information on the safety instructions ([chapter 2 "Important Instructions on Use"](#) on page 9 and [chapter 3 "Using the Safety Instructions"](#) on page 11).

For a short overview on the structure and the functions of the digital output module, refer to [chapter 4 "Device Description"](#) on page 13.

For information on mounting, refer to [chapter 5 "Mounting the Module"](#) on page 23.

For information on data and supply cables, refer to [chapter 6 "Connecting Data and Supply Cable"](#) on page 31.

For information on the commissioning, refer to [chapter 7 "Commissioning"](#) on page 37.

For information on the process images of the digital output module, refer to [chapter 8 "Process Images"](#) on page 39.

For the parameterization, refer to [chapter 9 "Parameterization"](#) on page 41.

For the diagnostic options regarding the digital output module, refer to [chapter 10 "Diagnostics via LED Signals"](#) on page 45.

For information on the module exchange, refer to [chapter 11 "Maintenance and Service"](#) on page 49.

For information on the accessories for the digital output module, refer to [chapter 12 "Accessories"](#) on page 51.

For diagnostic information, refer to [chapter 13 "Appendix"](#) on page 55.

For information on the customer service help desk of Bosch Rexroth, refer to [chapter 14 "Service and support"](#) on page 57.

About this Documentation

1.5 Terms and Abbreviations

| Term | Explanation |
|------------|---|
| CE | The CE marking (Conformité Européenne) is used by the manufacturer or EU importer according to the EU regulation 765/2008 and "indicates that the product complies with the applicable requirements specified in the Community harmonization legislation provided for its affixing" |
| UL | Underwriters Laboratories Inc., US organization for electrotechnical product certification |
| CSA | Canadian Standards Association. The CSA develops and maintains more than 3000 standards and regulations related to safety, design or performance |
| NEMA | National Electrical Manufacturers. The NEMA constitutes the representation of interests as well as the professional organization of the electrotechnical industry of North America |
| IndraWorks | Configuration and commissioning tool developed by Bosch Rexroth |
| GSD | Device master data (contains characteristic communication features of a Profibus device as electronic device data sheet) |
| SDDML | sercos Device Description Markup Language XML-based device description language for sercos III devices |
| VPE | Packaging unit |

Tab. 1-2: Terms and abbreviations

1.6 Customer Feedback

Customer requests, comments or suggestions for improvement are of great importance to us. Please email your feedback on the documentations to Feedback.Documentation@boschrexroth.de. Directly insert comments in the electronic PDF document and send the PDF file to Bosch Rexroth.

2 Important Instructions on Use

2.1 Intended Use

2.1.1 Introduction

The Rexroth products represent state-of-the-art developments and manufacturing. The products are tested prior to delivery to ensure operating safety and reliability.

The products may only be used for the intended purpose. If the products are not used as intended, situations causing personal injury as well as material damage can occur.



Rexroth shall not be liable for damages resulting from unintended use. In such cases, the guarantee and the right to payment of damages resulting from unintended use are forfeited. The user alone carries all responsibility of the risks.

Before using Bosch Rexroth products, the following requirements must be met to ensure intended use of the products:

- Personnel who in any way, shape, form or use one of our products must first read and understand the relevant safety instructions and be familiar with the intended use of the products
- If the product takes the form of hardware, then the products remain in the original state, in other words, no structural changes to the products are permitted. The decompilation of software products or the alteration of source codes is not permitted
- Do not install or operate damaged or faulty products
- Ensure that the products have been installed in the manner described in the relevant documentation

2.1.2 Use and Application Cases

The S67-DO8-HS-M12 module emits digital signals that are specified by a higher-level controller (e.g., a programmable coupler).

The S67-DO8-HS-M12 module cannot be used to control safety purpose function, i.e., the S67-DO8-HS-M12 module cannot be a functional component of a safety function.

The S67-DO8-HS-M12 module shall only be used in combination with a field bus coupler and I/O module of the IndraControl S67 series.

The S67-DO8-HS-M12 module was developed for applications requiring IP 67 (NEMA type 6, 6P) degree of protection.



The S67-DO8-HS-M12 module may only be used with the accessories and mounting parts listed in this documentation. Components that are not expressly mentioned must neither be attached nor connected. The same is valid for cables and lines.

Operation may only be carried out with the hardware component configurations and combinations that are expressly specified and with the software and firmware indicated and specified in the respective documentation and functional descriptions.

In case of non-compliance, the guarantee and warranty claims shall automatically expire.

Important Instructions on Use

The S67-DO8-HS-M12 may only be operated under the mounting and installation conditions, the position, and the ambient conditions (temperature, degree of protection, humidity, EMC, etc.) specified in the related documentation.

2.2 Safety Devices

All IndraControl S67 series products are designed to meet the requirements of IP 67. This includes complete protection against accidental contact with electrical voltage and currents – even when wet.

2.3 Information about the Operation

To integrate the IndraControl S67 components in your machine or system, the following valid and applicable standards, guidelines and provisions have to be complied with: e.g., BGV A 3, "Electrical Systems and Equipment", DIN EN 418, EN 60204. The emergency stop equipment shall remain effective in all operating modes of the system and machine.

For protection from electromagnetic interferences:

- Connect your system to protective earth (PE), and
- ensure that the cable routing and the installation of the field bus cable, S-BUS cable, supply cable, and sensor cable are correct

The following elements for 24V supply have to be available:

- Outer lightning protection on buildings
- Inner lightning protection of supply lines and signal lines
- Safe electrical separation of undervoltage 24VDC through PELV (Protective Extra Low Voltage) or SELV (Safety Extra Low Voltage) voltage sources.

2.4 Unintended Use

The use of the S67-DO8-HS-M12 module in applications other than the modules specified or described in the documentation and the technical specifications is considered as "unintended".

The S67-DO8-HS-M12 module must not be used if

- operation conditions which do not correspond to the specified ambient conditions Operation under water, extreme temperature fluctuations or extreme maximum temperatures is prohibited
- they are used in household devices or devices belonging to categories 1 to 7 and 10 specified in Appendix IA of the Directive 2002/96/EC ("WEEE")

3 Using the Safety Instructions

3.1 Structure of the Safety Instructions

The safety instructions are structured as follows:




Fig. 3-1: Structure of the safety instructions

3.2 Explaining Signal Words and Safety Alert Symbol

The safety instructions in this documentation contain specific signal words (danger, warning, caution, notice) and, if necessary, a safety alert symbol (according to ANSI Z535.6-2006).

The signal word is meant to draw the reader's attention to the safety instruction and signifies the degree of danger.

The safety alert symbol (a triangle with an exclamation point), which precedes the signal words danger, warning and caution is used to alert the reader to personal injury hazards.

-
- ⚠ DANGER**
- In case of non-compliance with this safety instruction, death or serious injury **will** occur.
-
- ⚠ WARNING**
- In case of non-compliance with this safety instruction, death or serious injury **can** occur.
-
- ⚠ CAUTION**
- In case of non-compliance with this safety instruction, minor or moderate injury **could** occur.
-
- NOTICE**
- In case of non-compliance with this safety instruction, property damage **could** occur.
-

Using the Safety Instructions

3.3 Symbols Used

Pointers are displayed as follows:



This is a note.

Tips are displayed as follows:



This is a tip.

4 Device Description

4.1 General Information

The digital output module S67-DO8-HS-M12 outputs the binary signals with short response times. The module is characterized by very fast high-speed outputs and is therefore particularly well-suited for using with fast Ethernet-based field buses (e.g. sercos). The module features comprehensive parameterization options for the individual channels and the entire module. The module settings are set, depending on the field bus, using the device description file (e.g. GSD, SDDML, etc.) of a field bus or independent of the field bus via a FDT/DTM border application (e.g. IndraWorks).



Detailed information on setting the module parameters using the field bus is in the corresponding manual (e.g. "Rexroth IndraControl S67 Profibus Coupler 8 Digital Inputs (M8)").



Detailed information about the properties of the S67-DO8-HS-M12 module is in [chapter 4.9 "Technical Data" on page 18](#).

4.2 Connections




Fig. 4-1: Identification of the module connections

Device Description

| Position | Description | Function |
|----------|--|--|
| 1 | S-BUS input M12 connector, B-coded | For transmitting data of the previous IndraControl S67 component |
| 2 | S-BUS output M12 socket, B-coded | For transmitting S-BUS data to the next IndraControl S67 component or to the S-BUS terminator. |
| 3 | Digital outputs X1 – X4 (assigned twice) M12 socket, A-coded | To connect digital actuators |
| 4 | Power supply output M12 socket, A-coded | To provide logic and/or sensor power supply and/or actuator supply for the next I/O module |
| 5 | Power supply input M12 socket, A-coded | Feeding of U_{LS} (logic and sensor voltage) and U_A (actuator voltage) |

Tab. 4-1: Identification of the module connections

4.3 Labeling Options and Mounting




Fig. 4-2: Identifying the options for labeling and mounting

| Position | Description | Function |
|----------|---------------------|--|
| 10 | Module legend plate | Identifying the module in a field bus node |
| 11 | Mounting holes | Mounting and grounding of the module using M4 screws |
| 12 | Labeling strips | Labeling connections |

Tab. 4-2: Identifying the options for labeling and mounting

4.4 Display Elements




Fig. 4-3: Labeling the module LEDs

| Position | LED | Color | Meaning |
|----------|-----------------|------------------|-----------------------------------|
| 15 | SB | Green/red/orange | S-BUS status |
| 16 | F | Red | Diagnostic information |
| 17 | 0 to 7 | Yellow/red | Signal status of the outputs |
| 18 | U _A | Green | Actuator supply available |
| 19 | U _{LS} | Green | Logic and sensor supply available |

Tab. 4-3: Labeling the module LEDs

Detailed information can be found in [chapter 10 "Diagnostics via LED Signals"](#) on page 45.

Device Description

4.5 Labeling and Bar Code Type at the Back of the Device





Fig. 4-4: Labeling and bar code type

| Position | Description |
|----------|--|
| 30 | Manufacturer's address |
| 31 | S-BUS pin assignment |
| 32 | Connection assignment of digital outputs |
| 33 | Pin example |
| 34 | Pin assignment of supply input and output |
| 35 | Information about licenses and CE mark |
| 36 | Current consumption and voltage specifications |
| 37 | Module description |

Tab. 4-4: Labeling and bar code type

4.6 Type Plate

A label is attached to the side of the module. This label contains important information for tracing in case of claims or complaints:



- ① Type-code
- ② Parts number
- ③ Technical index
- ④ Manufacturing date
- ⑤ Serial number

Fig. 4-5: Type plate

4.7 Schematic Circuit Diagram

The following schematic circuit diagram gives an overview about the power supply and the mode of operation of power supply connections as well as the digital module outputs (see also [chapter 6.4 "Supply Cable Connection" on page 33](#) and [chapter 6.5 "Connecting the Actuator cable" on page 35](#)).

Please note that the mutual field supply of the actuators is distributed to all module connections (X1 – X4, each pin 1).




Fig. 4-6: Schematic circuit diagram

Device Description

4.8 Dimensions




Fig. 4-7: Module dimensions in millimeters

4.9 Technical Data

4.9.1 Device Data

| | |
|---------------------------|-----------------|
| Dimensions (mm) B × H × T | 50 × 117 × 35,7 |
| Weight | Ca. 9.17 oz |

Tab. 4-5: Device data

4.9.2 Module Supply

| | |
|---|--|
| Type of connection | 2 M12 connectors, A-coded, 4-pin [Ⓞ] |
| Current-carrying capacity of the power supply connections | Maximum: 8 A (U _{LS} : 4 A, U _A : 4 A) |

Device Description

| | |
|--|--|
| Supply voltage Logic and sensor voltage U_{LS} U_A actuator supply | DC 24 V (-25 % ... +30 %) DC 24 V (-25 % ... +30 %) |
| Power supply input currents Logic and sensor voltage I_{LS} Actuator current I_A | Typically 40 mA (logic component only) Typically 35 mA + actuator supply (≤ 1 A) + load |
| Protection function | Reverse polarity protection for $U_{LS} + U_A$ Short circuit protection for actuator supply V_A |

⊕ Derating has to be complied with

Tab. 4-6: *Module power supply*

4.9.3 Communication

| | |
|------------------|--|
| S-BUS connection | 2 Shielded M12 connectors, B-coded, 5-pin |
|------------------|--|

Tab. 4-7: *Communication*

4.9.4 Digital Outputs

| | |
|--|---|
| Number of outputs | 8 (0 ... 7) |
| Type of connection | 4 Shielded M12 connectors, A-coded, 5-pin, assigned twice |
| Wiring technique | 2- to 3-wire |
| Output voltage | $\leq U_A$ |
| Output current (per channel) | 0.1 A short circuit and overload withstand capability (thermal deactivation) |
| Voltage drop against U_A at nominal load | Maximum 1.7 V DC |
| Output current (all channels) | Max. 0.8 A |
| Leakage current when switched off | Typically 50 μ A |
| Output circuit | Push/Pull |

Tab. 4-8: *Digital outputs*

4.9.5 Specification for Actuator Selection

| | |
|--|----------------------------------|
| Front-end throughput time 0 ... 90 % (Hardware) | Max. 0.5 μ s |
| Edge steepness $T_{ON/OFF}$ | Typically < 0.2 μ s |
| Front-end jitter/skew | < 0.2 μ s |
| Cable length, shielded | ≤ 30 m |
| Load type | Inductive, ohmic loads and lamps |

Device Description

| | |
|----------------------------|---|
| Switching frequency | Inductive load: on request Ohmic load: on request Lamp load: on request |
| Type of protective circuit | External protection (e.g., recovery diodes) |

Tab. 4-9: Information on selecting the actuator

4.9.6 Influence of Operating States to the Output

| | |
|--|-----------------------------------|
| CPU stop of PLC | Acc. to substitute value strategy |
| Interruption of the field bus | Acc. to substitute value strategy |
| Interruption of the S-BUS | 0 V status |
| Supply voltage under rated voltage tolerance | 0 V status |
| Disconnection of the supply voltage | 0 V status |
| Procedure of output | Non-storing |
| Behavior in case of overload | Automatic reboot |

Tab. 4-10: Influence of operating states on output

4.9.7 Electrical Isolation

| | |
|--------------------------|---------------|
| Channel - Channel | No |
| U_{LS} , U_A , S-BUS | DC 500 V each |

Tab. 4-11: Electrical isolation

4.9.8 Parameterizable Functions

| | |
|---|---|
| Substitute value strategy (per channel) | Switch substitute value/hold last value |
| Substitute value (per channel) | 0/1 |
| Diagnostics (per channel/per module) | Lock/unlock |

Tab. 4-12: Parameterizable functions

4.9.9 Diagnostic I/O

| | |
|-------------|--|
| Per channel | Actuator overtemperature (short circuit, overload or overtemperature of the output driver) |
| Per module | Undervoltage ($U_{LS} + U_A$) |

Tab. 4-13: Diagnostic I/O

4.9.10 Process Image

| | |
|--------------------|----------------------|
| Process data width | 1 byte data + status |
|--------------------|----------------------|



Tab. 4-14: Process image

4.9.11 Displays

| | |
|---------------------------------------|--|
| 0 ... 7: Signal status of the outputs | LED (yellow= signal status/red= diagnostics) |
| F: Error status | LED (red) |
| $U_{LS} + U_A$: Supply status | LED (green) |
| SB: S-BUS status | LED (green/red/orange) |
| Display | Non-storing |

Tab. 4-15: *Display*

4.9.12 Standards and Approvals

| | |
|---|---------------------------------------|
| UL/CSA  | UL 508 (Industrial Control Equipment) |
| | C22.2 No. 14-95 (CSA) |
| | UL file no. E210730 |
| Conformity marking  | CE |

Tab. 4-16: *Standards and approvals*

5 Mounting the Module

5.1 General Information

The S67-DO8-HS-M12 module can be fastened directly to the system using screws. It can also be mounted on a mounting rail using an adapter or fastened to a profile rail using a mounting profile.

For mounting on a flat surface, Bosch Rexroth offers spacers as mounting aid; the spacers can be inserted between the IndraControl S67 components. This helps by providing sufficient mounting distance for compact direct mounting, as well as eliminating gaps where dirt could accumulate. A cable tie can be fastened through each of two eyebolts in the spacer, which together serve as strain relieve from the actuator cables.

5.2 Mounting Notes

The following information shall always be observed:

- Disconnect the power supply from the system before starting the installation.
- The maximum drilling hole diameter for the fastening holes of the field bus coupler must not exceed 4 mm. Otherwise, there may be no full contact with the PE socket of the S67-DO8-HS-M12 module and correct shielding is not possible.
- To protect the S67-DO8-HS-M12 module from tensile forces that may arise, do not bridge spaces with the module
- Screw the S67-DO8-HS-M12 module down only on flat contact surfaces to protect the module from warping
- Ensure that the connectors are not soiled during mounting. Dirt damages the contacts, which can cause corrosion in these areas
- To avoid damaging the S67-DO8-HS-M12 module, do not mount the module in shear areas of moving devices.
- Provide sufficient potential equalization in the system
- Use all fastening holes to mount the S67-DO8-HS-M12 module to the system so that all FE connections lie on a ground potential.

5.3 Required Tools and Accessories for Mounting

Depending on the mounting type, the following tools are required for installation:

- A screwdriver for M4 fastening screws
- Drilling machine to pre-drill the fastening holes for mounting on the system for the S67-DO8-HS-M12 module and, if required for the imperforated mounting rails
- M4 thread cutter (bottoming tap or hand tap set)

The Bosch Rexroth accessories listed below are required for mounting. The associated order numbers are listed in [chapter 12 "Accessories" on page 51](#).

- Mounting rail adapter including fastening screws and perforated or non-perforated mounting rails (TS 35 x 7.5 rail) according to EN 60715
or
- Profile adapter, including fastening screws

Mounting the Module

- Spacer (optional)

Two M4x12 screws are required for direct mounting of the S67-DO8-HS-M12 module. The length of the screw shaft is to be selected according to the fastening type.

Bore dimensions

When fastening the IndraControl S67 component without a threaded hole, the clearance hole must not be wider than 4 mm to ensure a safe contact of the FE (functional earth ground) connections.

5.4 Direct Mounting to the System

Mount the S67-DO8-HS-M12 module without using Bosch Rexroth accessories directly on a flat surface of the system. For direct mounting of the module proceed as follows:

1. Disconnect the power supply from those devices on which you wish to mount the S67-DO8-HS-M12 module.
2. Mark the drilling holes. For this, use the drilling template printed on the packaging. Alternatively, hold the S67-DO8-HS-M12 module in the desired position and mark the drill holes. Ensure that there is sufficient space around the IndraControl S67 series component so that all cables can be connected without problems.



We recommend the use of Bosch Rexroth spacers for compact direct mounting. If these spacers are used, the additional distance from the second IndraControl S67 component must be observed (see [chapter 5.8 "Mounting the Spacer in Case of Compact Arrangement"](#) on page 28).

3. Fasten the S67-DO8-HS-M12 module with the M4x12 screws via the two fastening holes.




Fig. 5-1: Mounting the module at a grounded frame of the system or another earth connection point

5.5 Mounting on Carrier Rail (only with Bosch Rexroth Accessories)

5.5.1 Fastening Carrier Rail Adapter on the Module

A mounting rail adapter is required to mount the S67-DO8-HS-M12 module on mounting rails.

Mounting the Module

Screw together the S67-DO8-HS-M12 module and the mounting rail adapter using the M4 threaded screws provided, as shown in the figure below.




Fig. 5-2: Mounting on the mounting rail adapter

5.5.2 Fastening the Module with Mounting Rail Adapter to a Mounting Rail

In order to keep a clear representation, the mounting rail adapter in the figure below is shown without the S67-DO8-HS-M12 module.

When mounting the S67-DO8-HS-M12 module to a mounting rail (35 x 7.5 rail) using a mounting rail adapter, proceed as follows:

1. Disconnect the power supply from those devices on which you wish to mount the S67-DO8-HS-M12 module.
2. Set the S67-DO8-HS-M12 module onto the edge of the mounting rail (51) with the two notches (50).
3. Press the bottom side against the lower mounting rail edge until the latch (52) locks in place.



For vertical mounting of the mounting rail or when vibrations or shock occur, the end clamp SUP-M01 or SUP-M01-AL are to be used for stabilization (see [chapter 12.5 "End Clamp" on page 53](#)).

Mounting the Module




Fig. 5-3: Mounting the mounting rail adapter

5.6 Mounting on Profile Rail (only with Bosch Rexroth Accessories)

5.6.1 Fastening Profile Adapter on the Module

In addition to the attachment using a mounting rail adapter, the S67-DO8-HS-M12 module can be fastened to a profile rail using a profile adapter and nuts. It is required that the system supports this attachment type. The nuts are not included in the scope of delivery.

Screw together the S67-DO8-HS-M12 module and the profile adapter using the M4 threaded screws provided, as shown in the figure below.




Fig. 5-4: Attaching to a profile adapter

5.6.2 Fastening the Module with Profile Adapter on Profile Rail

To fasten the S67-DO8-HS-M12 module to a profile rail of the system, two nuts are required with one screw each (length of screw threads must be compatible with the system).

1. Disconnect the power supply from those devices on which you wish to mount the S67-DO8-HS-M12 module.
2. Insert the two screws into the holes above and beneath the fastened S67-DO8-HS-M12 module on the profile adapter.
3. Fasten an appropriate nut on each of these screws.
4. Insert the profile adapter with the attached S67-DO8-HS-M12 module into the profile rail of the system. Position the profile adapter and tighten the screws.

5.7 Replacing the Labeling Fields

The module labeling card and labeling strip are attached ex works. The protective cover is to be removed when labeling the labeling strip. Proceed as follows:

1. Press the slot screwdriver (maximum slot width: 3 mm) into the small opening under the labeling strip cover (12) and lever the cover up.
2. Remove the labeling strip cover.
3. Label the labeling strip with a waterproof pen.
4. Reinsert the labeling strip cover and press the cover firmly in place.

If the module labeling card (10) is to be replaced, proceed in accordance with the step sequence described previously. New module labeling cards are available from Bosch Rexroth as accessories.




Fig. 5-5: Replacing the labeling fields

Mounting the Module

5.8 Mounting the Spacer in Case of Compact Arrangement

By using the spacer, a sufficient mounting distance can be achieved when directly mounting the IndraControl S67 components, and gaps can be eliminated where otherwise dirt and other substances could accumulate. In addition, it is possible to optimize the cable routing of the actuators. For this purpose, two fastening lugs each are included on the spacer for cable ties.

1. Disconnect the power supply from those devices on which you wish to mount the S67-DO8-HS-M12 module.
2. To prevent the IndraControl S67 components from falling out when it is mounted overhead, the spacer can only be moved in the designated openings of the S67-DO8-HS-M12 module from below. To bind both components, place the S67-DO8-HS-M12 module on the spacer for this reason or push the spacer from the bottom into the S67-DO8-HS-M12 module.
3. Fasten the attached components on a flat surface by fastening the S67-DO8-HS-M12 module to the grounded border of your system or to another grounding point with two M4 screws via the mounting holes.




Fig. 5-6: Attaching a spacer on a module

4. When attaching further IndraControl S67 components, only one IndraControl S67 component connected with a spacer can be attached and screwed to the preceding component due to the mounting direction. The last IndraControl S67 component is fastened without a spacer.

Mounting the Module




Fig. 5-7: Attaching a further module with spacer

6 Connecting Data and Supply Cable

6.1 Notes

⚠ WARNING**Voltage!**

Operate the IndraControl S67 components exclusively with DC 24 V PELV (Protective Extra Low Voltage) or SELV (Safety Extra Low Voltage) voltage sources. Failure to comply may result in electric shock.

NOTICE**The highest current carrying capacity of the supply contacts is 4 A!**

Always observe the maximum current carrying capacity per supply line (U_{LS} , U_A) as well as the total current consumption for all IndraControl S67 components. The value must not exceed 4 A since an increase in current causes the contacts to overheat and damages the IndraControl S67 components.

NOTICE**Exposed connections!**

If connections have not been closed with protective caps, liquid or dirt can penetrate the S67-DO8-HS-M12 and destroy the module. Protect all non-required connection with protective caps to comply with protection class IP 67.

- The connectors must be disconnected from the power supply when screws are tightened.
- Tighten the connectors only by hand. Using mechanical tools can cause the threads to strip. In this case, the S67-DO8-HS-M12 module has to be exchanged

Tightening torques for connectors are:

- Actuator connections, M12: 0.6 Nm
- S-BUS and supply connections, M12: 0.6 Nm
- Check the exact positioning (coding) between plug and socket
- Use only ready-made Bosch Rexroth system cables for transmission of the power supply and for the S-BUS. This is the only way to achieve the specified values of technical data.
- Keep sufficient distance of the cables from electromagnetic sources of interference in order to maintain a high noise immunity of the IndraControl S67 system against electromagnetic emissions.
- Observe the minimum bending radius of Bosch Rexroth system cables, see [chapter 12 "Accessories" on page 51](#).
- When laying the cables, ensure not to lay the cables in shear areas of moving machine parts.
- Ensure the correct layout of the potential equalization.
- Do not use drop lines under any circumstances as otherwise increased line reflections and signal distortions arise. This would significantly impair the transmission properties.

Connecting Data and Supply Cable

6.2 Required Accessories

The Bosch Rexroth accessory components listed below are required for connecting the data and supply cable. The corresponding order numbers are listed in [chapter 12 "Accessories" on page 51](#).

- S-BUS M12 terminator, IP 67 degree of protection
- S-BUS and supply cables, ready-made on both ends, IP 67
- Protective caps



6.3 S-BUS Connection

The S-BUS is used for communication between a field bus coupler and the connected IndraControl S67 components.

Requirement

- A Bosch Rexroth S-BUS cable ready-made on both ends is available, which is necessary for optimal signal transmission.
- The S-BUS terminator is available, which is necessary for communication.

The following table outlines the assignment of the S-BUS connections:

| Connection | | Contact | Description | |
|---|---|----------|-------------|-----|
| | | | IN | OUT |
|  |  | 1 | RD+ | TD+ |
| | | 2 | RD- | TD- |
| | | 3 | TD- | RD- |
| | | 4 | TD+ | RD+ |
| | | 5 | 0 V DC | |
| Connection thread | | Shielded | | |

Tab. 6-1: S-BUS: Pin assignment

To connect the S-BUS cable to the field bus coupler and to the modules, proceed as follows:

1. Disconnect the power supply from those devices on which you have mounted the S67-DO8-HS-M12 module.
2. Connect the S-BUS cable (S1) to the OUT connection ⚡ (3) of the field bus coupler and the IN connection ⚡ (1) of the S67-DO8-HS-M12 module. For example, if two modules have been connected to the field bus coupler, connect the S-BUS cables (S1, S2) to the associated IN and OUT connections, as shown in the figure below.
3. Tighten the plugs and sockets using the knurled-head screw.
4. Attach the S-BUS terminator (T) to the last module as shown in the figure and tighten the S-BUS terminator.

Connecting Data and Supply Cable




Fig. 6-1: S-BUS connected to field bus coupler and I/O modules

6.4 Supply Cable Connection

The supply cable is used to supply the S67-DO8-HS-M12 module.

Requirement

Bosch Rexroth supply cables, ready-made on both ends (K1 and K2 in fig. 6-3 "Supply cable connected to field bus coupler and I/O modules" on page 35).

The following table outlines the assignment of the supply connections:

| Connection | | Contact | Description |
|------------|--|---------|------------------|
| | | 1 | 24 V DC U_{LS} |
| | | 2 | 24 V DC U_A |
| | | 3 | 0 V U_{LS} |
| | | 4 | 0 V U_A |

Tab. 6-2: Supply connection: Pin assignment

Contact assignment of the supply cable assembled on one end (view on socket):

| Connection | Contact | Description | Cable strand color |
|------------|---------|------------------|--------------------|
| | 1 | 24 V DC U_{LS} | Brown |
| | 2 | 24 V DC U_A | White |
| | 3 | 0 V U_{LS} | Blue |
| | 4 | 0 V U_A | Black |

Tab. 6-3: Supply cable assembled on one end: Contact assignment

Connecting Data and Supply Cable




Fig. 6-2: Supply cable assembled on one end

NOTICE

The highest current carrying capacity of the supply contacts is 4 A!

Always observe the maximum current carrying capacity per supply line (U_{LS} , U_A) as well as the total current consumption for all IndraControl S67 components. The value must not exceed 4 A since an increase in current causes the contacts to overheat and damages the IndraControl S67 components.

To connect the supply cable to the field bus coupler and to the modules, proceed as follows:

1. Disconnect the power supply from those devices on which you have mounted the S67-DO8-HS-M12 module.
2. Connect the power supply transmission cable (K1) to the OUT connections \ominus (9) of the field bus coupler and the IN connections \ominus (5) of the S67-DO8-HS-M12 module. For example, if two modules have been connected to the field bus coupler, connect the power supply transmission cable (K1, K2) to the associated inputs and outputs, as shown in the figure below.
3. Tighten the plugs and sockets using the knurled-head screw.
4. Screw a protective cap on all unused connections to comply with IP 67 degree of protection.

Information on connecting the power supply cable (K0) to the IN port \ominus (6) of a field bus coupler can be found in the appropriate application descriptions of the field bus coupler.

Connecting Data and Supply Cable




Fig. 6-3: Supply cable connected to field bus coupler and I/O modules

6.5 Connecting the Actuator cable

The actuator cable provides power to the connected actuators and transfers the actuator signals.

When using cables that have not been ready-made, make sure that the cables are connected to a M12 connector of IP 67 degree of protection. The following table outlines the assignment of the actuator connections:

| Connection | | Contact assignment |
|-------------------|-------------------|---|
| OUT X1, X3 | OUT X2, X4 | 1: 24 V U _A 3: 0 V U _A 5: Shield 4: Output A 2: Output B Housing: Shield |

Tab. 6-4: Digital outputs: Pin assignment

NOTICE

The highest current carrying capacity of the supply contacts is 4 A!

Ensure that the actuators from the U_A supply line are supplied with power. The actuator's power consumption must be taken into consideration when determining the current power demand for the V_A supply line.

Connecting Data and Supply Cable

NOTICE

The actuator's power consumption must not exceed 1 A!

Please note that the combined power consumption of all connected actuators must not exceed 1 A. The distribution of power among the existing connections is depending on the individual power requirements of the sensors.

To connect the actuators to the digital outputs (X1 – X4), proceed as follows:

1. Disconnect the power supply from those devices on which you have mounted the S67-DO8-HS-M12 module.
2. Insert the plug of the actuator cable into the socket of a digital output (3) of the S67-DO8-HS-M12 module, and tighten the plug using the knurled-head screw.
3. Screw a protective cap on all unused connections to comply with IP 67 degree of protection.




Fig. 6-4: Digital outputs

7 Commissioning

7.1 General Information

NOTICE**Exposed connections!**

If connections have not been closed with protective caps, liquid or dirt can penetrate the S67-DO8-HS-M12 and destroy the module. Protect all non-required connection with protective caps to comply with protection class IP 67.

Before starting up the IndraControl 767 station, make sure that:

- a field bus coupler of the IndraControl S67 series¹⁾ and the S67-DO8-HS-M12 module are correctly mounted
- all required supply, sensor or actuator and S-BUS connections as well as the S-BUS connection are screwed tightly at the provided connections (see [chapter 6 "Connecting Data and Supply Cable" on page 31](#))
- an appropriate potential equalization is executed at the system
- and the shielding is carried out correctly

¹⁾ See field bus coupler application descriptions (IndraControl S67)

8 Process Images

8.1 General Information

The process images of the module contained in the following chapters describe the data position on the S-BUS. The field bus coupler application manual describes the conversion of the S-BUS process images to the respective field bus process images.

The process image is divided into two areas: An area for output data and an area for input data. The process image can contain process data with or without diagnostic information, depending on whether the transmission of the synchronous¹⁾ diagnostic information has been activated. The diagnostic information can only be activated by means of a field bus coupler as the coupler supports the function of the synchronous diagnostic (e.g. S67-PB-BK-DI8-M8). Detailed information about activating the transmission of diagnostic information is contained in the application manual of the field bus coupler in the device description file chapter.



Synchronous diagnostics is disabled in the module in its delivery status.

Detailed information can be found starting in [chapter 9 "Parameterization"](#) on page 41.



Diagnosis:"overtemperature"

The "overtemperature" diagnosis of the outputs is only possible when the output is switched on.

8.2 Output Data

The process image for the process data that is sent from the field bus coupler to the S67-DO8-HS-M12 module has a size of 1 byte. If a synchronous diagnostic confirmation is parameterized for the module, the process image size is 3 byte.

The process data and the diagnostic confirmation are structured as follows:

¹⁾ *Synchronous diagnostic information specifies the cyclic diagnostic information transfer in the process image. By default, the cyclic diagnostic information transfer in the process image is disabled in the module.*

Process Images




Fig. 8-1: Process image, output data

8.3 Input Data

The process image for the process data that is sent from the field bus coupler to the S67-DO8-HS-M12 module has a size of 0 byte. If synchronous diagnostic data is parameterized for the module, the process image size is 2 bytes.

The byte configuration is as follow:




Fig. 8-2: Process image, input data

9 Parameterization

9.1 General Information

According to the field bus type only certain parameters are available for parameterization. Further information can be found in the respecting documentation of the field bus coupler.

⚠ WARNING**Changing parameters!**

When parameters are changed incorrectly, machine components can be placed in a dangerous state and endanger persons and machines. Before changing the parameters, ensure that the machine components are in a safe and defined state and switch off the higher-level controller. Ensure before start-up that no persons remain in the danger area of the machine components.

For parameterization with IndraWorks, set the operating settings of the S67-DO8-HS-M12 module, e.g. the behavior in the event of failures, the release of diagnostic messages etc.

The operating settings are transmitted via parameter telegram to the S67-DO8-HS-M12 module operated at the S-BUS.

The parameters of the S67-DO8-HS-M12 module are set in IndraWorks. By double-clicking the S67-DO8-HS-M12 module in the project explorer, the parameterization user interface is opened in the workspace. The S67-DO8-HS-M12 module is parameterized offline. The offline mode enables the parameterization of an S67-DO8-HS-M12 module that is not yet present. Firstly, the set parameters are saved in the project. The parameter data is transmitted during the download of the PLC program.

9.2 Diagnostic Overview

The S67-DO8-HS-M12 module supports module-comprehensive and channel-specific diagnostics. The transmission of diagnostics can be activated and deactivated. If diagnostics is deactivated, the display behavior of the LED(s), which signalize(s) the respective diagnostics, changes. For further information please refer to [chapter 10 "Diagnostics via LED Signals" on page 45](#).

Diagnostic messages of the S67-DO8-HS-M12 module are specified according to the following tables:

Parameterization

| Global diagnostics | Description |
|-----------------------|--|
| Undervoltage U_{LS} | <p>⚠ WARNING</p> <p>Disabling the outputs. In case of an undervoltage of U_A and/or U_{LS}, the module outputs are disabled. Machine components can be set to a dangerous state and endanger personnel as well as the machine.</p> <p>If there is an undervoltage at the module of the logic and sensor supply ($U_{LS} < 18\text{ V}$), the outputs are disabled and a diagnostics is sent to the field bus coupler. The F-LED of the module lights up</p> |
| Undervoltage U_A | <p>⚠ WARNING</p> <p>Disabling the outputs. In case of an undervoltage of U_A and/or U_{LS}, the module outputs are disabled. Machine components can be set to a dangerous state and endanger personnel as well as the machine.</p> <p>If there is an undervoltage of the actuator supply at the module ($U_A < 18\text{ V}$), the outputs are disabled and a diagnostics is sent to the field bus coupler. The F-LED of the module lights up</p> |

Tab. 9-1: Global diagnostics of the module

| Channel diagnostics | Description |
|---------------------|--|
| Overheating | The module detected excess temperature at the corresponding channel (only active in case of an active actuator output) The causes may include: overtemperature load or short circuit or overload of the output level |

Tab. 9-2: Channel diagnostics of the module



When interrupting an S-BUS, the S67-DO8-HS-M12 module is automatically set to STOP. The module outputs are disabled.

9.3 Input Parameters

An overview of the parameters that can be set for the digital output is given in the following table.

| Parameter | Description |
|---------------------------|--|
| Diagnostics | The channel-related diagnostics can be enabled/disabled here (for more information, see tab. 9-2 "Channel diagnostics of the module" on page 42): - lock ^① - unlock |
| Substitute value strategy | The substitute value strategy outputs the substitute value or the last valid output value, e.g. in case a field bus is interrupted. The following options are available: - Activate the substitute value ^① - Retain last value ^② |
| Substitute value | Enter here the process value that is released in case of an error or if a field bus is missing. In the case of an error (e.g. field bus interruption), this value is used with the "Switch to Substitute Value" substitute value strategy. - 0 ^① - 1 |

① Delivery status

② The last value is a value that is reported at the contact before the interference occurs. For example, this value can be a process value

Tab. 9-3: Overview of adjustable parameters for the digital outputs

9.4 Global Settings for Field Supply

If a short circuit has occurred, the field supply is switched off 1000 ms. Then the field supply is switched on again. If the short circuit condition remains, the procedure is repeated.

9.5 Automatic Storage of System Parameters

Some field bus couplers provide the "System Parameter Handling" feature. This function is used to identify changes to the configuration of the IndraControl S67 node and to the automatic parameterization of the modules. If a module is to be replaced due to a defect, the new module is not to be reconfigured anymore. The stored parameters are automatically transferred to the replaced module.

9.6 Firmware Update

During a firmware update of the S67-DO8-HS-M12 module, the stored module parameters can be overwritten. Thus, check the parameterization after a firmware update.



The firmware update can be carried out only by the Bosch Rexroth Service.

10 Diagnostics via LED Signals

10.1 General Information

For on-site diagnostics, the S67-DO8-HS-M12 module has different LEDs that display the operating state of the module and of the S-BUS.

10.2 Operating Messages of the Module

The following table lists the operating messages that are indicated via LEDs. Information regarding remedies of certain causes is also provided.




Fig. 10-1: LEDs indicating operating messages

Diagnostics via LED Signals

| Position | LED | Color/status | Cause | Remedy/Information |
|----------|-----|-------------------------------------|---|---|
| 15 | SB | Off | Low voltage U_{LS} is not present | Check the supply voltage |
| | | Red, flashing, 4 Hz | S-BUS error at the module | Check whether the S-BUS cable is connected. Check the S-BUS cable for damages. Check whether the firmware of the field bus coupler is compatible with the firmware of the module |
| | | Red, flashing, 1 or 2 Hz | The module is being restarted via the field bus coupler | If the flashing frequency is 1 Hz, please contact the Bosch Rexroth service |
| | | Green | Data exchange is executed; process data values are valid. The module is in RUN status | – |
| | | Green and orange, flashing, 1 Hz | The set substitute value is applied to the module | Can be set by the field bus coupler if field bus is missing. Check the field bus connection as well as the status of the higher-level controller |
| | | Orange, flashing, 2 Hz | The module has detected the S-BUS | – |
| | | Orange and green, flashing, 4 Hz | Detection of the last module in IndraControl S67 node is executed | Check the S-BUS terminator and/or the S-BUS wiring |
| | | Orange, flashing, 1 Hz | The field bus coupler addresses the module in the IndraControl S67 node | – |
| | | Orange and green, flashing, 2 Hz | S-BUS parameters are taken over by the field bus coupler | – |
| | | Orange | The firmware is being updated | All IndraControl S67 components are being updated by the field bus coupler within the node |
| | | Orange, flashing, 4 Hz | The module tries to establish a communication with the field bus coupler | Check the supply voltage of the upstream IndraControl S67 component and/or check the S-BUS cable for damages |
| 15 | SB | Green, flashing, 1 Hz | The module is in HOLD state | Is initiated by the field bus coupler. The last values output at the modules are retained |
| | | Green, flashing, 2 Hz | The module is in STOP state | Is initiated by the field bus coupler. "0" is returned as output value |

Tab. 10-1: Operational message 1

Diagnostics via LED Signals

| Position | LED | Color/status | Cause | Remedy/Information |
|----------|-----|--------------|---|--|
| 16 | F | Red | At least one global diagnostic message was reported at the module | Check the supply voltages U_{LS} and U_A of the upstream IndraControl S67 components |
| 17 | I/O | Yellow | Output signal active | – |
| | | Red | Error at output | Check the actuator connection for short circuits or overload |

Tab. 10-2: Operational message 2

| Position | LED | Color/status | Cause | Remedy/Information |
|----------|----------|--------------|---|--|
| 18 | U_A | Green | Actuator supply U_A available | – |
| | | Off | Actuator supply U_A not available | Connect the supply voltage and check the voltage level, if applicable. |
| 19 | U_{LS} | Green | Logic supply and sensor supply U_{LS} available | – |
| | | Off | Logic supply and sensor supply U_{LS} not available | Connect the supply voltage and check the voltage level, if applicable. |

Tab. 10-3: Operational message 3

11 Maintenance and Service

11.1 General Information

This section contains information on maintenance and service.

11.2 Replacing the Module

11.2.1 General Information

To replace a S67-DO8-HS-M12 module in the event of version change, etc., proceed as described in the following chapters.

11.2.2 Disconnecting the Wiring

Before removing the connectors, clean the S67-DO8-HS-M12 module to ensure that no dirt or other material comes in contact with the connections. This could damage the contacts.

To unplug the cables, proceed as follows:

1. Disconnect the power supply from those devices on which you have mounted the S67-DO8-HS-M12 module.

⚠ CAUTION**Hot connection sockets!**

Even when taking into account derating, high surface temperatures on the metallic connection sockets and on the enclosure can arise during operation. If the IndraControl S67 component has been in operation, allow the component to cool off before touching it.

2. Unscrew all screw connections and remove the cables.

11.2.3 Removing the Field Bus Coupler from the System

To remove the S67-DO8-HS-M12 module from the system, proceed as follows:

1. Disconnect the power supply from those devices on which you have mounted the S67-DO8-HS-M12 module.
2. Release the S67-DO8-HS-M12 module from the system by unscrewing the M4 screws.

11.2.4 Removing the Field Bus Coupler from the Carrier Plate

In order to keep a clear representation, the mounting rail adapter in the figure below (B, C) is shown without the S67-DO8-HS-M12 module.

If the S67-DO8-HS-M12 module is mounted on a mounting rail, proceed with the removal as follows:

1. Disconnect the power supply from those devices on which you have mounted the S67-DO8-HS-M12 module.
2. To remove the S67-DO8-HS-M12 module, press down the release eye-bolt of the mounting rail adapter using a slot screwdriver (B) and remove it from the rail (C).

Maintenance and Service




Fig. 11-1: Removing the module with mounting rail adapter from the mounting rail

11.2.5 Removing the Field Bus Coupler from the Profile Adapter

If the S67-DO8-HS-M12 module is mounted on a profile adapter, proceed with the removal as follows:

1. Disconnect the power supply from the device on which you have mounted the S67-DO8-HS-M12 module before beginning to remove the module.
2. Unscrew the screws on which the nuts are fastened and remove the S67-DO8-HS-M12 module from the profile rail of the system.
3. Unscrew the screws that connect the S67-DO8-HS-M12 module with the profile adapter.

11.2.6 Connecting the Module

To connect the new S67-DO8-HS-M12 module proceed as described in the following chapters:

- [chapter 5 "Mounting the Module" on page 23](#)
- [chapter 6 "Connecting Data and Supply Cable" on page 31](#)
- [chapter 7 "Commissioning" on page 37](#)

If necessary, the parameters of the previous S67-DO8-HS-M12 module are transferred to the new module, depending on the type of the field bus coupler being used (see also [chapter 9.5 "Automatic Storage of System Parameters" on page 43](#)).

11.3 Disposal

Do not dispose of the IndraControl S67 components in the household waste; observe the local applicable laws. You can also contact a certified disposal company.

12 Accessories

12.1 General Information

The most important IndraControl S67 accessory components to commission the IndraControl S67-DO8-HS-M12 module are listed.

12.2 Assembled S-BUS Cables

Cable carrier-compatible

- RKB0049: Cable carrier-compatible
- RKB0041: No cable carrier compatibility specified

Bending radius:

- Bending radius for one-time bending: At least 5 times the outer diameter

Tensile load:

- Cable, tensile load: 60 N
- Connector, tensile load: 60 N



For the connector assignment of the S-BUS connection as well as the notes on the S-BUS cable connection, refer to the chapter "Connecting Data and Supply Cables".

System bus cable, M12 female connector, M12 connector

| Ordering code | Parts number | Length |
|---------------|--------------|-----------------|
| RKB0046/000,0 | R911172581 | Variable length |

Tab. 12-1: S-BUS cable, ready-made on both sides, B-coded

| Ordering code | Parts number | Length |
|---------------|--------------|-----------------|
| RKB0041/000,2 | R911171990 | 0.2 m |
| RKB0041/000,3 | R911171991 | 0.3 m |
| RKB0041/000,5 | R911171992 | 0.5 m |
| RKB0041/001,0 | R911171993 | 1.0 m |
| RKB0041/002,0 | R911171994 | 2.0 m |
| RKB0041/005,0 | R911171995 | 5.0 m |
| RKB0041/010,0 | R911171996 | 10.0 m |
| RKB0041/000,0 | R911172579 | Variable length |

Tab. 12-2: S-BUS cable, ready-made on both sides, B-coded

System bus terminator, connector B-coded, axial

| Ordering code | Parts number |
|---------------|--------------|
| RBS0020/CNN | R911171998 |

Tab. 12-3: S-BUS terminator

12.3 Ready-Made Supply Cables

Cable carrier-compatible:

Accessories

- RKB0046: Cable carrier-compatible
- RKB0047: Cable carrier-compatible

Bending radius:

- Bending radius for one-time bending: At least 10 times the outer diameter

Tensile load:

- Cable, tensile load: 45 N
- Connector, tensile load: 45 N



The pin assignment of the supply connection is described in the chapter "Connecting Data and Supply Cables".

Voltage cable, unshielded, 4-pin, 0.75 mm², PUR M12 connector, straight, A-coded - M12 female connector, straight, A-coded

| Ordering code | Parts number | Length |
|---------------|--------------|-----------------|
| RKB0046/000,2 | R911172102 | 0.2 m |
| RKB0046/000,3 | R911172103 | 0.3 m |
| RKB0046/000,5 | R911172104 | 0.5 m |
| RKB0046/001,0 | R911172105 | 1.0 m |
| RKB0046/002,0 | R911172106 | 2.0 m |
| RKB0046/005,0 | R911172107 | 5.0 m |
| RKB0046/010,0 | R911172108 | 10.0 m |
| RKB0046/000,0 | R911172580 | Variable length |

Tab. 12-4: Supply cable, A-coded - Male and female connector

Voltage cable, unshielded, 4-pin, 0.75 mm², PUR M12 female connector, straight, A-coded - Open end

| Ordering code | Parts number | Length |
|---------------|--------------|--------|
| RKB0047/005,0 | R911172100 | 5.0 m |
| RKB0047/010,0 | R911172101 | 10.0 m |

Tab. 12-5: Supply cable, A-coded - Female connector, open end

12.4 Carrier Rail Adapter, Profile Adapter and Spacer

| Ordering code | Parts number | Brief description |
|------------------|--------------|--|
| SUP-M01-S67-0001 | R911172119 | Carrier rail adapter for field bus coupler |
| SUP-M01-S67-0002 | R911172120 | Carrier rail adapter for I/O modules and power distributor |
| SUP-M01-S67-0003 | R911172121 | Profile adapter for field bus coupler |

| Ordering code | Parts number | Brief description |
|------------------|--------------|---|
| SUP-M01-S67-0004 | R911172122 | Profile adapter for I/O modules and power distributor |
| SUP-M01-S67-0005 | R911172123 | Spacer |

Tab. 12-6: Carrier rail adapter, profile adapter and spacer

12.5 End Clamp

| Ordering code | Parts number | Brief description |
|----------------------|--------------|---|
| SUP-M01-ENDHALTER | R911170685 | Rapid assembly end clamp for 35 mm NS 35/7,5 or NS 35/15 carrier rail, width: 9.5 mm |
| SUP-M01-ENDHALTER/AL | R911171035 | End clamp for 35 mm NS 35/7,5 or NS 35/15 carrier rail, model: Aluminum, 2 screws used for fixing, width: 10 mm |
| SUP-M01-ENDHALTER/PA | R911172352 | End clamp for 35 mm carrier rail, model: Polyamide, width: 9.5 mm |

Tab. 12-7: End clamp

12.6 Protective Caps

Protective caps for female and male connectors that are not assigned (M8, M12)

| Ordering code | Parts number | Brief description |
|-----------------|--------------|--------------------------------------|
| RF-PROT-M8 | R911170895 | M8 protective cap (external thread) |
| RF-PROT-M12-M | R911171999 | M12 protective cap (internal thread) |
| SUP-M01-SM*12.1 | R911277260 | M12 protective cap (external thread) |

Tab. 12-8: Protective caps

12.7 Module Labeling Strips

| Ordering code | Parts number | Brief description |
|------------------|--------------|---|
| SUP-M01-S67-0007 | R911172125 | Labeling strip 4xM12 (for I/O modules) VPE=10 |

Tab. 12-9: Module labeling strips

13 Appendix

13.1 Diagnostic Information

Some field bus couplers display the error code in the form of an attribute path (CIA), through which the diagnostics can be clearly assigned. Other field bus couplers (e.g. Profinet I/O or Profibus DP) convert the attribute path into the respecting field bus-specific message.

The following diagnostic codes can be generated by the S67-DO8-HS-M12 module:

| Diagnostic message | Attribute path | | | Classification |
|--|----------------|---|-----|------------------|
| | C | I | A | |
| Undervoltage U_{LS} (Sensor supply) | 50 | 1 | 128 | Diagnostic alarm |
| Undervoltage U_A (Actuator supply) | 50 | 1 | 129 | Diagnostic alarm |

Tab. 13-1: Diagnostics of the module

| Diagnostic message | Attribute path | | | Classification |
|---|----------------|-------------|-----|------------------|
| | C | I | A | |
| Overheating This function is only active when the actuator output is switched on | 9 | Channel no. | 130 | Diagnostic alarm |

Tab. 13-2: Diagnostics of the channels of the module

14 Service and support

Our worldwide service network provides an optimized and efficient support. Our experts offer you advice and assistance should you have any queries. You can contact us **24/7**.

Service Germany Our technology-oriented Competence Center in Lohr, Germany, is responsible for all your service-related queries for electric drive and controls.

Contact the **Service Helpdesk & Hotline** under:

Phone: **+49 9352 40 5060**
Fax: **+49 9352 18 4941**
E-mail: service.svc@boschrexroth.de
Internet: <http://www.boschrexroth.com>

Additional information on service, repair (e.g. delivery addresses) and training can be found on our internet sites.

Service worldwide Outside Germany, please contact your local service office first. For hotline numbers, refer to the sales office addresses on the internet.

Preparing information To be able to help you more quickly and efficiently, please have the following information ready:

- Detailed description of malfunction and circumstances resulting in the malfunction
- Type plate name of the affected products, in particular type codes and serial numbers
- Your contact data (phone and fax number as well as your email address)

Index

A

| | |
|---|----|
| Abbreviations..... | 8 |
| About this documentation | |
| Validity of the documentation..... | 6 |
| Accessories..... | 51 |
| Assembled S-BUS cables..... | 51 |
| Carrier rail adapter, profile adapter and spacer..... | 52 |
| End clamp..... | 53 |
| Module labeling strips..... | 53 |
| Protective caps..... | 53 |
| Ready-made supply cables..... | 51 |
| Appendix..... | 55 |
| Diagnostic information..... | 55 |

C

| | |
|--------------------------------------|----|
| Commissioning..... | 37 |
| Complaints..... | 8 |
| Connect data and supply cable..... | 31 |
| Notes..... | 31 |
| Connecting the data and supply cable | |
| Connecting the Actuator Cable..... | 35 |
| Connecting the module..... | 50 |
| Criticism..... | 8 |
| Customer Feedback..... | 8 |

D

| | |
|---|----|
| Data and supply cable connection | |
| Required accessories..... | 32 |
| S-BUS connection..... | 32 |
| Supply cable connection..... | 33 |
| Device description..... | 13 |
| Connections..... | 13 |
| Dimensions..... | 18 |
| Display elements..... | 15 |
| Labeling and bar code type at the back of the device..... | 16 |
| Labeling options and mounting..... | 14 |
| Schematic circuit diagram..... | 17 |
| Technical data..... | 18 |
| Type plate..... | 16 |
| Diagnostics via LED signals..... | 45 |
| Operating messages of the module..... | 45 |
| Display elements..... | 15 |
| Displays..... | 21 |
| Disposal..... | 50 |

F

| | |
|---------------|---|
| Feedback..... | 8 |
|---------------|---|

I

| | |
|--------------------------------------|----|
| Intended use | |
| Application cases..... | 9 |
| Information about the operation..... | 10 |
| Introduction..... | 9 |

| | |
|---------------------|----|
| Safety devices..... | 10 |
| Use cases..... | 9 |

M

| | |
|--|----|
| Maintenance and service..... | 49 |
| Connecting the module..... | 50 |
| Field bus coupler replacement, disconnecting the wiring..... | 49 |
| Replacing the field bus coupler, removing the field bus coupler from the carrier plate..... | 49 |
| Replacing the field bus coupler, removing the field bus coupler from the profile adapter..... | 50 |
| Replacing the module..... | 49 |
| Maintenance and Service | |
| Replacing the field bus coupler, removing the field bus coupler from the system..... | 49 |
| Manufacturing date..... | 16 |
| Mounting of the module | |
| Direct mounting to the system..... | 24 |
| Mounting the field bus coupler | |
| Replacing the labeling fields..... | 27 |
| Required tools and accessories for mounting..... | 23 |
| Mounting the module..... | 23 |
| Mount on carrier rail..... | 24 |
| Mount on carrier rail, fasten carrier rail adapter on the module..... | 24 |
| Mount on profile rail..... | 26 |
| Mount on profile rail, fasten module with profile adapter on profile rail..... | 27 |
| Mount on profile rail, fasten profile adapter on the module..... | 26 |
| Mounting notes..... | 23 |
| Mounting the spacer in case of compact arrangement..... | 28 |
| Mounting to a mounting rail, Fastening the module with mounting rail adapter to a mounting rail..... | 25 |

P

| | |
|---|----|
| Parameterization..... | 41 |
| Automatic storage of system parameters..... | 43 |
| Diagnostic overview..... | 41 |
| Firmware update..... | 43 |
| Global settings for field supply..... | 43 |
| Input parameters..... | 42 |
| Parts number..... | 16 |
| Process images..... | 39 |
| Input data..... | 40 |
| Output data..... | 39 |
| Product phases..... | 6 |

S

| | |
|--|----|
| S-BUS cable, bending radius..... | 51 |
| S-BUS cable, cable carrier-compatible..... | 51 |
| S-BUS cable, tensile load..... | 51 |

Index

| | |
|---|----|
| Safety alert symbol..... | 11 |
| Safety instructions..... | 11 |
| Schematic circuit diagram..... | 17 |
| Scope..... | 5 |
| Serial number..... | 16 |
| Signal words..... | 11 |
| Structure documentation..... | 7 |
| Suggestions..... | 8 |
| Supply cable, bending radius..... | 52 |
| Supply cable, cable carrier-compatible..... | 51 |
| Supply cable, tensile load..... | 52 |
| Support | |
| See service hotline..... | 57 |
| Symbols..... | 12 |

T

| | |
|--|----|
| Target groups..... | 6 |
| Technical data | |
| Communication..... | 19 |
| Diagnostic I/O..... | 20 |
| Digital outputs..... | 19 |
| Displays..... | 21 |
| Electrical isolation..... | 20 |
| Influence of operating states to the output..... | 20 |
| Module supply..... | 18 |
| Parameterizable functions..... | 20 |
| Process image..... | 20 |
| Specification for actuator selection..... | 19 |
| Standards and approvals..... | 21 |
| Technical data..... | 18 |
| Technical index..... | 16 |
| Terms..... | 8 |
| Terms and abbreviations..... | 8 |
| Type plate..... | 16 |
| Type-code..... | 16 |

U

| | |
|---|----|
| Unintended use..... | 10 |
| Consequences, exclusion of liability..... | 9 |

Notes

Bosch Rexroth AG

Electric Drives and Controls

P.O. Box 13 57

97803 Lohr, Germany

Bgm.-Dr.-Nebel-Str. 2

97816 Lohr, Germany

Tel. +49 9352 18 0

Fax +49 9352 18 8400

www.boschrexroth.com/electrics



R911342200