

# Rexroth IndraLogic XLC IndraMotion MLC 12VRS Automation Interface

R911334178  
Edition 01

## Application Manual



**Title** Rexroth IndraLogic XLC  
IndraMotion MLC 12VRS  
Automation Interface

**Type of Documentation** Application Manual

**Document Typecode** DOK-XLCMLC-AUT\*INT\*V12-AP01-EN-P

**Internal File Reference** RS-7d7d10c8a32c1c780a6846a00018b113-1-en-US-3

**Purpose of Documentation** This documentation describes the script-based access to the IndraWorks project data via the interface of the Automation Interface.

**Record of Revision**

Edition	Release Date	Notes
Edition 01	04.2011	First edition for 12VRS

**Copyright** © Bosch Rexroth AG 2011

Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

**Validity** The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

**Published by** Bosch Rexroth AG

Bgm.-Dr.-Nebel-Str. 2 ■ 97816 Lohr a. Main, Germany  
Phone +49 (0)93 52/ 40-0 ■ Fax +49 (0)93 52/ 40-48 85  
<http://www.boschrexroth.com/>

System Development Automation Motion Logic Control, WoP, (FrWe/MePe)

**Note** This document has been printed on chlorine-free bleached paper.

# Table of Contents

	Page
<b>1 About this Documentation.....</b>	<b>3</b>
1.1 Validity of the Documentation.....	3
1.2 Required and Supplementing Documentations.....	3
1.3 Representation of Information.....	7
1.3.1 Safety Instructions.....	7
1.3.2 Symbols used.....	7
1.3.3 Names and Abbreviations.....	8
<b>2 Important Instructions on Use.....</b>	<b>9</b>
2.1 Appropriate Use.....	9
2.1.1 Introduction.....	9
2.1.2 Areas of Use and Application.....	9
2.2 Inappropriate Use.....	10
<b>3 Introduction.....</b>	<b>11</b>
3.1 General.....	11
3.2 Scripting.....	12
3.3 Using Automation Scripts .....	12
<b>4 Basic Objects.....</b>	<b>15</b>
4.1 Object Model.....	15
4.2 Object - Application.....	15
4.3 Object - ProjectManager.....	17
4.4 Object - Project.....	19
4.5 Object - ProjectElement.....	22
4.6 Object - Device (Derived from ProjectElement).....	25
4.7 Object - File (Derived from ProjectElement).....	26
4.8 Object - Folder (Derived from ProjectElement).....	26
4.9 Object - AiCollection.....	26
4.10 Object - AiList.....	26
<b>5 Example Codes - Basic Objects.....</b>	<b>29</b>
5.1 Example code - Initializing the Automation Interface.....	29
5.2 Example Code - Creating an IndraWorks Project.....	29
5.3 Example Code - Opening an IndraWorks Project.....	30
5.4 Example Code - Adding Folders and Files.....	30
5.5 Example Code - Searching in Projects.....	31
5.6 Example Code - Accessing Devices.....	33
5.7 Example Code - Archiving a Project.....	34
5.8 Example Code - Restoring a Project.....	35
5.9 Example Code - Validating a Project.....	36

## Table of Contents

	Page
<b>6 XLC/MLC Objects.....</b>	<b>39</b>
6.1 Object Model.....	39
6.2 Object - XLC (Derived from Device).....	39
6.3 Adding an XLC.....	43
6.4 Object - MLC (Derived from Device).....	45
6.5 Adding an MLC.....	49
6.6 Object - MultiDeviceTable.....	51
<b>7 Example Codes - XLC/MLC Objects.....</b>	<b>53</b>
7.1 Example Code - Access to the XLC/MLC.....	53
7.2 Example Code - Going Online/Offline.....	53
7.3 Example Code - Reading/Writing Phase.....	54
7.4 Example Code - Importing Parameter.....	55
7.5 Example Code - Reading/Writing Parameter.....	56
7.6 Example Code - Firmware Download.....	57
7.7 Example Code - Adding XLC/MLC.....	58
7.8 Example Code - Using/Not Using Multi-Device.....	59
7.9 Code Example - Activating an XLC/MLC from the Multi-Device Table.....	60
7.10 Code Example - Accessing the "Logic" Object.....	61
<b>8 IL Objects.....</b>	<b>63</b>
8.1 Object – Logic.....	63
8.2 Object – Application.....	63
<b>9 Service and Support.....</b>	<b>67</b>
<b>Index.....</b>	<b>69</b>

# 1 About this Documentation

## 1.1 Validity of the Documentation

- Target group** This documentation describes the script-based access to the IndraWorks project data via the interface of the Automation Interface.
- This documentation supports the user during the following phases:
- Engineering and
  - Commissioning

## 1.2 Required and Supplementing Documentations

Documentation titles with type designation codes and parts numbers

IndraWorks		MLC	XLC
/36/	<b>Rexroth IndraWorks 12VRS Software Installation</b> DOK-IWORKS-SOFTINS*V12-COxx-EN-P, R911334396 This documentation describes the IndraWorks installation.	X	X
/5/	<b>Rexroth IndraWorks 12VRS Engineering</b> DOK-IWORKS-ENGINEE*V12-APxx-EN-P, R911334388 This documentation describes the application of IndraWorks in which the Rexroth Engineering tools are integrated. It includes instructions on how to work with IndraWorks and how to operate the oscilloscope function.	X	X
/20/	<b>Rexroth IndraMotion MLC 12VRS Functional Description</b> DOK-MLC***-FUNC****V12-APxx-EN-P, R911333848 This documentation describes wizards, context menus, dialogs, control commissioning, device configuration and functionalities of the IndraMotion MLC.	X	
/20/	<b>Rexroth IndraLogic XLC 12VRS Functional Description</b> DOK-XLC***-FUNC****V12-APxx-EN-P, R911333878 This documentation describes wizards, context menus, dialogs, control commissioning, device configuration and functionalities of the IndraLogic XLC.		X
/7/	<b>Rexroth IndraWorks 12VRS CamBuilder</b> DOK-IWORKS-CAMBUIL*V12-APxx-EN-P, R911333842 This documentation describes the basic principles and operation of the CamBuilder, the cam editing tool.	X	X
/37/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS Automation Interface</b> DOK-XLCMLC-AUT*INT*V12-APxx-EN-P, R911334178 This documentation describes the script-based access to IndraWorks project data via the interface of the Automation Interface.	X	X
/38/	<b>Rexroth IndraWorks 12VRS FDT Container</b> DOK-IWORKS-FDT*CON*V12-APxx-EN-P, R911334398 This documentation describes the IndraWorks FDT Container functionality. It includes the activation of the functionality in the project and working with DTMs.	X	X

## About this Documentation

/29/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS Project Conversion</b> DOK-XLCMLC-PROCONV*V12-APxx-EN-P, R911334187 This documentation describes the project conversion from IndraWorks version 7 projects with IndraLogic 1.x to IndraWorks version 12 with IndraLogic 2G. It especially focuses on changes in the field of Motion and PLC.	X	X
/28/	<b>Rexroth IndraMotion MLC 12VRS Commissioning</b> DOK-MLC***-STARTUP*V12-COxx-EN-P, R911333858 This documentation describes the steps required for commissioning and performing service on the IndraMotion MLC system. It includes checklists for tasks to be frequently performed and a detailed description of the steps.	X	

Motion		MLC	XLC
/23/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS PLCopen Libraries</b> DOK-XLCMLC-FUNLIB**V12-LIxx-EN-P, R911334182 This documentation describes the function blocks, functions and data types of the RIL_CommonTypes, ML_Base and ML_PLCopen libraries for the IndraLogic XLC/IndraMotion MLC. It also includes the error reactions of function blocks.	X	X
/27/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS Generic Application Template</b> DOK-XLCMLC-TF*GAT**V12-APxx-EN-P, R911334191 This documentation provides a structured template to the IndraLogic PLC programmer. This template can be used to add and edit the PLC programming code. It includes the template, the template wizard and example applications.	X	X
/31/	<b>Rexroth IndraMotion MLC 12VRS RCL Programming Instruction</b> DOK-MLC***-RCL*PRO*V12-APxx-EN-P, R911333852 This documentation provides information on the RobotControl. It is given most importance to the programming language RCL (RobotControl Language). The program structure, variables, functions, motion statements and the required system parameters are described.	X	
/21/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS Parameters</b> DOK-XLCMLC-PARAM***V12-RExx-EN-P, R911334176 This documentation describes the parameters of the XLC/MLC systems as well as the interaction between parameterization and programming. It includes the axis parameters, control parameters, kinematic parameters, touch probe parameters and programmable limit switch parameters.	X	X
/10/	<b>Rexroth IndraDrive; Firmware for Drive Controllers MPH, MPB, MPD, MPC-07</b> DOK-INDRV*-MP*-07VRS**-FKxx-EN-P, R911328670		
/11/	<b>Rexroth IndraDrive MPx-16 Functions</b> DOK-INDRV*-MP*-16VRS**-APxx-EN-P, R911326767		

Field Buses		MLC	XLC
/39/	<b>Rexroth IndraMotion MLC 11VRS PLCopen Field Bus</b> DOK-IM*ML*-PLCFBUS*V11-APxx-EN-P, R911333896 This documentation describes the creation of field bus drives in an IndraWorks project, function blocks, functions and data types of the libraries RIL_CommonTypes.library (excerpt for field bus drives), RMB_PLCopenFieldBus.library, RIL_Utility.library (excerpt for field bus drives). It also includes the error reactions of function blocks.	X	X
/4/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS Field Buses</b> DOK-XLCMLC-FB*****V12-APxx-EN-P, R911334394 This documentation describes the supported field buses and their diagnostic function blocks.	X	X

## About this Documentation

HMI		MLC	XLC
/8/	<b>Rexroth IndraWorks 12VRS HMI</b> DOK-IWORKS-HMI****V12-APxx-EN-P, R911334392 This documentation describes the functions, configuration and operation of the user interfaces IndraWorks HMI Engineering and IndraWorks HMI Operation.	X	X
/6/	<b>Rexroth IndraWorks 12VRS WinStudio</b> DOK-IWORKS-WINSTUD*V12-APxx-EN-P, R911333844 This documentation describes the installation of the software, working with WinStudio and the creation and operation of applications.	X	X
/50/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS HMI Connection</b> DOK-XLCMLC-HMI****V12-APxx-EN-P, R911334184 This documentation describes the visualization systems supported by the IndraLogic XLC and IndraMotion MLC and their connection.	X	X
PLC		MLC	XLC
/3/	<b>Rexroth IndraWorks 12VRS IndraLogic 2G Programming Instruction</b> DOK-IWORKS-IL2GPRO*V12-APxx-EN-P, R911334390 This documentation describes the PLC programming tool IndraLogic 2G and its usage. It includes the basic usage, first steps, visualization, menu items and editors.	X	X
/33/	<b>Rexroth IndraWorks 12VRS, Basic Libraries, IndraLogic 2G</b> DOK-IL*2G*-BASLIB**V12-LIxx-EN-P, R911333835 This documentation describes the system-comprehensive PLC libraries.	X	X
Technology			
/30/	<b>Rexroth IndraMotion MLC 12VRS Technology Libraries</b> DOK-MLC***-TF*LIB**V12-LIxx-EN-P, R911333868 This documentation describes the function blocks, functions and data types of the libraries "ML_TechInterface.library", "ML_TechMotion.library", "RMB_TechCam.library" and "ML_TechBase.library". It also includes libraries for the winder functionality, register controller functionality and CrossCutter functionality.	X	
/60/	<b>Rexroth IndraMotion MLC 12VRS RegisterControl (Library)</b> DOK-MLC***-REGI*CO*V12-LIxx-EN-P, R911333856 This documentation describes the inputs and outputs of the individual function blocks and provides information on their usage.	X	
/62/	<b>Rexroth IndraMotion MLC 12VRS RegisterControl (Application Manual)</b> DOK-MLC***-REGI*CO*V12-APxx-EN-P, R911333854 This documentation describes the application of the integrated register control for a rotogravure printing machine. The components of the mark stream sensor, the HMI application and the error recovery options are described. This instruction provides information on how to operate the register control, react on errors and query diagnostics. This documentation is written for machine setters and machine operators.	X	
/49/	<b>Rexroth IndraMotion MLC 12VRS Application of Winder Functions</b> DOK-MLC***-TF*WIND*V12-APxx-EN-P, R911333870 This application-related system documentation describes the usage of the winder technology functions.	X	

## About this Documentation

Hardware		MLC	XLC
/1/	<b>Rexroth IndraControl L45/L65</b> DOK-CONTRL-IC*L45*L65*-PRxx-EN-P, R911324661	X	X
/2/	<b>Rexroth IndraControl L25</b> DOK-CONTRL-IC*L25*****-PRxx-EN-P, R911328474	X	X
/24/	<b>Rexroth IndraControl Lxx 12VRS Function Modules</b> DOK-CONTRL-FM*LXX**V12-APxx-EN-P, R911333830 This documentation describes all function modules of the Lxx controls including engineering and diagnostics.	X	
/12/	<b>Rexroth IndraDrive Drive Controllers MPx-02 to MPx-07</b> DOK-INDRV*-GEN-**VRS**-PAxx-EN-P, R911297317		
/13/	<b>Rexroth IndraDrive MPx-02 to MPx-07 and HMV</b> DOK-INDRV*-GEN-**VRS**-WAxx-EN-P, R911297319		
/35/	<b>Rexroth IndraDrive Drive Controller Control Units CSB01, CSH01, CDB01</b> DOK-INDRV*-CSH*****-PR08-EN-P, R911295012		

Diagnostics and Service		MLC	XLC
/26/	<b>Rexroth IndraMotion MLC/XLC 11VRS Service Tool</b> DOK-IM*ML*-IMST****V11-RExx-EN-P, R911331940	X	X
/22/	<b>Rexroth IndraLogic XLC IndraMotion MLC 12VRS Diagnostics</b> DOK-XLCMLC-DIAG****V12-RExx-EN-P, R911334180 This documentation includes all control parameters implemented in the control systems IndraLogic XLC and IndraMotion MLC.	X	X

System Overview		MLC	XLC
/48/	<b>Rexroth IndraMotion for Printing 12VRS System Overview</b> DOK-IM*PR*-SYSTEM**V11-PRxx-EN-P, R911333840 This documentation describes the product IndraMotion for Packaging. It introduces the control systems, drive systems and I/O systems as well as the commissioning and programming.	X	
/48/	<b>Rexroth IndraMotion for Packaging 12VRS System Overview</b> DOK-IM*PA*-SYSTEM**V12-PRxx-EN-P, R911333838 This documentation describes the product IndraMotion for Packaging. It introduces the control systems, drive systems and I/O systems as well as the commissioning and programming.	X	
/9/	<b>Rexroth IndraMotion MLC 12VRS System Overview</b> DOK-MLC***-SYSTEM**V12-PRxx-EN-P, R911333860 This documentation provides an overview on the possible hardware/software components of the automation system IndraMotion MLC of the named version. It helps assembling a system.	X	
/9/	<b>Rexroth IndraLogic XLC 12VRS System Overview</b> DOK-XLC***-SYSTEM**V12-PRxx-EN-P, R911333880 This documentation provides an overview on the possible hardware/software components of the automation system IndraLogic XLC of the named version. It helps assembling a system.		X

First Steps		MLC	XLC
/25/	<b>Rexroth IndraMotion MLC 12VRS First Steps</b> DOK-MLC***-F*STEP**V12-COxx-EN-P, R911333846 This documentation describes the first steps of the IndraMotion MLC and the RobotControl. It includes the hardware and software prerequisites as well as the creation of a project.	X	
/25/	<b>Rexroth IndraLogic XLC 12VRS First Steps</b> DOK-XLC***-F*STEP**V12-COxx-EN-P, R911333876 This documentation describes the first steps of the IndraLogic XLC. It includes the hardware and software prerequisites as well as the creation of a project.		X

xx Respective edition  
 Fig. 1-1: XCL/MLC documentation overview

## 1.3 Representation of Information

### 1.3.1 Safety Instructions

The safety instructions available in the user documentations contain certain signal words (Danger, Warning, Caution, Notice) and a signal graphic if necessary (acc. to ANSI Z535.6-2006).

The signal word should focus the attention on the safety instructions and designates the severity of the hazard.

The signal graphic (warning triangle with exclamation mark) located in front of the signal words "Danger", "Warning" and "Caution" indicates hazards for individuals.

#### DANGER

In case of non-compliance with this safety instruction, death or serious injury will occur.

#### WARNING

In case of non-compliance with this safety instruction, death or serious injury could occur.

#### CAUTION

In case of non-compliance with this safety instruction, minor or moderate injury could occur.

#### NOTICE

In case of non-compliance with this safety instruction, property damages can occur.

### 1.3.2 Symbols used

**Note** Notes are represented as follows:



This is a note for the user.

**Tip** Tips are represented as follows:

About this Documentation



This is a tip for the user.

---

### 1.3.3 Names and Abbreviations

Term	Meaning
AI	Automation Interface
HMI	Human machine interface
HTML	Hypertext markup language
IDE	Integrated development environment
JavaScript	Interpretable commands under Java
MLC	MotionLogic Control
OLE	Object linking and embedding
VB	Visual Basic
VBScript	Interpretable commands under Visual Basic

*Fig. 1-2: Names and abbreviations used*

## 2 Important Instructions on Use

### 2.1 Appropriate Use

#### 2.1.1 Introduction

Rexroth products represent state-of-the-art developments and manufacturing. They are tested prior to delivery to ensure operating safety and reliability.

The products may only be used appropriately. If they are not used correctly and appropriately, situations could occur that could result in damage to property and injury to personnel.



Bosch Rexroth as manufacturer is not liable for any damages resulting from inappropriate use. In such cases, the guarantee and the right to payment of damages resulting from inappropriate use are forfeited. The user alone carries all responsibility of the risks.

---

Before using Rexroth products, make sure that all the pre-requisites for an appropriate use of the products are satisfied:

- Personnel who in any way, shape or form use our products must first read and understand the relevant safety instructions and be familiar with the appropriate use of the products.
- If the products take the form of hardware, then they must remain in their original state, in other words, no structural changes are permitted. It is not permitted to decompile software products or alter source codes.
- Do not install or operate damaged or faulty products.
- Ensure that the products have been installed in the manner described in the relevant documentation.

#### 2.1.2 Areas of Use and Application

##### Rexroth IndraMotion MLC/MLP

Rexroth IndraMotion MLP and IndraMotion MLC and their function modules are intended for Motion/Logic applications.



The Rexroth IndraMotion MLP and IndraMotion MLC controls and their function modules may only be used with the accessories and mounting parts listed in this documentation. Components that are not expressly mentioned must neither be attached nor connected. The same is valid for cables and lines.

Operation must only be carried out with the hardware component configurations and combinations that are expressly specified and with the software and firmware indicated and specified in the respective documentation and functional descriptions.

---

The Rexroth IndraMotion MLP and IndraMotion MLC and their function modules have been developed for use in single and multi-axis drive and control tasks.

For the application-specific use of the machine operating and visualization terminals, device models featuring different equipments and different interfaces are available.

Typical areas of application for the Rexroth IndraMotion MLP and IndraMotion MLC and their function modules are:

- Handling and mounting systems
- Packaging and food machines

## Important Instructions on Use

- Printing and paper-processing machines
- Machine tools

Rexroth IndraMotion MLP and IndraMotion MLC and their function modules must only be operated under the mounting and installation conditions, the position, and the ambient conditions (temperature, type of protection, moisture, EMC, etc.) specified in the related documentations.

## 2.2 Inappropriate Use

The use of Rexroth IndraMotion MLP and IndraMotion MLC and their function modules in applications other than those specified or described in the documentation and the technical data is considered as "inappropriate".

The Rexroth IndraMotion MLP and IndraMotion MLC and their function modules may not be used if they are

- exposed to operating conditions which do not correspond to the specified ambient conditions. Operation under water, extreme temperature fluctuations or extreme maximum temperatures etc. is prohibited.
- Furthermore, the IndraMotion MLP and IndraMotion MLC and their function modules must not be used in any applications not expressly approved by Bosch Rexroth. Therefore, please read the statements given in the general safety instructions!

### 3 Introduction

#### 3.1 General

The Automation Interface provides a simple, clearly structured script interface for IndraWorks, permitting access to the IndraWorks project data.

IndraWorks automation scripts (from now on called AI scripts) can be generated in script languages such as VBScript and JavaScript and subsequently executed in the IndraWorks Engineering desktop or in the Windows console. During the execution in IndraWorks, it is possible to integrate AI scripts or to insert them as a separate note in an IndraWorks project.




Fig.3-1: Automation scripts in IndraWorks

A listing of typical applications that can be processed using the Automation Interface is shown in the following:

- Creation of customer-specific reports.
- Automation of periodically recurring modifications in the IndraWorks projects.
- Automated creation of IndraWorks projects using the script-based processing of parts lists.
- Creation of simple customer-specific GUIs in the IndraWorks Engineering desktop.



For the code examples described in later chapters, there are partially requirements that are not met automatically during the installation. Thus, it can be possible that a script does not run immediately in each case if, for example, the security settings of the browser impede the creation of ActiveX objects.

## 3.2 Scripting

IndraWorks Automation allows other applications to use the IndraWorks project data via the Windows OLE automation (ActiveX). The Automation Interface is normally used with script clients such as JavaScript or VBScript.

Scripts can either be executed via Microsoft Scripting Host (command line version: or integrated in the IndraWorks Engineering desktop. Thus, an HTML page must be created in which the automation script is embedded (for an example, refer to the following chapter). An HTML site can be subsequently added as individual menu item in the IndraWorks main menu (main menu **Tools ▶ External applications...** or as separate node to the IndraWorks project and started from there.

Some important comments on the scripting are listed below:

- Scripts do not have types, i.e. the script space contains only objects, but no special types (classes).
- Type termination using LateBinding, i.e. it is not checked before runtime whether the addressed type/method can be terminated.
- When creating AI scripts, refer to this Automation Interface manual. Since scripts have no type, there is no IDE IntelliSense help.
- During scripting, all methods and attributes of the basic classes are available in a derived object; for example, the methods and attributes of **Device** and **ProjectElement** can be accessed in the **MLC** object.

## 3.3 Using Automation Scripts

### Executing HTML files in embedded scripts

Scripts can also be used when embedded in an HTML file. The script is automatically executed if the HTML site is opened with a browser.

#### Example:

The following example show the structure of an HTML site with embedded JavaScript.

#### Program:

---

```
<html>
  <body>
    <script language = "JavaScript">
      alert("Hello World...");
    </script>
  </body>
</html>
```

---

### Executing script files in a console with "CScript.exe"

Scripts can be executed in a console window when using the "CScript.exe" application in Microsoft Windows. Script outputs are directly written to the console window.

#### Example:

After opening a console (command prompt) the JavaScript file "MyScript.js" can be executed as follows after entering "CScript.exe":

```
CScript.exe MyScript.js
```

A helpful option to develop scripts is "//D".

```
With CScript.exe MyScript.js //D,
```

a script can be debugged. Therefore, a debugger like "Visual Studio" must be installed on the computer executing the script. As breakpoint within a script, the keyword "debugger" is to be used. As soon as the program counter detects the keyword "debugger" when processing the script, the further processing of the

## Introduction

script is canceled and the debugger to be used can be started in which the script will be subsequently processed further.

More "CScript.exe" options can be listed by calling

`CScript.exe`

(without arguments).



## 4 Basic Objects

### 4.1 Object Model

The object hierarchy of the Automation Interface is shown in the following diagram. In terms of structure, the diagram corresponds to an IndraWorks Project.




Fig.4-1: Object model of the Automation Interface to access from AI script

The objects shown in beige in the diagram is the **Basis Automation Interface** described in this documentation. The objects shown in green are system-specific devices, such as HMI, MTX, MLC and IndraLogic adding system-specific aspects to the Basis Automation Interface. The description of these objects - if available for a system - is part of the respective system documentation.

### 4.2 Object - Application

The **Application** object is the starting object used for the initialization of the Automation Interface. It represents a running IndraWorks Engineering desktop instance. When an AI script is executed in IndraWorks, the object is already created by IndraWorks and can be read from the property **window.external** in the script. After the initialization is completed, IndraWorks project data can be accessed. Apart from the access via **window.external**, the **Application** object can also be initialized via the **Rexroth.IndraWorks.Automation.Application** namespace. In this case, a security query of the Internet Explorer appears when the script is executed.

## Basic Objects

## Attributes of "Application"

Attribute	Type	Description
ProjectManager	Rexroth.Indraworks.Automation.ProjectManager	Read-only. Reference to ProjectManager.

## Application methods

Method	Type	Description
Connect (string dest-ComputerName, string mode)	void	<p>Initializes the Automation Interface and establishes a connection to the Automation Server.</p> <p>Parameters: destComputerName [string in], target computer name on that the Automation Server - to which a connection should be established - is located. Currently, only local connections are supported (destComputerName = "localhost").</p> <p>Parameters: mode [string in], dtm / automation / tci.</p> <p>Currently, only the mode = "automation" is supported.</p>
GetService( string serviceName)	object	<p>This method provides access to the services registered at the AI.</p> <p>When it is executed successfully, the method returns a reference to the new instance of the queried service. "Zero" is returned in case of error. The service description, that is the interface description of the respective service is provided by the service provider (e.g. MTX, MLC, IndraLogic, Drive...).</p> <p>Parameters: serviceName [string in], unique name of the service registered at the AI. An access object should be returned for this service.</p>
Disconnect()	void	Disconnects the connection to the Automation Server. The Engineering desktop is not shut down.

Basic Objects

Method	Type	Description
Shutdown()	void	Shuts down the IndraWorks Engineering desktop to which a connection is established. All active procedures are canceled in the Engineering desktop.
CreateComInstance (string progId)	object	<p>This method can be used to create COM objects that cannot be created in the scripting using "new ActiveXObject(..)" due to the security settings in the Internet Explorer.</p> <p>If, for example, a file access is required via the FileSystemObject in the Automation Script, the FileSystemObject is created via the following call in the script:</p> <pre>var fso = new ActiveXObject("Scripting.FileSystemObject")</pre> <p>However, this is only possible if the corresponding ActiveX privileges are set in the browser security settings. If the security settings do not allow new objects to be created using "new ActiveXObject(..)", the required FileSystemObject can be generated by calling:</p> <pre>var fso = Application.CreateComInstance("Scripting.FileSystemObject");</pre> <p>via the Automation Interface. As a result, a file access is possible even if it would normally not be allowed due to the security settings.</p> <p>When it is executed successfully, the method returns a reference to the new instance. If an error occurs, a COMException with the HRESULT code: 0x800A01AD ("Can't create ActiveX object!") is triggered.</p> <p>Parameters: progId [string in]: ProgId of the registered COM class that is to be instanced by this call.</p> <p>Example: The ProgId for FileSystemObject is "Scripting.FileSystemObject".</p>

For an example code, please refer to: [Chapter 5.2 Example Code - Creating an IndraWorks Project, page 29.](#)

### 4.3 Object - ProjectManager

The **ProjectManager** object can be used to manage, i.e. create, open, delete, archive or restore, the various projects. While creating and opening, a reference to a **Project** object is provided.

The **Projects** attribute can be used to read a collection of all opened projects.

#### Attributes of "ProjectManager"

Attribute	Type	Description
Projects	Rexroth.IndraWorks.Automation.AiCollection	<p>Read-only. List of all opened projects. The list of type "AiCollection" contains the references to "Project" objects.</p> <p>In the current IndraWorks implementation, only one project can be opened.</p>

## Basic Objects

## ProjectManager methods - Part 1

Method	Type	Description
CreateProject(string fileName)	Rexroth.IndraWorks.Automation.Project	Creates a new project with the specified name and returns a reference to it. Parameters: fileName [string in], path and name of the project file (*.iwp file), contains drive and directory name.
OpenProject(string fileName)	Rexroth.IndraWorks.Automation.Project	Opens an existing project with the specified name and returns a reference to it. Parameters: fileName [string in], path and name of the project file (*.iwp file), contains drive and directory name.
DeleteProject(Rexroth.IndraWorks.Automation.Project iProject)	void	Deletes the specified project.
ArchiveProject( Scripting.Dictionary archiveArgs)	void Exception in case of error.	Creates a ZIP archive of an IndraWorks project. Only the data located in the project directory is zipped. If necessary, system-specific archiving procedures have to be executed before. Only closed projects can be archived. While archiving an open project, it is to be closed using the 'CloseProject' (True/False) key. Parameters: archiveArgs [System.Dictionary, in], all parameters for the archiving as key/value pairs in a Scripting.Dictionary object are transferred. The following keys (parameters) are available for archiving. Key: 'ProjectFile' [string in], Value: [string in] project file (*.iwp) of the project to be archived (including path name). Key: 'ArchiveFile' [string in], Value: [string in] name of the archive file (*.zip) that is to be created during archiving (including path information). Key: 'ArchiveComment' [string in], Value: [string in] [optional parameter], comment on the archive. Key: 'Password' [string in], Value: [string in] [optional parameter], password used to protect the archive. If this key is not specified or if the password is an empty string, the archive is not protected. Key: 'CloseProject' [string in], Value: [string in, True or False], this parameter can be used to specify whether the project to be archived is automatically closed before the archiving. The parameter is especially reasonable if the automatic archiving is time-controlled using AI script while the user is editing the IndraWorks project. If "CloseProject" is set to "False", the AI cannot close the project automatically while it is edited in the interface. True: The project is closed during archiving and then reopened. False: The project is not closed. <b>Caution:</b> An open project can only be archived if this parameter is set to "True". For an example code, please refer to: <a href="#">Chapter 5.7 Example Code - Archiving a Project, page 34.</a>

**ProjectManager methods - Part 2**

Method	Type	Description
RestoreProject( Scripting.Dictionary restoreArgs)	void Exception in case of error.	Restores a previously created IndraWorks project archive. The archive is unzipped and the IndraWorks project is restored.  Parameters: restoreArgs [System.Dictionary, in], all parameters for the restoration are transferred as key/value pairs in a Scripting.Dictionary object. The following keys (parameters) are available for restoration.  Key: 'ArchiveFile' [string in], Value: [string in] file of the IndraWorks project archive (*.zip) that is to be restored (including path information).  Key: 'RestoreDir' [string in], Value: [string in], target directory for restoration. Specifies the directory in which the IndraWorks project archive is to be restored. The project directory is created below this directory while restoring it.  Key: 'NewProjectName' [string in], Value: [string in] [optional parameter], if the project to be restored should get a new name, it can be specified here. In this case, project directory, project file and project name are changed accordingly during restoration.  Key: 'Password' [string in], Value: [string in] [optional parameter], password used to protect the archive. If this key is not specified or if the password is an empty string, it is tried to restore the archive without a password.  Key: 'OpenProject' [string in], Value: [string in, True or False], Boolean variable determining whether the restored project should be opened after restoration. True: The project is automatically opened after the restoration (the currently open project is closed before). False: The project is not reopened after the restoration.  For an example code, please refer to: <a href="#">Chapter 5.8 Example Code - Restoring a Project, page 35.</a>

For an example code, please refer to: [Chapter 5.2 Example Code - Creating an IndraWorks Project, page 29.](#)

## 4.4 Object - Project

The **Project** object represents an IndraWorks project. The project methods can be used to create new subordinate project elements and search for project elements or delete them. Project data can be exported/imported via **Export/Import**.

If the project contains system-specific devices such as MTX, MLC or IndraLogic, the **GetChildrenOfType** method and the corresponding type string can be used to determine a reference to these objects. This reference can be used to access the extended functionality of the system-specific devices.

The **Children** attribute provides a collection of all project elements of the project (all nodes of the first level below the project node).

### Attributes of "Project"

Attribute	Type	Description
Name	string	Read/write. Project name.
Id	string	Read-only. Unique project ID (guid).

## Basic Objects

Attribute	Type	Description
Location	string	Read-only. Directory path in which the project (project file) is saved.
Children	Rexroth.IndraWorks.Automation.AiCollection	Read-only. Provides a collection of all children (all nodes of the first level below the project node). The collection contains references to objects of the type <code>Typ Rexroth.IndraWorks.Automation.Device</code> , <code>Typ Rexroth.IndraWorks.Automation.File</code> , <code>Typ Rexroth.IndraWorks.Automation.Folder</code> or types of system-specific devices.

## Project methods

Method	Type	Description
Save()	void	Saves the project.
SaveAs(string fileName)	Rexroth.IndraWorks.Automation.Project	Saves the current project under a new name and returns a reference to the new project. <b>Caution:</b> The previous "Project" object (with the old name) becomes invalid after the call! Parameters: fileName [string in], name of the new project file (*.iwp) containing drive and directory name.
Close()	void	Closes the project.
Export(string fileName)	void Exception in case of error.	The project is exported via this method. Parameters: fileName [string in], file name (including path information) of the export file (*.iwx) created during export.
Import(string fileName, string mode)	void Exception in case of error.	This method is used to reimport the data of a project created earlier with "Project.Export". Parameters: fileName [string in], file name (including path information) of the export file (*.iwx or *.xml for the previous format) whose data is to be imported. Parameters: mode [string in, mode = "Insert" or "Replace"], import mode indicates whether the data to be imported should be inserted ("Insert") or whether already existing data should be replaced ("Replace"). The parameter is not evaluated for the previous export format (*.xml). Please set the parameter to "None".

## Basic Objects

Method	Type	Description
CreateChild(string type, object args)	Rexroth.IndraWorks.Automation.ProjectElement	<p>This method can be used to create a ProjectElement either of type "file" or "folder" or a system-specific device as child of the project node. Proceed as follows to create a new ProjectElement:</p> <p><b>Creating a file:</b>  type = "File".  args = Complete file name to be added as string.  If a zero or an empty string is transferred, a file selection dialog appears in the Engineering desktop that can be used to select a file to be added.</p> <p><b>Creating a folder:</b>  type = "Folder"  args = Name of the new folder as string.  If a zero or an empty string is transferred, the name of the new folder is assigned automatically.</p> <p><b>Creating a system-specific device:</b>  type = &lt;Device type identifier (string) of the device to be newly created&gt;  args = Use the AI documentation of the corresponding device to check how this parameter is to be assigned.</p>
DeleteChild(string id)	bool	<p>Deletes a child project element with the given ID ("MnO Guid" is the internal identifier for this ID in IndraWorks).</p> <p>Parameters: id [string in]: ID (guid) of the child project element to be deleted.</p>
GetChildrenOfType(string objectType, bool recurse)	Rexroth.IndraWorks.Automation.AiCollection	<p>Provides a collection of all project elements of the type specified. The collection contains references of the types Rexroth.IndraWorks.Automation.IDevice, Rexroth.IndraWorks.Automation.IFile, Typ Rexroth.IndraWorks.Automation.IFolder or types of system-specific devices.</p> <p>Parameters: objectType [string in], type string of the project elements searched for. The basic types are "File", "Folder" and "Device". If system-specific devices such as MTX, MLC, IndraLogic or HMI exist, they can be determined using the respective type string.</p> <p>Parameters: recurse [bool in],</p> <p>True: All project elements are taken into account during the search  False: Only the project elements located on the first level below the project node are taken into account during the search.</p> <p>For an example code, please refer to: <a href="#">Chapter 5.5 Example Code - Searching in Projects, page 31</a>.</p>

## Basic Objects

Method	Type	Description
GetElement(string id)	Rexroth.IndraWorks.Automation.ProjectElement	Provides the reference to the project element with the given ID ("MnO Guid" is the internal identifier in IndraWorks for this ID). Parameters: id [string in]: ID (guid) of the project element searched for.
Validate(Scripting.Dictionary validateArgs)	string	The project data is subject to a plausibility check. Obvious discrepancies can thus be detected and eliminated. Important: This check cannot verify the correctness of all project data!  The feedback about the check result is given as string in XML format. The nodes "Errors", "Warnings" und "Information" return the number of the respective messages. If "Cancelled" is equal to 'True', the check was aborted. The messages found are stored under "Messages". A message is described by its attributes. They corresponds to the columns of the message window in the IndraWorks Engineering desktop: Type - Message type "Error", "Warning", "Info" Id - Message ID Text - Message text Element - Name of the project element Position - Optional: e.g. line and column specification if the project element is a source text Path - Relative project path  Parameters: validateArgs [System.Dictionary, in], in a Scripting.Dictionary, key/value pairs can be transferred as optional parameters. An empty table corresponds to a validation function as it can be started at the project node via the context menu item. If special function should be checked, they can be controlled via special key/value parameters. In this case, the names of the keys and the meaning of the respective values of the documentations (System Description) can be found in the respective project elements.  For an example code, please refer to: Chapter 5.9 <a href="#">Example Code - Validating a Project</a> , page 36.

```
<?xml version="1.0" encoding="UTF-8" ?>
- <ValidationResults xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  - <Messages>
    <Message Type="Info" Id="PKG-00000007" Text="The element is on the 1. level of the project!" Element="Sample 1" Position="" Path="Sample 1" />
    <Message Type="Error" Id="PKG-00004711" Text="Element is deactivated!" Element="Sample 1" Position="" Path="Sample 1" />
    <Message Type="Info" Id="PKG-00071030" Text="The name "AAA" is not unique!" Element="AAA" Position="Ln 12345 Col 67" Path="Ordner/AAA" />
    <Message Type="Info" Id="PKG-00071030" Text="The name "AAA" is not unique!" Element="AAA" Position="" Path="Ordner/AAA" />
  </Messages>
  <Errors>1</Errors>
  <Warnings>0</Warnings>
  <Informations>3</Informations>
  <Cancelled>False</Cancelled>
</ValidationResults>
```

Fig. 4-2: Project.Validate(..): Return format of the check results

## 4.5 Object - ProjectElement

**ProjectElement** is a basic class of the Automation Interface. This basic class is used by the objects **Device**, **File** and **Folder** as well as by all system-specific devices such as MLC, MTX and IndraLogic. This means that these objects can be used to access all attributes of the basic class **ProjectElement**.

The basic class **ProjectElement** provides a series of attributes that can be used to navigate through the project.

If there are system-specific devices such as MTX, MLC or IndraLogic under the current **ProjectElement**, the **GetChildrenOfType** method and the respective type string can be used to determine a reference to these objects. This refer-

Basic Objects

ence can be used to access the extended functionality of the system-specific devices.

Child ProjectElements can be created/deleted using the **CreateChild** and **DeleteChild** methods.

The **Export** method can export all ProjectElement data including the data of all child elements (if these support an export) to an export file.

The **Import** method can reimport the data from an export file to the ProjectElement or its child elements.

The **SupportsExportImport** attribute can be used to query whether the export/import is supported by this ProjectElement.

The **Parent** attribute can be used to determine the parent node. The attribute **Children** provides a collection of all child project elements of the first level and the assigned project can be determined via **OwnerProject**.

**Attributes of "ProjectElement"**

Attributes	Type	Description
Name	string	Read/write. Project element name (display name).
Id	string	Read-only. Unique project element ID (guid).
Location	string	Read-only. Directory path under which the project element is saved.
OwnerProject	Rexroth.IndraWorks.Automation.Project	Read-only. Reference to the project to which the project element is assigned.
Parent	Rexroth.IndraWorks.Automation.ProjectElement	Read-only. Reference to the parent project element. Zero is returned if the parent element is the project node.
Children	Rexroth.IndraWorks.Automation.AiCollection	Read-only. Provides a collection of all children of the first level. The collection contains references of the types Rexroth.IndraWorks.Automation.IDevice, Rexroth.IndraWorks.Automation.IFile, Type Rexroth.IndraWorks.Automation.IFolder or types of system-specific devices.
SupportsExportImport	bool	Read-only. Provides information whether the ProjectElement supports the "Export" and "Import" functionalities. True: Export/Import is supported. False: Export/Import is not supported.
SupportsValidate	bool	Read-only. Provides information whether the project element supports the "Validate" functionality. True: "Validate" is supported. False: "Validate" is not supported.

## Basic Objects

## ProjectElement methods

Method	Type	Description
Export(string fileName)	void Exception in case of error.	The project element data and all subordinate project elements supporting an export are exported using this method. <b>Caution:</b> This method is not supported by each ProjectElement! Check before whether this method is supported using the "ProjectElement.SupportsExportImport" attribute. Parameters: fileName [string in], file name (including path information) of the export file (*.iwx) created during export.
Import(string fileName, string mode)	void Exception in case of error.	This method re-imports export file data that was created earlier with "ProjectElement.Export". <b>Caution:</b> This method is not supported by each ProjectElement! Check before whether this method is supported using the "ProjectElement.SupportsExportImport" attribute. Parameters: fileName [string in], file name (including path information) of the export file (*.iwx) whose data should be imported. Parameters: mode [string in, mode = "Insert" or "Replace"], import mode indicates whether the data to be imported should be inserted ("Insert") or whether already existing data should be replaced ("Replace").
CreateChild(string type, object args)	Rexroth.IndraWorks.Automation.ProjectElement	This method can be used to create a ProjectElement of the types "File" or "Folder" or a system-specific device as child of the current ProjectElement. Proceed as follows to create a new ProjectElement: <b>Creating a file:</b> type = "File". args = Complete file name to be added as string. If a zero or an empty string is transferred, a file selection dialog appears in the Engineering desktop that can be used to select a file to be added. <b>Creating a folder:</b> type = "Folder" args = Name of the new folder as string. If a zero or an empty string is transferred, the name of the new folder is assigned automatically. <b>Creating a system-specific device:</b> type = <Device type identifier (string) of the device to be newly created> args = Use the AI documentation of the corresponding device to check how this parameter is to be assigned.
DeleteChild(string id)	bool	Deletes a child project element with the given ID ("MnO Guid" is the internal identifier for this ID in IndraWorks). Parameters: id [string in]: ID (guid) of the child project element to be deleted.

Basic Objects

Method	Type	Description
GetChildrenOf- Type(string object- Type, bool recurse)	Rexroth.IndraWorks.A utomation.AiCollection	Provides a collection of all project elements of the type specified. The collection contains references of the types Rexroth.IndraWorks.Automation.IDevice, Rexroth.IndraWorks.Automation.IFile, Type Rexroth.IndraWorks.Automation.IFolder or types of system-specific devices.  Parameters: objectType [string in], type string of the project elements searched for. The basic types are "File", "Folder" and "Device". If system-specific devices such as MTX, MLC, IndraLogic or HMI exist, they can be determined using the respective type string.  Parameters: recurse [bool in],  True: All project elements are taken into account during the search  False: Only the project elements located on the first level below the project node are taken into account during the search.
Validate(Scripting.Dic- tionary validateArgs)	string	The project element data and all subordinate project elements are subject to a plausibility check. Obvious discrepancies can thus be detected and eliminated. Important: This check cannot verify the correctness of all project data!  Call parameter of the return value: see object "Project", method "Validate"  <b>Caution:</b> This method is not supported by each ProjectElement! Check before if this method is supported using the "ProjectElement.SupportsValidate" attribute.

## 4.6 Object - Device (Derived from ProjectElement)

The **Device** object represents a project element of the **Device** type, i.e. a device in an IndraWorks project.

The methods of the object can be used to go online or offline with the device. The "IsOnline" attribute can be used to query whether the device is currently in online mode.

In addition, all attributes and methods of the basic class **ProjectElement** are available in the **Device** context.

### Attributes of "Device"

Attributes	Type	Description
IsOnline	bool	Read-only. Provides information whether the device is online or offline. Provides "true" if the device is online and "false" if it is offline.

### Methods of "Device"

Method	Type	Description
GoOnline()	void	Switches the device to online mode.  Use the device-specific AI documentation to check whether this function is available for the device.
GoOffline()	void	Switches the device to offline mode.  Use the device-specific AI documentation to check whether this function is available for the device.

For an example code, please refer to: Chapter [5.6 Example Code - Access to Devices](#), page 33.

## Basic Objects

## 4.7 Object - File (Derived from ProjectElement)

The **File** object represents a project element of the **File** type, i.e. a file in an IndraWorks project.

The **FileName** attribute can be used to read the file name.

In addition, all attributes and methods of the basic class **ProjectElement** are available in the **File** context.

### Attributes of "File"

Attributes	Type	Description
FileName	string	Read-only. File name.

For an example code, please refer to: [5.4 Example Code - Adding Folders and Files, page 30](#).

## 4.8 Object - Folder (Derived from ProjectElement)

The **Folder** object represents a project element of the **Folder** type, i.e. a directory in an IndraWorks project.

In addition, all attributes and methods of the basic class **ProjectElement** are available in the **File** context.

For an example code, please refer to: Chapter [5.4 Example Code - Adding Folders and Files, page 30](#).

## 4.9 Object - AiCollection

The **AiCollection** object is an unsorted list of objects that can be read according to the following attributes and methods.

### Attributes of "AiCollection"

Attributes	Type	Description
Count	int	Read-only. Provides the number of objects.
Current	object	Read-only. Provides the currently selected object.
this[int]	object	Read-only. Indexer. Parameters: Index [int in], index (basis 0) in the collection.

### Methods of "AiCollection"

Method	Type	Description
GetEnumerator()	System.Collections.IE-numerator	Provides an enumerator.
Contains(object item)	bool	Checks whether the specified object is located in the collection. True: The object searched for is located in the collection. False: The object is not located in the collection.

For an example code, please refer to: Chapter [5.5 Example Code - Searching in Projects, page 31](#).

## 4.10 Object - AiList

The **AiList** object is an unsorted list of objects that can be read according to the following attributes and methods. In contrast to the "AiCollection", the "AiList"

## Basic Objects

object allows objects to be added to the list or to be removed from it using the methods **Add()** and **Remove()**.

**Attributes of "AiList"**

Attributes	Type	Description
Count	int	Read-only. Provides the number of objects.
Current	object	Read-only. Provides the currently selected object.
this[int]	object	Read-only. Indexer. Parameters: Index [int in], index (basis 0) in the collection.

**Methods of "AiList"**

Method	Type	Description
Add(object value)	int	Adds a new object to the list and returns the index at which the object was inserted.
Remove(object value)	void	Removes the first object that is identical to the object specified in the list.
GetEnumerator()	System.Collections.IE-numerator	Provides an enumerator.
Contains(object item)	bool	Checks whether the specified object is located in the collection. True: The object searched for is located in the collection. False: The object is not located in the collection.



## 5 Example Codes - Basic Objects

### 5.1 Example code - Initializing the Automation Interface

#### AI initialization

*Program:*

---

```
<html>
<body>
  <script language = "JavaScript">
    try
    {
      //Get Application object of Automation Interface
      var Application = window.external;

      //Alternatively: Initialization of Application object,
      //this forces an Internet Explorer Security Dialog
      //var Application = new ActiveXObject
      //  ("Rexroth.IndraWorks.Automation.Application");

      //Initialize Automation Interface (Connect to Automation Server)
      Application.Connect("localhost", "automation");

      //
      //ToDo: Access Project data
      //
    }
    catch (e)
    {
      //Show Exception
      alert(e + ", " + e.message);

      //Disconnect from Automation Server
      Application.Disconnect();
    }
  </Script>
</Body>
</html>
```

---

### 5.2 Example Code - Creating an IndraWorks Project

#### Initializing the AI and creating a project

*Program:*

---

```
<html>
<body>
  <script language = "JavaScript">
    try
    {
      //Get Application object of Automation Interface
      var Application = window.external;

      //Alternatively: Initialization of Application object,
      //this forces an Internet Explorer Security Dialog
      //var Application = new ActiveXObject("Rexroth.IndraWorks.Automation.Application");

      //Initialize Automation Interface (Connect to Automation Server)
      Application.Connect("localhost", "automation");

      //Get Project Manager
      var ProjectManager = Application.ProjectManager;

      //Create Project
      var Project = ProjectManager.CreateProject
      ("C:\\AI-Test\\MyProject_001\\MyProject_001.iwp");

      //
      //ToDo: Access Project data
      //
    }
    catch (e)
```

---

## Example Codes - Basic Objects

```

{
  //Show Exception
  alert(e + ", " + e.message);

  //Disconnect from Automation Server
  Application.Disconnect();
}
<Script>
<Body>
<html>

```

---

## 5.3 Example Code - Opening an IndraWorks Project

Initializing the AI and opening a project

*Program:*

```

<html>
<body>
<script language = "JavaScript">
  try
  {
    //Get Application object of Automation Interface
    var Application = window.external;

    //Alternatively: Initialization of Application object,
    //this forces an Internet Explorer Security Dialog
    //var Application = new ActiveXObject
    //("Rexroth.IndraWorks.Automation.Application");

    //Initialize Automation Interface (Connect to Automation Server)
    Application.Connect("localhost", "automation");

    //Get Project Manager
    var ProjectManager = Application.ProjectManager;

    //Create Project
    var Project = ProjectManager.OpenProject
    ("C:\\AI-Test\\MyProject_001\\MyProject_001.iwp");

    //
    //ToDo: Access Project data
    //
  }
  catch (e)
  {
    //Show Exception
    alert(e + ", " + e.message);

    //Disconnect from Automation Server
    Application.Disconnect();
  }
</Script>
</Body>
</html>

```

---

## 5.4 Example Code - Adding Folders and Files

Creating folders and files in a project

*Program:*

```

<html>
<body>
<script language = "JavaScript">
  try
  {
    //Get Application object of Automation Interface
    var Application = window.external;

    //Alternatively: Initialization of Application object, this forces an
    //Internet Explorer Security Dialog
    //var Application = new ActiveXObject("Rexroth.IndraWorks.Automation.Application");

    //Initialize Automation Interface (Connect to Automation Server)
    Application.Connect("localhost", "automation");
  }

```

## Example Codes - Basic Objects

```

//Get Project Access (use Example Code for creating "MyProject_001" before)
var CurrentProject;
var OpenProjects = Application.ProjectManager.Projects;
for(var prjElements = new Enumerator(OpenProjects);
!prjElements.atEnd(); prjElements.moveNext())
{
    CurrentProject = prjElements.item();
    break;
}
if(( CurrentProject == null) || ( CurrentProject.Name != "MyProject_001"))
{
    CurrentProject = Application.ProjectManager.OpenProject
    ("C:\\AI-Test\\MyProject_001\\MyProject_001.iwp");
}

//Create a new Folder with name "MyRootFolder" as child of Project node
var RootFolder = CurrentProject.CreateChild("Folder", "MyRootFolder");

//Create 20 further folders as Children of RootFolder and set names
var ChildFolder;
for( var i=1; i<21; i++)
{
    ChildFolder = RootFolder.CreateChild("Folder", "MyRootFolder_" + i);
}

//Create (Add) a File as a child of the Project node (FileOpen Dilaog will open)
CurrentProject.CreateChild("File", null);

//Create (Add) some Files as Child of CurrentProject (!!!no FileOpen Dialog!!!)
CurrentProject.CreateChild("File",
    ".\\ATLHost.dll");
CurrentProject.CreateChild("File",
    ".\\Indraworks.Automation.dll");
CurrentProject.CreateChild("File",
    ".\\IndraWorks.AutomationServer.dll");
CurrentProject.CreateChild("File",
    ".\\Indraworks.AutomationServer.Interfaces.dll");
CurrentProject.CreateChild("File",
    ".\\IndraWorks.FilePackage.dll");
CurrentProject.CreateChild("File",
    ".\\IndraWorks.Formatter.dll");

//Create (Add) a File as a child of the RootFolder (FileOpen Dilaog will open)
RootFolder.CreateChild("File", null);

//Create (Add) some Files as Child of RootFolder (!!!no FileOpen Dialog!!!)
RootFolder.CreateChild("File", ".\\ATLHost.dll");
RootFolder.CreateChild("File", ".\\Indraworks.Automation.dll");
RootFolder.CreateChild("File", ".\\IndraWorks.AutomationServer.dll");

//
//ToDo: Access Project data
//
}
catch (e)
{
    //Show Exception
    alert(e + ", " + e.message);

    //Disconnect from Automation Server
    Application.Disconnect();
}
</Script>
</Body>
</html>

```

## 5.5 Example Code - Searching in Projects

### Searching in a project

*Program:*

```

<html>
<body>
<script language = "JavaScript">
    try
    {
        //Get Application object of Automation Interface

```

## Example Codes - Basic Objects

```

var Application = window.external;

//Alternatively: Initialization of Application object, this forces an
//Internet Explorer Security Dialog
//var Application = new ActiveXObject
//("Rexroth.IndraWorks.Automation.Application");

//Initialize Automation Interface
//Connect to Automation Server
Application.Connect("localhost", "automation");

//Get Project Access
//use Example Code for creating "MyProject_001" before)
var CurrentProject;
var OpenProjects = Application.ProjectManager.Projects;
for(var prjElements = new Enumerator
    (OpenProjects);
    !prjElements.atEnd(); prjElements.moveNext())
{
    CurrentProject = prjElements.item();
    break;
}
if(( CurrentProject == null) ||
    ( CurrentProject.Name != "MyProject_001"))
{
    CurrentProject = Application.ProjectManager.OpenProject
    ("C:\\AI-Test\\MyProject_001\\MyProject_001.iwp");
}

//
//Note: The Examples for creating files, folders and devices
//should be executed before this example in order to have
//some data available.
//

//-----
//Get children (first level) of current project
//-----
var Children = CurrentProject.Children;

//Show children
var childElements = new Enumerator(Children);
var child;
document.write("Children (first level) of Project:<br>");
document.write("=====<br>");
for(; !childElements.atEnd(); childElements.moveNext())
{
    child = childElements.item();
    document.write("Name: '" + child.Name +
        "' | Type: '" + child.ObjectType + "'<br>");
}

//-----
//Get all children of type "File", scan all nodes of project
//-----
Children = CurrentProject.GetChildrenOfType("File", true);

//Show children
childElements = new Enumerator(Children);
document.write("<br>All Files of Project:<br>");
document.write("=====<br>");
for(; !childElements.atEnd(); childElements.moveNext())
{
    child = childElements.item();
    document.write("Name: '" + child.Name +
        "' | Type: '" + child.ObjectType + "'<br>");
}

//-----
//Get all children of type "Folder", scan all nodes of project
//-----
Children = CurrentProject.GetChildrenOfType("Folder", true);

//Show children
childElements = new Enumerator(Children);
document.write("<br>All Folders of Project:<br>");
document.write("=====<br>");
for(; !childElements.atEnd(); childElements.moveNext())
{
    child = childElements.item();

```

Example Codes - Basic Objects

```
        document.write("Name: '" + child.Name +
            "' | Type: '" + child.ObjectType + "'<br>");
    }

    //-----
    //Get children (first level) of type "Device"
    //-----
    Children = CurrentProject.GetChildrenOfType("Device", false);

    //Show children
    childElements = new Enumerator(Children);
    document.write("<br>Devices (first level) of Project:<br>");
    document.write("=====<br>");
    for(; !childElements.atEnd(); childElements.moveNext())
    {
        child = childElements.item();
        document.write("Name: '" + child.Name +
            "' | Type: '" + child.ObjectType + "'<br>");
    }

    //
    //ToDo: Access Project data
    //
}
catch (e)
{
    //Show Exception
    alert(e + ", " + e.message);

    //Disconnect from Automation Server
    Application.Disconnect();
}
</Script>
</Body>
</html>
```

---

## 5.6 Example Code - Accessing Devices

Accessing devices (= device-specific AI extension

*Program:*

---

```
<html>
<body>
<script language = "JavaScript">
    try
    {
        //Get Application object of Automation Interface
        var Application = window.external;

        //Alternatively: Initialization of Application object, this forces an
        //Internet Explorer Security Dialog
        //var Application = new ActiveXObject
        //("Rexroth.IndraWorks.Automation.Application");

        //Initialize Automation Interface (Connect to Automation Server)
        Application.Connect("localhost", "automation");

        //Get Project Access (use Example Code for creating "MyProject_001" before)
        var CurrentProject;
        var OpenProjects = Application.ProjectManager.Projects;
        for(var prjElements = new Enumerator(OpenProjects);
            !prjElements.atEnd(); prjElements.moveNext())
        {
            CurrentProject = prjElements.item();
            break;
        }
        if(( CurrentProject == null) || ( CurrentProject.Name != "MyProject_001"))
        {
            CurrentProject = Application.ProjectManager.OpenProject
            ("C:\\AI-Test\\MyProject_001\\MyProject_001.iwp");
        }

        //-----
        //Get Device with Type name "MtxTestDevice_V001"
        //This example will cause an Exception cause the given tpestring is
        //not a valid one. Do use this code to query for a valid tpestring
        //of a device like MTX, HMI, IL or MLC.
        //-----
    }
}
```

## Example Codes - Basic Objects

```

Children = CurrentProject.GetChildrenOfType("MtxTestDevice_V001", true);

//Show children of Type "MtxTestDevice_V001"
if( Children.Count == 0)
{
    alert("No ProjectElements of type 'MtxTestDevice_V001' found!");
}
else
{
    childElements = new Enumerator(Children);
    document.write("<br>All Files of Project:<br>");
    document.write("=====<br>");
    for( ; !childElements.atEnd(); childElements.moveNext())
    {
        child = childElements.item();
        document.write("Name: ' " + child.Name +
            "' | Type: ' " + child.ObjectType + "'<br>");
    }
}

//
//ToDo: Access Project data
//

}
catch (e)
{
    //Show Exception
    alert(e + ", " + e.message);

    //Disconnect from Automation Server
    Application.Disconnect();
}
</Script>
</Body>
</html>

```

## 5.7 Example Code - Archiving a Project

### Creating an IndraWorks project archive (\*.zip)

*Program:*

```

<html>
<body>
<script language = "JavaScript">
try
{
    //Get Application object of Automation Interface
    var Application = window.external;

    //Alternatively: Initialization of Application object, this forces
    //an Internet Explorer Security Dialog
    //var Application = new ActiveXObject
    //("Rexroth.IndraWorks.Automation.Application");

    //Initialize Automation Interface (Connect to Automation Server)
    Application.Connect("localhost", "automation");

    //Get Project Manager
    var ProjectManager = Application.ProjectManager;

    try
    {
        //-----
        //Archive Project 'IndraWorksProject_001'
        //-----
        //Create Scripting.Dictionary object
        var archiveArgs = new ActiveXObject("Scripting.Dictionary");

        //Add the archive arguments as Key-/Value- pairs
        archiveArgs.Add('ProjectFile',
            'D:\\Projects\\IndraWorksProject_001\\IndraWorksProject_001.iwp');
        archiveArgs.Add('ArchiveFile', 'C:\\IWArchive_001.zip');
        archiveArgs.Add('ArchiveComment', 'Das ist der Archiv Kommentar...');
        archiveArgs.Add('Password', 'MyPassword-123');
        archiveArgs.Add('CloseProject', 'True');

        //Do Archive process
        ProjectManager.ArchiveProject( archiveArgs);
    }
}
}

```

```
    }  
    catch (e)  
    {  
        //Show Exception  
        alert(e + ", " + e.message);  
  
        //  
        //ToDo: Exception handling  
        //  
    }  
} catch (e)  
{  
    //Show Exception  
    alert(e + ", " + e.message);  
  
    //Disconnect from Automation Server  
    Application.Disconnect();  
}  
</Script>  
</Body>  
</html>
```

---

## 5.8 Example Code - Restoring a Project

Restoring an IndraWorks project from a project archive (\*.zip)

*Program:*

---

```
<html>  
<body>  
  <script language = "JavaScript">  
    try  
    {  
        //Get Application object of Automation Interface  
        var Application = window.external;  
  
        //Alternatively: Initialization of Application object, this forces  
        //an Internet Explorer Security Dialog  
        //var Application = new ActiveXObject  
        //("Rexroth.IndraWorks.Automation.Application");  
  
        //Initialize Automation Interface (Connect to Automation Server)  
        Application.Connect("localhost", "automation");  
  
        //Get Project Manager  
        var ProjectManager = Application.ProjectManager;  
  
        try  
        {  
            //-----  
            //Restore IndraWorks Project Archive 'IWArchive_001.zip'  
            //-----  
            //Create Scripting.Dictionary object for restore parameters  
            var restoreArgs = new ActiveXObject("Scripting.Dictionary");  
  
            //Add the restore arguments as Key-/Value- pairs  
            restoreArgs.Add('ArchiveFile', 'C:\\IWArchive_001.zip');  
            restoreArgs.Add('RestoreDir', 'D:\\Projects');  
            restoreArgs.Add('NewProjectName', 'IndraWorksProject_001_NewName');  
            restoreArgs.Add('Password', 'MyPassword-123');  
            restoreArgs.Add('OpenProject', 'True');  
  
            //Do Restore process  
            ProjectManager.RestoreProject( restoreArgs);  
        }  
        catch (e)  
        {  
            //Show Exception  
            alert(e + ", " + e.message);  
  
            //  
            //ToDo: Exception handling  
            //  
        }  
    }  
    catch (e)  
    {  
        //Show Exception  
        alert(e + ", " + e.message);  
    }  
  }  
</script>  
</body>  
</html>
```

## Example Codes - Basic Objects

```

    //Disconnect from Automation Server
    Application.Disconnect();
}
</Script>
</Body>
</html>

```

## 5.9 Example Code - Validating a Project

Executing a default validation for a project with subsequent result output

*Program:*

```

<html>
  <body>
    <script language = "JavaScript">

      var xmlDoc = new ActiveXObject("Microsoft.XMLDOM");
      try
      {
        debugger;

        //Get Application object of Automation Interface
        var Application = window.external;

        //Alternatively: Initialization of Application object,
        // this forces an Internet Explorer Security Dialog
        //var Application = new ActiveXObject("Rexroth.IndraWorks.Automation.Application");

        //Initialize Automation Interface (Connect to Automation Server)
        Application.Connect("localhost", "automation");

        var CurrentProject;
        var OpenProjects = Application.ProjectManager.Projects;
        for(var prjElements=new Enumerator(OpenProjects); !prjElements.atEnd(); prjElements.moveNext())
        {
          CurrentProject = prjElements.item();
          break;
        }

        document.write("<b>Scanning project elements =====</b><br>");
        var thisMnODoesntSupportValidate;
        for(var mnos = new Enumerator(CurrentProject.Children); !mnos.atEnd(); mnos.moveNext())
        {
          var mno = mnos.item();
          document.write("'" + mno.Name + "': ");
          if (mno.SupportsValidate == false)
          {
            thisMnODoesntSupportValidate = mno; //Take the last element found
            document.write("NOT ");
          }
          document.write("supported<br>");
        }
        document.write("<br>");

        //-----
        //Do validation for ProjectNode
        //-----
        document.write("<b>Validation of '" + CurrentProject.Name + "' =====</b><br>");

        //Create Scripting.Dictionary object
        var args = new ActiveXObject("Scripting.Dictionary");

        //Add the arguments as Key-/Value- pairs
        args.Add("PKG-FirstLevelDevice", "");
        //This is a key used in the platform SamplePackage (PKG)

        var result;
        var errorCode = 0;
        var errorsFound = 0;
        var cancelled = 0;
        try
        {
          result = CurrentProject.Validate(args);
        }
        catch (exception)
        {
          errorCode = exception.number;
          document.write("ErrorCode=" + errorCode + "<br>");
          errorsFound = errorCode & 0x0080;
        }
      }
    </script>
  </body>
</html>

```

## Example Codes - Basic Objects

```

        cancelled = errorCode & 0x0001;
        result = exception.message;
    }
    if (errorsFound != 0)
    {
        document.write(" Error(s) found!" + "<br>");
    }
    if (cancelled != 0)
    {
        document.write(" Validation aborted!" + "<br>");
    }

    //Store the XML result to a file
    var fso = Application.CreateComInstance("Scripting.FileSystemObject");
    var xmlFile = "c:\\\\ValidationResults.xml";
    var fh = fso.CreateTextFile(xmlFile, true);
    fh.WriteLine(result);
    fh.Close();

    //Show XML result
    document.write("Returned XML values: -----<br>");

    xmlDoc.loadXML(result);
    var childNodes = xmlDoc.documentElement.childNodes;
    var xmlNodes = new Enumerator(childNodes);
    var xmlElement;
    var xmlMessages;
    for( ; !xmlNodes.atEnd(); xmlNodes.moveNext() )
    {
        xmlElement = xmlNodes.item();
        if (xmlElement.nodeName == "Messages")
        {
            xmlMessages = xmlElement;
        }
        else
        {
            //Errors, Warnings,...
            document.write(xmlElement.nodeName + "=" + xmlElement.text + "<br>");
        }
    }

    document.write("Messages:<br>");
    xmlNodes = new Enumerator(xmlMessages.childNodes);
    for( ; !xmlNodes.atEnd(); xmlNodes.moveNext() )
    {
        xmlElement = xmlNodes.item();
        document.write(
            ""
            + xmlElement.getAttribute("Type") + " ' ' "
            + xmlElement.getAttribute("Id") + " ' ' "
            + xmlElement.getAttribute("Text") + " ' ' "
            + xmlElement.getAttribute("Element") + " ' ' "
            + xmlElement.getAttribute("Position") + " ' ' "
            + xmlElement.getAttribute("Path") + " '<br>");
    }

    //Now validate a project element --> we expect an InvalidOperationException
    try
    {
        if (thisMnODoesntSupportValidate != null)
        {
            document.write(
                "<br><b>Validation of a project element that doesn't support validation =====</b><br>");
            result = thisMnODoesntSupportValidate.Validate(args); //Start validation
        }
    }
    catch (exception)
    {
        //catch InvalidOperationException
        document.write("Expected InvalidOperationException:<br>");
        document.write("ErrorCode = " + exception.number + "<br>");
        document.write("Message = " + exception.message);
    }
}
catch (e)
{
    document.write("<br><br>!!!!!! Exception occured in JavaScript !!!!!!!:<br>");
    document.write("Error name=" + e.name + "<br>");
    document.write("Error code=" + e.number + "<br>");
    document.write("Error message=" + e.message + "<br>");

    //Disconnect from Automation Server
    Application.Disconnect();
}

```

## Example Codes - Basic Objects

```
    }  
  </Script>  
</Body>  
</html>
```

---

## 6 XLC/MLC Objects

### 6.1 Object Model

The object hierarchy of the Automation Interface for the XLC/MLC objects is shown in the following diagram.

The objects shown in the diagram are system-specific XLC/MLC objects, the **Device** object shown in beige is part of the **Basis Automation Interface**.




Fig. 6-1: Object model: Object Device of the Basis Automation Interfaces and the assigned XLC/MLC objects

### 6.2 Object - XLC (Derived from Device)

The **XLC** object represents a device of the **XLC** type, i.e. a system-specific device within an IndraWorks project.

The object **XLC** is derived from the **Device** object. Therefore, it provides all the attributes and methods of this object. This includes for example the attribute **IsOnline** as well as the methods **GoOnline** and **GoOffline**.

The **Logic** object below the **XLC** can be accessed using **GetObject**.

## XLC/MLC Objects

## Attributes of XLC

Attribute	Type	Description
IsMultiDeviceEnabled	bool	Read-only. Returns the information whether the multi-device functionality is used. True: Multi-device is used. False: Multi-device is not used.
IsOnline	bool	Read-only, inherited from "Device". True: XLC in the IndraWorks project is connected to a physical XLC. False: No connection between XLC in the IndraWorks project and the physical XLC.
MultiDeviceTable	object	Read-only. Returns a reference to the XLC-internal object "MultiDeviceTable".

## Methods of XLC

Method	Type	Description
ClearErrors()	void	Deletes all errors on the control and in the connected SERCOS drives. Therefore, the XLC must be in "online" state.
DisableMultiDevice()	void	Do not use the multi-device functionality. If the multi-device functionality cannot be disabled, an exception is thrown.
DownloadFirmware(string fileName)	void	Loads the firmware in the "fileName" file to the control. Therefore, the XLC has to be in download mode (SERCOS phase P0) and the PLC has to be stopped. Parameters: fileName [string], contains the complete name and path of a firmware file of type "FW". Example: "C:\FW\CML65s-XLs-12T01.0040.fw"
EnableMultiDevice()	void	Using multi-device functionality. The XLC may neither be in "online" state nor in "logged in" state. If the multi-device functionality cannot be used because the XLC is in "online" state and/or "logged in", an exception is thrown.
GetObject(string object)	object	Returns a reference to an object assigned to an XLC. If the requested object is not known, an exception is thrown. Parameters: Object [string], string of the searched object. Currently, only "Logic" is available as object.
GetPhase()	int	Returns the current SERCOS phase. Therefore, the XLC must be in "online" state. If the phase cannot be read, since the XLC is not in "online" state for example, an exception is thrown.
GoOffline()	void	Inherited from "Device". Cancels a connection between the XLC in the IndraWorks project and a physical XLC. If it cannot be gone offline, an exception is thrown.
GoOnline()	void	Inherited from "Device". Establishes a connection between the XLC in the IndraWorks project and a physical XLC. If the online connection cannot be established, since the PLC should be stopped or the planned drive configuration does not match, the connection established is aborted and an exception is thrown.

## XLC/MLC Objects

Method	Type	Description
ImportParameter(string fileName)	string	<p>Imports the SERCOS parameters in the "fileName" file. Therefore, the XLC must be in "online" state.</p> <p>Possible writing errors such as "date and time write-protected" are collected by the method and returned as string at the end of the parameter import. The line format is "IDN ParameterName Result".</p> <p>Parameters:</p> <p>fileName [string], contains the complete name and path of the file to be imported of type "PAR". Example: "C:\Archive\Parameters.par"</p>
ImportParameter2(string fileName, Scripting.Dictionary args)	string	<p>Imports the SERCOS parameters in the "fileName" file. Therefore, the XLC must be in "online" state. In contrast to "ImportParameter", it has to be specified which parameter types should be imported in which axes (or controls).</p> <p>Possible writing errors such as "date and time write-protected" are collected by the method and returned as string at the end of the parameter import. The line format is "IDN ParameterName Result".</p> <p>Parameters:</p> <p>fileName [string], contains the complete name and path of the file to be imported of type "PAR". Example: "C:\Archive\Parameters.par"</p> <p>args [System.Dictionary]</p> <p>All specific parameter specifications on the parameter import are transferred to a System.Dictionary object. The following keys and values are available.</p> <p>Key: "C-ParameterImportListByNumber" [string], (control parameters).</p> <p>Value: [string] [optional parameter]</p> <p>Contains the parameter file "C-parameters". If the C-parameters should be imported, the string "*-&gt;*" has to be specified. If the key "C-ParameterImportListByNumber" is not specified or an empty string "" is specified (default value), the C-parameters are not loaded. If the parameter file does not contains any C-parameters, the specification is ignored.</p> <p>Example (JavaScript):</p> <pre>args.Add("C-ParameterImportListByNumber", "*-&gt;*");</pre> <p>Loads the C-parameters from the parameter file to the control.</p> <p>Example (JavaScript):</p> <pre>args.Add("C-ParameterImportListByNumber", "");</pre> <p>Causes the C-parameters in the parameter file not to be loaded.</p> <p>Key: "M-ParameterImportListByNumber" [string] (touch probe parameters).</p> <p>Value: [string] [optional parameter]</p> <p>Same behavior as "C-ParameterImportListByNumber"</p> <p>Key: "O-ParameterImportListByNumber" [string] (oscilloscope parameters).</p> <p>Value: [string] [optional parameter]</p> <p>Same behavior as "C-ParameterImportListByNumber"</p>

## XLC/MLC Objects

Method	Type	Description
ImportParameter2(string fileName, Scripting.Dictionary args) (Continuation)	string	<p>Key: "A-ParameterImportListByNumber" [string] (drive-related parameters in the control). Value: [string] [optional parameter]</p> <p>Contains the parameter file "A-parameters" and if the A-parameters should be loaded, the axis numbers on which the A-parameters are to be loaded can be specified with a comma-separated list. Ranges can also be defined with "-". A-parameters are not loaded with "" (default value). If the key "A-ParameterImportListByNumber" is not specified, the A-parameters in the parameter file are not loaded. If the parameter file does not contains any A-parameters, the specification is ignored.</p> <p>Example (JavaScript):</p> <pre>args.Add("A-ParameterImportListByNumber", "1-&gt;1; 2-&gt;2,3-6,8");</pre> <p>Loads the A-parameters from the parameter file for the axis with the number 1 to the configured axis with the number 1. The A-parameters in the parameter file for the axis with the number 2 are loaded to the configured axes with the numbers 2, 3, 4, 5, 6 and 8.</p> <p>Example (JavaScript):</p> <pre>args.Add("A-ParameterImportListByNumber", "*-&gt;*");</pre> <p>Loads the A-parameters from the parameter file to the axes specified in the parameter file.</p> <p>Example (JavaScript):</p> <pre>args.Add("A-ParameterImportListByNumber", "");</pre> <p>Causes the A-parameters in the parameter file not to be loaded.</p> <p>Example (JavaScript):</p> <pre>// nothing</pre> <p>If the key "A-ParameterImportListByNumber" is not specified, the A-parameters in the parameter file are not loaded.</p> <p>Key: "SP-ParameterImportListByNumber" [string], (drive parameters in the drive). Value: [string] [optional parameter] Same behavior as "A-ParameterImportListByNumber"</p> <p>Key: "SP-ParameterImportListByAddress" [string], (drive parameters in the drive) Value: [string] [optional parameter] Same behavior as "SP-ParameterImportListByNumber" except that the SERCOS addresses have to be specified at "SP-ParameterImportListByAddress" instead of logic axis numbers.</p>
ReadListParameter(string idn)	Rexroth .IndraWorks.Automation.AiList	<p>Reads a list parameter of the control or a SERCOS device (list parameter = parameter of variable length). Therefore, the MLC must be in "online" state. The individual elements of the list parameter are returned in an "AiList" as a list of strings [string].</p> <p>Parameters:</p> <p>idn [string], ident number of the parameter, such as "C-0-0001" or "C-0-0001.0.0". For axis-related parameters (A-, S-, P-parameters) and for kinematic parameters (K-parameters), the 3-digit reference number has to be specified as well such as "A001:A-0-0001" or "A001:A-0-0001.0.0" as well as "A001:S-0-0001" or "K001:K-0-0001".</p>
ReadParameter(string idn)	string	<p>Reads a "normal" parameter of the control or a SERCOS device. Therefore, the MLC must be in "online" state.</p> <p>Parameters:</p> <p>idn [string], ident number of the parameter. For the spelling of the ident number applies the same as under "ReadListParameter".</p>

XLC/MLC Objects

Method	Type	Description
SwitchPhase(int phase)	void	Switches to SERCOS phase. Therefore, the XLC must be in "online" state. If the phase cannot be switched, since an invalid phase was specified for example or the master axis is enabled, an exception is thrown. Parameters: phase [int], contains the target phase in numbers. The following target phases are allowed: <ul style="list-style-type: none"> <li>• 0 (download mode)</li> <li>• 2 (parameterization mode)</li> <li>• 4 (operating mode)</li> </ul>
WriteListParameter(string idn, Rexroth.IndraWorks.Automation.AiList values)	void	Writes a list parameter of the control or a SERCOS device (list parameter = parameter of variable length). The individual elements of the list parameter have to be transferred in an "AiList" as a list of strings [string]. Parameters: idn [string], ident number of the parameter. For the spelling of the ident number applies the same as under "ReadListParameter". values [Rexroth.IndraWorks.Automation.AiList], contains the elements of the list parameter to be written as list of strings [string].
WriteParameter(string idn, string value)	void	Writes a "normal" parameter of the control or a SERCOS device. Parameters: idn [string], ident number of the parameter. For the spelling of the ident number applies the same as under "ReadListParameter". value [string], contains the value to be written.

### 6.3 Adding an XLC

Using the Basis Automation Interface object **Project**, XLC devices can be added to the current project below the project node. Therefore, use the **CreateChild** method of the **Project** object.

Two function arguments have to be transferred to the **CreateChild** method: the type of the object (**XLC**) to be generated as well as a **Scripting.Dictionary** object containing the special XLC characteristics as key/value pairs.

**Object - Project, "CreateChild" method**

Method	Type	Description
CreateChild(string childLibGuid, object args)	Rexroth.IndraWorks.Automation.ProjectElement	This method of the Basis Automation Interface can be used to create a "ProjectElement" of the types "File", "Folder" or "Device" as child of the project node. To create a "ProjectElement" of the type "XLC", the following arguments have to or can be used.

## XLC/MLC Objects

## Object - Project, "CreateChild" method (continuation)

Method	Type	Description
CreateChild(string childLibGuid, object args)	Rexroth .IndraWorks.Automation.ProjectElement	<p><b>Creating an XLC:</b></p> <p>Parameters:</p> <p>childLibGuid [string], the object ("XLC") to be created.</p> <p>args [System.Dictionary]</p> <p>The property values of the XLC are transferred as key/value pairs to a System.Dictionary object. The following keys and values are available.</p> <p>Key: "Hardware" [string],</p> <p>Value: [string] XLC, hardware name.</p> <p>The following formats are supported:</p> <ul style="list-style-type: none"> <li>• "CML25.1-3N"</li> <li>• "CML25.1-3N-400-NA-NNNN-NW"</li> <li>• "CML25.1-PN"</li> <li>• "CML25.1-PN-400-NA-NNNN-NW"</li> <li>• "CML45.1-3P"</li> <li>• "CML45.1-3P-500-NA-NNNN-NW"</li> <li>• "CML45.1-NP"</li> <li>• "CML45.1-NP-500-NA-NNNN-NW"</li> <li>• "CML65.1-3P"</li> <li>• "CML65.1-3P-504-NA-NNNN-NW"</li> <li>• "CML65.1-NP"</li> <li>• "CML65.1-NP-504-NA-NNNN-NW"</li> </ul> <p>Only the front part is currently evaluated, such as "CML25.1-3N". If the back part is also indicated, the format has to correspond to the format given here.</p> <p>Key: "Firmware" [string],</p> <p>Value: [string] XLC, firmware name.</p> <p>The following firmware names are supported:</p> <ul style="list-style-type: none"> <li>• "FWA-CML25*-XL*-12V02"</li> <li>• "FWA-CML25*-XL*-12VRS"</li> <li>• "FWA-CML45*-XL*-12V02"</li> <li>• "FWA-CML45*-XL*-12VRS"</li> <li>• "FWA-CML65*-XL*-12V02"</li> <li>• "FWA-CML65*-XL*-12VRS"</li> </ul> <p>The firmware has to "fit" the hardware. No hardware "CML25.1-3N" may be used with the firmware "FWA-CML45*-XL*-12VRS" for example (conflict L25 ⇔ L45). When specifying "VRS" instead of "V02" for example, the latest firmware release is automatically used.</p>

**Object - Project, "CreateChild" method (continuation)**

Method	Type	Description
CreateChild(string childLibGuid, object args)	Rexroth .IndraWorks.Automation.ProjectElement	Key: "Name" [string], Value: [string] [optional parameter] Control name. If no name is given, it is automatically specified. Key: "IpAddress" [string], Value: [string] [optional parameter] IP address of the control. If no IP address is specified, it is automatically specified. Key: "PlcGateway" [string], Value: [string] [optional parameter] IP address of the PLC gateways. If no PLC gateway is specified, "localhost" is used. Key: "PlcSecureOnlineMode" [string], Value: [string] [optional parameter] "True" if the secure online mode should be used, otherwise "False" (default). Key: "Author" [string], Value: [string] [optional parameter] Name of the person who added the control to the project. Key: "Comment" [string], Value: [string] [optional parameter] Comment.

## 6.4 Object - MLC (Derived from Device)

The **MLC** object represents a device of the **MLC** type, i.e. a system-specific device within an IndraWorks project. Its interface is identical to the **XLC** object. That means that it is provided with the same attributes and methods.

**Attributes of MLC**

Attribute	Type	Description
IsMultiDeviceEnabled	bool	Read-only. Returns the information whether the multi-device functionality is used. True: Multi-device is used. False: Multi-device is not used.
IsOnline	bool	Read-only, inherited from "Device". True: MLC in the IndraWorks project connected to the physical MLC. False: No connection between MLC in the IndraWorks project and the physical MLC.
MultiDeviceTable	object	Read-only. Returns a reference to the MLC-internal object "MultiDeviceTable".

## XLC/MLC Objects

## Methods of MLC

Method	Type	Description
ClearErrors()	void	Deletes all errors on the control and in the connected SERCOS drives. Therefore, the MLC must be in "online" state.
DisableMultiDevice()	void	Do not use the multi-device functionality. If the multi-device functionality cannot be disabled, an exception is thrown.
DownloadFirmware(string fileName)	void	Loads the firmware in the "fileName" file to the control. Therefore, the MLC has to be in download mode (SERCOS phase P0) and the PLC has to be stopped. Parameters: fileName [string], contains the complete name and path of the file of type "FW" in the firmware. Example: "C:\FW\CML45s-MLs-12T01.0040.fw"
EnableMultiDevice()	void	Using multi-device functionality. The MLC may neither be in "online" state nor in "logged in" state. If the multi-device functionality cannot be used, since the MLC is in "online" state and/or "logged in", an exception is thrown.
GetObject(string object)	object	Returns a reference to an object assigned to the MLC. If the requested object is not known, an exception is thrown. Parameters: Object [string], string of the searched object. Currently, only "Logic" is available as object.
GetPhase()	int	Returns the current SERCOS phase. Therefore, the MLC must be in "online" state. If the phase cannot be read since the MLC is not in "online" state for example, an exception is thrown.
GoOffline()	void	Inherited from "Device". Cancels a connection between the MLC in the IndraWorks project and a physical MLC. If it cannot be gone offline, an exception is thrown.
GoOnline()	void	Inherited from "Device". Establishes a connection between the MLC in the IndraWorks project and a physical MLC. If the online connection cannot be established, since the PLC should be stopped or the planned drive configuration does not match, the connection established is aborted and an exception is thrown.
ImportParameter(string fileName)	string	Imports the SERCOS parameters in the "fileName" file. Therefore, the MLC must be in "online" state. Possible writing errors such as "date and time write-protected" are collected by the method and returned as string at the end of the parameter import. The line format is "IDN ParameterName Result". Parameters: fileName [string], contains the complete name and path of the file to be imported of type "PAR". Example: "C:\Archive\Parameters.par"

## XLC/MLC Objects

Method	Type	Description
ImportParameter2(string fileName, Scripting.Dictionary args)	string	<p>Imports the SERCOS parameters in the "fileName" file. Therefore, the MLC must be in "online" state. In contrast to "ImportParameter", it has to be specified which parameter types should be imported in which axes (or controls).</p> <p>Possible writing errors such as "date and time write-protected" are collected by the method and returned as string at the end of the parameter import. The line format is "IDN ParameterName Result".</p> <p>Parameters:</p> <p>fileName [string], contains the complete name and path of the file to be imported of type "PAR". Example: "C:\Archive\Parameters.par"</p> <p>args [System.Dictionary]</p> <p>All specific parameter specifications on the parameter import are transferred to a System.Dictionary object. The following keys and values are available.</p> <p>Key: "C-ParameterImportListByNumber" [string], (control parameters). Value: [string] [optional parameter]</p> <p>Contains the parameter file "C-parameters". If the C-parameters should be imported, the string "*-&gt;*" has to be specified. If the key "C-ParameterImportListByNumber" is not specified or an empty string "" is specified (default value), the C-parameters are not loaded. If the parameter file does not contain any C-parameters, the specification is ignored.</p> <p>Example (JavaScript):</p> <pre>args.Add( "C-ParameterImportListByNumber", "*-&gt;*" );</pre> <p>Loads the C-parameters from the parameter file to the control.</p> <p>Example (JavaScript):</p> <pre>args.Add( "C-ParameterImportListByNumber", "" );</pre> <p>Causes the C-parameters in the parameter file not to be loaded.</p> <p>Key: "K-ParameterImportListByNumber" [string] (kinematic parameters). Value: [string] [optional parameter]</p> <p>Same behavior as "C-ParameterImportListByNumber"</p> <p>Key: "M-ParameterImportListByNumber" [string] (touch probe parameters). Value: [string] [optional parameter]</p> <p>Same behavior as "C-ParameterImportListByNumber"</p> <p>Key: "O-ParameterImportListByNumber" [string] (oscilloscope parameters). Value: [string] [optional parameter]</p> <p>Same behavior as "C-ParameterImportListByNumber"</p>

## XLC/MLC Objects

Method	Type	Description
ImportParameter2(string fileName, Scripting.Dictionary args) (Continuation)	string	<p>Key: "A-ParameterImportListByNumber" [string] (drive-related parameters in the control). Value: [string] [optional parameter]</p> <p>Contains the parameter file "A-parameters" and if the A-parameters should be loaded, the axis numbers on which the A-parameters are to be loaded can be specified with a comma-separated list. Ranges can also be defined with "-". A-parameters are not loaded with "" (default value). If the key "A-ParameterImportListByNumber" is not specified, the A-parameters in the parameter file are not loaded. If the parameter file does not contains any A-parameters, the specification is ignored.</p> <p>Example (JavaScript):</p> <pre>args.Add("A-ParameterImportListByNumber", "1-&gt;1; 2-&gt;2,3-6,8");</pre> <p>Loads the A-parameters from the parameter file for the axis with the number 1 to the configured axis with the number 1. The A-parameters in the parameter file for the axis with the number 2 are loaded to the configured axes with the numbers 2, 3, 4, 5, 6 and 8.</p> <p>Example (JavaScript):</p> <pre>args.Add("A-ParameterImportListByNumber", "*-&gt;*");</pre> <p>Loads the A-parameters from the parameter file to the axes specified in the parameter file.</p> <p>Example (JavaScript):</p> <pre>args.Add("A-ParameterImportListByNumber", "");</pre> <p>Causes the A-parameters in the parameter file not to be loaded.</p> <p>Example (JavaScript):</p> <pre>// nothing</pre> <p>If the key "A-ParameterImportListByNumber" is not specified, the A-parameters in the parameter file are not loaded.</p> <p>Key: "SP-ParameterImportListByNumber" [string], (drive parameters in the drive). Value: [string] [optional parameter] Same behavior as "A-ParameterImportListByNumber"</p> <p>Key: "SP-ParameterImportListByAddress" [string], (drive parameters in the drive) Value: [string] [optional parameter] Same behavior as "SP-ParameterImportListByNumber" except that the SERCOS addresses have to be specified at "SP-ParameterImportListByAddress" instead of logic axis numbers.</p>
ReadListParameter(string idn)	Rexroth .IndraWorks.Automation.AiList	<p>Reads a list parameter of the control or a SERCOS device (list parameter = parameter of variable length). The individual elements of the list parameter are returned in an "AiList" as a list of strings [string].</p> <p>Parameters:</p> <p>idn [string], ident number of the parameter, such as "C-0-0001" or "C-0-0001.0.0". For axis-related parameters (A-, S-, P-parameters) and for kinematic parameters (K-parameters), the 3-digit reference number has to be specified as well such as "A001:A-0-0001" or "A001:A-0-0001.0.0" as well as "A001:S-0-0001" or "K001:K-0-0001".</p>
ReadParameter(string idn)	string	<p>Reads a "normal" parameter of the control or a SERCOS device.</p> <p>Parameters:</p> <p>idn [string], ident number of the parameter. For the spelling of the ident number applies the same as under "ReadListParameter".</p>

XLC/MLC Objects

Method	Type	Description
SwitchPhase(int phase)	void	Switches to SERCOS phase. Therefore, the MLC must be in "online" state. If the phase cannot be switched, since an invalid phase was specified for example or the master axis is enabled, an exception is thrown. Parameters: phase [int], contains the target phase in numbers. The following target phases are allowed: <ul style="list-style-type: none"> <li>• 0 (download mode)</li> <li>• 2 (parameterization mode)</li> <li>• 4 (operating mode)</li> </ul>
WriteListParameter(string idn, Rexroth.IndraWorks.Automation.AiList values)	void	Writes a list parameter of the control or a SERCOS device (list parameter = parameter of variable length). Therefore, the MLC must be in "online" state. The individual elements of the list parameter have to be transferred in an "AiList" as a list of strings [string]. Parameters: idn [string], ident number of the parameter. For the spelling of the ident number applies the same as under "ReadListParameter". values [Rexroth.IndraWorks.Automation.AiList], contains the elements of the list parameter to be written as list of strings [string].
WriteParameter(string idn, string value)	void	Writes a "normal" parameter of the control or a SERCOS device. Therefore, the MLC must be in "online" state. Parameters: idn [string], ident number of the parameter. For the spelling of the ident number applies the same as under "ReadListParameter". value [string], contains the value to be written.

## 6.5 Adding an MLC

Using the Basis Automation Interface object **Project**, MLC devices can be added to the current project below the project node. As for the XLC device, the **CreateChild** method of the **Project** object has to be called to add an MLC.

### Object - Project, "CreateChild" method

Method	Type	Description
CreateChild(string childLibGuid, object args)	Rexroth.IndraWorks.Automation.ProjectElement	This method of the Basis Automation Interface can be used to create a "ProjectElement" of the types "File", "Folder" or "Device" as child of the project node. To create a "ProjectElement" of the type "MLC", the following arguments have to or can be used.

## XLC/MLC Objects

## Object - Project, "CreateChild" method (continuation)

Method	Type	Description
CreateChild(string childLibGuid, object args)	Rexroth .IndraWorks.Automation.ProjectElement	<p><b>Creating an MLC:</b></p> <p>Parameters:</p> <p>childLibGuid [string], the object ("MLC") to be created.</p> <p>args [System.Dictionary]</p> <p>The property values of the MLC are transferred as key/value pairs to a System.Dictionary object. The following keys and values are available.</p> <p>Key: "Hardware" [string],</p> <p>Value: [string], hardware name.</p> <p>The following formats are supported:</p> <ul style="list-style-type: none"> <li>• "CML25.1-3N"</li> <li>• "CML25.1-3N-400-NA-NNNN-NW"</li> <li>• "CML45.1-3P"</li> <li>• "CML45.1-3P-500-NA-NNNN-NW"</li> <li>• "CML65.1-3P"</li> <li>• "CML65.1-3P-504-NA-NNNN-NW"</li> </ul> <p>Only the front part is currently evaluated, such as "CML25.1-3N". If the back part is also indicated, the format has to correspond to the format given here.</p> <p>Key: "Firmware" [string],</p> <p>Value: [string], firmware name.</p> <p>The following firmware names are supported:</p> <ul style="list-style-type: none"> <li>• "FWA-CML25*-ML*-12V02"</li> <li>• "FWA-CML25*-ML*-12VRS"</li> <li>• "FWA-CML45*-ML*-12V02"</li> <li>• "FWA-CML45*-ML*-12VRS"</li> <li>• "FWA-CML65*-ML*-12V02"</li> <li>• "FWA-CML65*-ML*-12VRS"</li> </ul> <p>The firmware has to "fit" the hardware. No hardware "CML25.1-3N" may be used with the firmware "FWA-CML45*-ML*-12VRS" for example (conflict L25 ⇔ L45). When specifying "VRS" instead of "V02" for example, the latest firmware release is automatically used.</p>

**Object - Project, "CreateChild" method (continuation)**

Method	Type	Description
CreateChild(string childLibGuid, object args)	Rexroth .IndraWorks.Automation.ProjectElement	Key: "Name" [string], Value: [string] [optional parameter] Control name. If no name is given, it is automatically specified. Key: "IpAddress" [string], Value: [string] [optional parameter] IP address of the control. If no IP address is specified, it is automatically specified. Key: "PlcGateway" [string], Value: [string] [optional parameter] IP address of the PLC gateways. If no PLC gateway is specified, "localhost" is used. Key: "PlcSecureOnlineMode" [string], Value: [string] [optional parameter] "True" if the secure online mode should be used, otherwise "False" (default). Key: "Author" [string], Value: [string] [optional parameter] Name of the person who added the control to the project. Key: "Comment" [string], Value: [string] [optional parameter] Comment.

## 6.6 Object - MultiDeviceTable

The **MultiDeviceTable** object is an XLC/MLC-specific object which exclusively provides attributes and methods for the multi-device functionality. This object is accessed from the objects **XLC** or **MLC** via the **MultiDeviceTable** attribute.

**Attribute of MultiDeviceTable**

Attribute	Type	Description
DeviceNames	Rexroth.IndraWorks.Automation.AiCollection	Read-only. Provides a string collection with the names of all devices in the multi-device table.

**Methods of MultiDeviceTable**

Method	Type	Description
ActivateDevice(string deviceName)	void	Enables a device in the multi-device table. The XLC/MLC may neither be in "online" state nor in "logged in" state. The activated device can then be used in IndraWorks. It can be used for a PLC program download or a parameter import. If the specified device cannot be activated, since it is not in the multi-device tables, an exception is thrown. Parameters: deviceName [string]: Name of a device in the multi-device tables such as "XLC_21" or "MLC_21".



## 7 Example Codes - XLC/MLC Objects

### 7.1 Example Code - Access to the XLC/MLC

*Program:*

---

```
var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get all devices of type "XLC"
    var objXLCs = objProject.GetChildrenOfType("XLC", false); // "XLC" <=> "MLC"
    WScript.Echo("" + objXLCs.Count + " XLC(s) in project found");

    // Iterate over all XLCs in the actual project until the specific XLC is found
    var objXLC = null;
    for (var enuXLCs = new Enumerator(objXLCs); !enuXLCs.atEnd(); enuXLCs.moveNext())
    {
        objXLC = enuXLCs.item();
        if (objXLC.Name == "IndraLogicXlc2")
        {
            // Do something with IndraLogicXlc2
            break;
        }
    }

    // Get all devices of type "MLC"
    var objMLCs = objProject.GetChildrenOfType("MLC", false); // "XLC" <=> "MLC"
    WScript.Echo("" + objMLCs.Count + " MLC(s) in project found");

    // Iterate over all MLCs in the actual project until the specific MLC is found
    var objMLC = null;
    for (var enuMLCs = new Enumerator(objMLCs); !enuMLCs.atEnd(); enuMLCs.moveNext())
    {
        objMLC = enuMLCs.item();
        if (objMLC.Name == "IndraMotionMlc3")
        {
            // Do something with IndraMotionMlc3
            break;
        }
    }

    // Disconnect from IndraWorks
    objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}
```

---

### 7.2 Example Code - Going Online/Offline

*Program:*

---

```
var g_booOpenProject = false;
```

## Example Codes - XLC/MLC Objects

```

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get first XLC in project
    var objXLCs = objProject.ChildrenOfType("XLC", false); // "XLC" <=> "MLC"
    var objXLC = (new Enumerator(objXLCs)).item();

    // Go online
    objXLC.GoOnline();
    if (objXLC.IsOnline)
        WScript.Echo("XLC is online");

    // Go offline
    objXLC.GoOffline();
    if (!objXLC.IsOnline)
        WScript.Echo("XLC is offline");

    // Get first MLC in project
    var objMLCs = objProject.ChildrenOfType("MLC", false); // "XLC" <=> "MLC"
    var objMLC = (new Enumerator(objMLCs)).item();

    // Go online
    objMLC.GoOnline();
    if (objMLC.IsOnline)
        WScript.Echo("MLC is online");

    // Go offline
    objMLC.GoOffline();
    if (!objMLC.IsOnline)
        WScript.Echo("MLC is offline");

    // Disconnect from IndraWorks
    objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}

```

## 7.3 Example Code - Reading/Writing Phase

*Program:*

```

var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

```

## Example Codes - XLC/MLC Objects

```

// Get first XLC in project
var objXLCs = objProject.ChildrenOfType("XLC", false); // "XLC" <=> "MLC"
var objXLC = (new Enumerator(objXLCs)).item();

// Go online
objXLC.GoOnline();

WScript.Echo("Actual phase: " + objXLC.GetPhase());

// Switch phase if not in P4
if (objXLC.GetPhase() != 4)
    objXLC.SwitchPhase(4);

WScript.Echo("Actual phase: " + objXLC.GetPhase());

// Go offline
objXLC.GoOffline();

// Get first MLC in project
var objMLCs = objProject.ChildrenOfType("MLC", false); // "XLC" <=> "MLC"
var objMLC = (new Enumerator(objMLCs)).item();

// Go online
objMLC.GoOnline();

WScript.Echo("Actual phase: " + objMLC.GetPhase());

// Switch phase if not in P4
if (objMLC.GetPhase() != 4)
    objMLC.SwitchPhase(4);

WScript.Echo("Actual phase: " + objMLC.GetPhase());

// Go offline
objMLC.GoOffline();

// Disconnect from IndraWorks
objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}

```

## 7.4 Example Code - Importing Parameter

*Program:*

```

var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get first XLC in project
    var objXLCs = objProject.ChildrenOfType("XLC", false); // "XLC" <=> "MLC"
    var objXLC = (new Enumerator(objXLCs)).item();

    // Go online

```

## Example Codes - XLC/MLC Objects

```

objXLC.GoOnline();

// Switch phase if not in P2
if (objXLC.GetPhase() != 2)
    objXLC.SwitchPhase(2);

// Import parameter
var strErrors = objXLC.ImportParameter("C:\\IW-Projects\\XlcParameter.par")
WScript.Echo("Import erros:");
WScript.Echo(strErrors);

// Get first MLC in project
var objMLCs = objProject.GetChildrenOfType("MLC", false); // "XLC" <=> "MLC"
var objMLC = (new Enumerator(objMLCs)).item();

// Go online
objMLC.GoOnline();

// Switch phase if not in P2
if (objMLC.GetPhase() != 2)
    objMLC.SwitchPhase(2);

// Import parameter via load list
var args = new ActiveXObject("Scripting.Dictionary");
args.Add("C-ParameterImportListByNumber", "*->*");
args.Add("A-ParameterImportListByNumber", "1->1; 2->2,3-6,8");
args.Add("SP-ParameterImportListByNumber", "1->1; 2->2,3-6,8");

var strErrors = objMLC.ImportParameter2("C:\\IW-Projects\\MlcParameter.par", args)
WScript.Echo("Import erros:");
WScript.Echo(strErrors);

// Go offline
objMLC.GoOffline();

// Disconnect from IndraWorks
objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}

```

## 7.5 Example Code - Reading/Writing Parameter

This example can also be used for an MLC if the `GetChildrenOfType("XLC", false)` call is replaced by `GetChildrenOfType("MLC", false)`.

*Program:*

```

var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get first XLC in project
    var objXLCs = objProject.GetChildrenOfType("XLC", false); // "XLC" <=> "MLC"
    var objXLC = (new Enumerator(objXLCs)).item();
}

```

## Example Codes - XLC/MLC Objects

```

// Go online
objXLC.GoOnline();

// Switch phase if not in P2
if (objXLC.GetPhase() != 2)
    objXLC.SwitchPhase(2);

// "Normal" parameter

// Read parameter
var objValue = objXLC.ReadParameter("C-0-0081");
WScript.Echo("Value of C-0-0081: " + objValue);

// Write parameter
objXLC.WriteParameter("C-0-0081", "New value of the C-0-0081");

// Reread parameter
objValue = objXLC.ReadParameter("C-0-0081");
WScript.Echo("Value of C-0-0081: " + objValue);

// List parameter

// Read list parameter values
var objAiList = objXLC.ReadListParameter("C-0-0484");
WScript.Echo("C-0-0484 contains a fixed length of " + objAiList.Count + " entries:");
for (var numIndex = 0; numIndex < objAiList.Count; numIndex++)
{
    WScript.Echo(objAiList.Item(numIndex));
}

// Write list parameter values
objAiList = new ActiveXObject("Rexroth.IndraWorks.Automation.AiList");
objAiList.Add("16");
objAiList.Add("0");
objAiList.Add("16");
objAiList.Add("0");

objXLC.WriteListParameter("C-0-0484", objAiList);

// Reread list parameter values
objAiList = objXLC.ReadListParameter("C-0-0484");
WScript.Echo("C-0-0484 contains a fixed length of " + objAiList.Count + " entries:");
for (var numIndex = 0; numIndex < objAiList.Count; numIndex++)
{
    WScript.Echo(objAiList.Item(numIndex));
}

// Go offline
objXLC.GoOffline();

// Disconnect from IndraWorks
objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}

```

## 7.6 Example Code - Firmware Download

This example can also be used for an MLC if the `GetChildrenOfType("XLC", false)` call is replaced by `GetChildrenOfType("MLC", false)`.

*Program:*

```

var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

```

## Example Codes - XLC/MLC Objects

```

// Project-Manager
var objProjectManager = objApplication.ProjectManager;

// Open or use an already existing project
var objProject = null;
if (g_booOpenProject)
    objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
else
    objProject = (new Enumerator(objProjectManager.Projects)).item();

// Get first XLC in project
var objXLCs = objProject.GetChildrenOfType("XLC", false); // "XLC" <=> "MLC"
var objXLC = (new Enumerator(objXLCs)).item();

// Get Logic object
var objLogic = objXLC.GetObject("Logic");

// Get Application object (see PLC documentation)
var objPlcApplication = objLogic.GetObject("Application");

// Stop PLC
objPlcApplication.Stop();

// Go online
objXLC.GoOnline();

// Switch phase if not in P0 (download mode)
if (objXLC.GetPhase() != 0)
    objXLC.SwitchPhase(0);

// Download firmware
WScript.Echo("Downloading firmware...");
objXLC.DownloadFirmware("C:\\IW-Projects\\CML65s-XLs-12T01.0040.fw");

// Switch to P4
objXLC.SwitchPhase(4);

// Clear errors
objXLC.ClearErrors();

// Go offline
objXLC.GoOffline();

// Disconnect from IndraWorks
objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}

```

## 7.7 Example Code - Adding XLC/MLC

*Program:*

```

var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();
}

```

## Example Codes - XLC/MLC Objects

```

// Scripting.Dictionary object for creating a XLC with a minimum of properties
var args = new ActiveXObject("Scripting.Dictionary");
args.Add("Hardware", "CML25.1-3N");
args.Add("Firmware", "FWA-CML25*-XL*-12VRS");

// Create XLC
objProject.CreateChild("XLC", args);

// Scripting.Dictionary object for creating a MLC with a maximum of properties
var args = new ActiveXObject("Scripting.Dictionary");
args.Add("Hardware", "CML65.1-3P-500-NA-NNNN-NW");
args.Add("Firmware", "FWA-CML65*-ML*-12VRS");
args.Add("Name", "MLC_212");
args.Add("IpAddress", "10.52.10.212");
args.Add("PlcGateway", "localhost");
args.Add("PlcSecureOnlineMode", "True");
args.Add("Author", "Kim");
args.Add("Comment", "Control Unit 212");

// Create MLC
objProject.CreateChild("MLC", args);

// Disconnect from IndraWorks
objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}

```

## 7.8 Example Code - Using/Not Using Multi-Device

This example can also be used for an MLC if the `GetChildrenOfType("XLC", false)` call is replaced by `GetChildrenOfType("MLC", false)`.

*Program:*

```

var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get first XLC in project
    var objXLCs = objProject.GetChildrenOfType("XLC", false); // "XLC" <=> "MLC"
    var objXLC = (new Enumerator(objXLCs)).item();

    // Enable multi-device
    objXLC.EnableMultiDevice()
    WScript.Echo("Multi-Device is " + objXLC.IsMultiDeviceEnabled ? "enabled" : "disabled");

    // Disable multi-device
    objXLC.DisableMultiDevice()
    WScript.Echo("Multi-Device is " + objXLC.IsMultiDeviceEnabled ? "enabled" : "disabled");

    // Disconnect from IndraWorks
    objApplication.Disconnect();
}

```

## Example Codes - XLC/MLC Objects

```
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}
```

---

## 7.9 Code Example - Activating an XLC/MLC from the Multi-Device Table

This example can also be used for an MLC if the `GetChildrenOfType("XLC", false)` call is replaced by `GetChildrenOfType("MLC", false)`.

*Program:*

---

```
var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get first XLC in project
    var objXLCs = objProject.GetChildrenOfType("XLC", false); // "XLC" <=> "MLC"
    var objXLC = (new Enumerator(objXLCs)).item();

    // Enable multi-device
    objMLC.EnableMultiDevice();

    // Get multi-device table object
    var objMultiDeviceTable = objXLC.MultiDeviceTable;

    // Iterate over all devices inside the AiCollection
    var objDeviceNames = objMultiDeviceTable.DeviceNames;
    for (var enuDeviceNames = new Enumerator(objDeviceNames); !enuDeviceNames.atEnd(); enuDeviceNames.moveNext())
    {
        // Look for specific device inside the multi-device table
        var strDeviceName = enuDeviceNames.item();
        if (strDeviceName == "XLC22")
        {
            // Activate specific device
            objMultiDeviceTable.ActivateDevice(strDeviceName);
            break;
        }
    }

    // Disconnect from IndraWorks
    objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}
```

---

## 7.10 Code Example - Accessing the "Logic" Object

This example can also be used for an MLC if the `GetChildrenOfType("XLC", false)` call is replaced by `GetChildrenOfType("MLC", false)`.

*Program:*

---

```
var g_booOpenProject = false;

try
{
    // Connect to IndraWorks
    var objApplication = WScript.GetObject("", "Rexroth.IndraWorks.Automation.Application");
    objApplication.Connect("localhost", "automation");

    // Project-Manager
    var objProjectManager = objApplication.ProjectManager;

    // Open or use an already existing project
    var objProject = null;
    if (g_booOpenProject)
        objProject = objProjectManager.OpenProject("C:\\IW-Projects\\Project.iwp");
    else
        objProject = (new Enumerator(objProjectManager.Projects)).item();

    // Get first XLC in project
    var objXLCs = objProject.GetChildrenOfType("XLC", false);
    var objXLC = (new Enumerator(objXLCs)).item();

    // Get Logic object
    var objLogic = objXLC.GetObject("Logic");

    // Get Application object (see PLC documentation)
    var objPlcApplication = objLogic.GetObject("Application");

    // Do something with objPlcApplication (see PLC documentation)

    // Disconnect from IndraWorks
    objApplication.Disconnect();
}
catch (ex)
{
    WScript.Echo("");
    WScript.Echo("=== Error ===");
    WScript.Echo("Message: " + ex.message);
    WScript.Echo("");
}
```

---



## 8 IL Objects

### 8.1 Object – Logic

The **Logic** object represents the PLC Logic subobject.

#### Methods of Logic

Method	Type	Description
GetObject(string object)	object	Provides the reference to an object assigned to the "Logic" object. Parameter object [string], name of the object searched. Currently, the "Application" object is allowed. Example: <pre>var logic = device.GetObject("Logic");</pre>

### 8.2 Object – Application

The **Application** object represents an application below the **Logic** object. Different functions of an application can be executed via this object.

To access the application via the Automation Interface, the following commands are available:

#### Attributes of Application

Method	Type	Description
IsRunning	bool	Returns whether the PLC of the application is running. True: PLC running. False: PLC not running.
IsLoggedIn	bool	Returns whether logged in on the application. True: Logged in on application False: Not logged in.

## IL Objects

## Methods of Application

Method	Type	Description
Login()	string	<p>Logging on the application.</p> <p>If the PLC program was changed, it is compiled and subsequently downloaded via "Download".</p> <p>In case of error (if the PLC program was not correctly compiled for example), an exception is thrown. Otherwise, compiler warnings and other outputs are returned as string.</p> <p>Example:</p> <pre>var application = logic.GetObject("Application"); application.Login();</pre>
Login2(int mode)	string	<p>Logging on the application. If the PLC program was changed, it is compiled and subsequently downloaded as follows:</p> <p>Parameters: mode [int],</p> <ul style="list-style-type: none"> <li>• 0: Log in without changes</li> <li>• 1: Log in with online change</li> <li>• 2: Log in with "Download"</li> <li>• 3: If OC possible, log in with OC, otherwise "Download"</li> </ul> <p>In case of error (if the PLC program was not correctly compiled for example), an exception is thrown. Otherwise, compiler warnings and other outputs are returned as string.</p> <p>Example:</p> <pre>var application = logic.GetObject("Application"); application.Login2(0);</pre>
Logout()	void	Executes the command "Log out".
Build()	string	<p>Compiles the PLC program.</p> <p>Provides the errors occurred as string. If no error occurred, an empty string is returned.</p>
Rebuild()	string	<p>Compiles the PLC program again.</p> <p>Provides the errors occurred as string. If no error occurred, an empty string is returned.</p>
Download()	string	<p>Transfers the PLC program to the control.</p> <p>If the PLC program was changed, it is compiled again before.</p> <p>In case of error (if the PLC program was not correctly compiled for example), an exception is thrown. Otherwise, compiler warnings and other outputs are returned as string.</p> <p>Example:</p> <pre>var application = logic.GetObject("Application"); var erg = application.Download();</pre>

## IL Objects

Method	Type	Description
Download2(int mode)	string	<p>Transfers the PLC program to the control as follows:</p> <p>Parameters: mode [int],</p> <ul style="list-style-type: none"><li>• 1: Log in with online change.</li><li>• 2: Log in with "Download".</li><li>• 3: If OC possible, log in with OC, otherwise "Download".</li></ul> <p>In case of error (if the PLC program was not correctly compiled for example), an exception is thrown. Otherwise, compiler warnings and other outputs are returned as string.</p> <p>Example:</p> <pre>var application = logic.GetObject("Application"); var erg = application.Download2(0);</pre>
Start()	void	Starts the application.
Stop()	void	Stops the application.



## 9 Service and Support

Our service helpdesk at our headquarters in Lohr, Germany and our worldwide service will assist you with all kinds of enquiries. You can reach us **around the clock - even on weekend and on holidays**.

	Helpdesk	Service Hotline Worldwide
Phone	+49 (0) 9352 40 50 60	Outwith Germany please contact our sales/service office in your area first.
Fax	+49 (0) 9352 40 49 41	
E-mail	<a href="mailto:service.svc@boschrexroth.de">service.svc@boschrexroth.de</a>	For hotline numbers refer to the sales office addresses on the Internet.
Internet	<a href="http://www.boschrexroth.com">http://www.boschrexroth.com</a> You will also find additional notes regarding service, maintenance (e.g. delivery addresses) and training.	

### Preparing Information

For quick and efficient help please have the following information ready:

- Detailed description of the fault and the circumstances
- Information on the type plate of the affected products, especially type codes and serial numbers
- Your phone, fax numbers and e-mail address so we can contact you in case of questions.



# Index

## A

About this documentation	
Validity of the documentation .....	3
About this Documentation.....	3
Access devices.....	33
Access to "Logic" object.....	61
Access to the MLC.....	53
Access to the XLC.....	53
Activate an XLC/MLC from a multi-device table.	60
Add folders and files.....	30
Add MLC.....	58
Add XLC.....	58
Application	
Attributes .....	63
Methods .....	64
Object .....	63
Appropriate use	
Use cases .....	9
Appropriate Use	
Introduction .....	9
Archive a project.....	34
Automation Interface	
Example codes, XLC/MLC .....	53
IL objects .....	63
Scripting .....	12
Using automation scripts .....	12
XLC/MLC objects .....	39

## C

Code examples, XLC/MLC	
Access to "Logic" object .....	61
Activate an XLC/MLC from a multi-device table .....	60
Create an IndraWorks project.....	29

## E

Example codes, XLC/MLC.....	53
Access to the MLC .....	53
Access to the XLC .....	53
Add MLC .....	58
Add XLC .....	58
Firmware download .....	57
Go online/offline .....	53
Import parameter .....	55
Read/write parameter .....	56
Read/write phase .....	54
Using/not using multi-device .....	59

## F

Firmware download.....	57
------------------------	----

## G

Go online/offline.....	53
------------------------	----

## I

IL objects.....	63
Import parameter.....	55
Inappropriate Use.....	10
Consequences, Exclusion of Liability .....	9
Initialize the Automation Interface.....	29

## L

Logic	
Methods .....	63
Object .....	63

## M

MLC	
Add .....	49
Attributes .....	45
Methods .....	46
Object model .....	39
Objects .....	45
MultiDeviceTable	
Attributes .....	51
Methods .....	51
Object .....	51

## O

Open an IndraWorks project.....	30
---------------------------------	----

## R

Read/write parameter.....	56
Read/write phase.....	54
Restore a project.....	35

## S

Scripting.....	12
Search in projects.....	31
Support	
see Service Hotline .....	67

## U

Using/not using multi-device.....	59
Using automation scripts.....	12

## V

Validate a project.....	36
-------------------------	----

## X

XLC	
Add .....	43
Attributes .....	40
Methods .....	40
Object .....	39

Index

**X**

...XLC

Object model ..... 39

# Notes

Bosch Rexroth AG  
Electric Drives and Controls  
P.O. Box 13 57  
97803 Lohr, Germany  
Bgm.-Dr.-Nebel-Str. 2  
97816 Lohr, Germany  
Tel. +49 (0)93 52-40-0  
Fax +49 (0)93 52-48 85  
[www.boschrexroth.com/electrics](http://www.boschrexroth.com/electrics)



R911334178